Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cofiyard G3E040

Cofiyard G3E040 20,000 BTUs 2 Burner Propane Camping Stove Instruction Manual

1. Product Overview

The Cofiyard G3E040 is a portable, dual-burner propane camping stove designed for outdoor cooking. Its compact and foldable design makes it suitable for various outdoor activities such as camping, hiking, and tailgating. Featuring two adjustable burners with a combined output of 20,000 BTUs, it provides efficient heat for preparing meals.



Figure 1: The Cofiyard G3E040 camping stove shown in both its compact, folded state and fully unfolded, ready for use. The image highlights its dual burner design and integrated carrying handle.

2. Safety Information

WARNING: For outdoor use only. Do not operate indoors or in enclosed spaces. Ensure adequate ventilation.

- Always operate the stove on a stable, level surface.
- Keep flammable materials at a safe distance from the stove.
- Check all gas connections for leaks before each use.
- Do not leave the stove unattended while in operation.
- Keep children and pets away from the stove during use.
- Use only propane fuel with the provided regulator.
- Allow the stove to cool completely before cleaning or storing.

3. Package Contents

Your Cofiyard G3E040 camping stove package includes the following items:

- 1 x Cofiyard Camping Gas Stove with 2 Burners (Folding)
- 1 x Cofiyard Gas Stove Regulator
- 1 x Cofiyard Woven Carry Bag
- 1 x User Manual

4. Setup Instructions

1. **Unfold the Stove:** Place the stove on a stable, level surface. Unlatch the two halves and unfold them until they are fully extended and stable.
2. **Install Grates:** Place the removable grates securely over each burner.
3. **Connect Regulator:** Attach the provided gas stove regulator to the stove's gas inlet. Ensure it is threaded on securely to prevent leaks.
4. **Connect Propane Tank:** Screw a 1 lb (16 oz) propane tank onto the regulator. Hand-tighten only. Do not overtighten.
5. **Check for Leaks:** Before lighting, apply a soapy water solution to all connections. Bubbles indicate a leak. Tighten connections or replace parts if leaks persist.



Figure 2: Close-up view of the stove's ignition and control knobs, with the regulator and a 1 lb propane tank connected. This illustrates the gas connection process.

Video 1: A seller demonstration showing the setup process of a similar dual-burner camping stove, including connecting the propane tank and unfolding the unit.

5. Operating Instructions

1. **Ignition:** Ensure the propane tank is connected and the regulator valve is open. Push and turn the desired burner knob counter-clockwise to the 'ON' position (usually past the maximum setting) until you hear a click, which activates the built-in ignition system. The burner should light immediately.
2. **Adjust Flame:** Once lit, adjust the burner knob to achieve the desired flame intensity. The stove offers precise flame control from low simmer to high heat.
3. **Cooking:** Place your cookware on the grates over the lit burners. The dual burners allow for cooking multiple dishes simultaneously.
4. **Wind Resistance:** The stove is designed with exceptional wind resistance, often eliminating the need for an external windscreen in mild conditions.

5. **Shut Down:** To turn off a burner, turn the knob clockwise to the 'OFF' position. Close the valve on the propane tank when finished cooking.



Figure 3: The Cofiyard G3E040 stove in operation, demonstrating its capability to accommodate two pots for simultaneous cooking, highlighting its dual burner functionality.

Video 2: A seller demonstration from Cofiyard-US showing the stove in use for cooking, highlighting its practical application for outdoor meals.

6. Maintenance & Cleaning

Regular maintenance ensures the longevity and optimal performance of your camping stove.

- **Cleaning:** The stove features a high-quality 304 stainless steel cooktop and removable grates, making cleaning easy. Allow the stove to cool completely. Remove the grates and wipe down all surfaces with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Corrosion Resistance:** Constructed with corrosion-resistant materials (Iron, Metal, PA66, Stainless Steel), the stove is built for durability in various outdoor environments.
- **Storage:** Ensure the stove is clean and dry before folding and storing it in the provided woven carry bag.

Store in a cool, dry place away from direct sunlight.



Figure 4: A hand demonstrating the ease of cleaning the Cofiyard camping stove by wiping its removable grate, emphasizing its user-friendly maintenance.

7. Troubleshooting

If you encounter issues with your stove, refer to the following common problems and solutions:

- **Burner Not Lighting:**
  - Ensure propane tank is securely connected and has fuel.
  - Check that the regulator valve is fully open.
  - Verify the burner knob is turned fully to the 'ON' position.
- **Low Flame:**
  - Check propane tank for low fuel.
  - Ensure burner ports are not clogged. Clean if necessary.

- Confirm regulator is functioning correctly.

- **Gas Leak Smell:**
  - Immediately turn off the stove and propane tank.
  - Check all connections for tightness.
  - Perform a soapy water leak test. Do not use the stove if a leak is detected.

8. Specifications

Feature	Specification
Brand	Cofiyard
Model Number	G3E040
Fuel Type	Propane
Material	Iron, Metal, PA66, Stainless Steel
Product Dimensions (Folded)	10.5"L x 9"W x 6"H
Product Dimensions (Unfolded)	23.6"L x 9"W x 3"H
Item Weight	4.5 Pounds
Maximum Energy Output	20,000 BTU (total for two burners)



Figure 5: Detailed specifications of the Cofiyard G3E040 camping stove, including dimensions, materials, and BTU output.

9. Warranty & Support

The Cofiyard G3E040 2 Burner Propane Camping Stove comes with a**1-Year Warranty**. For any product inquiries, technical assistance, or warranty claims, please contact our **24/7 Customer Support**.
Contact information for customer support can be found in the included User Manual or on the official Cofiyard website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DR81PT6W

More documents and user manuals: **https://manuals.plus/**