EUROSTAR ES102W

EUROSTAR ES102W Single Burner Instruction Manual

Model: ES102W

Introduction

Thank you for purchasing the EUROSTAR ES102W Single Burner with Spiral Plate. This portable electric hot plate is designed for convenient cooking in various settings, including dorms, offices, RVs, or as an additional burner at home. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance. Please read these instructions thoroughly before using the appliance and retain them for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Setup

1. **Unpacking:** Carefully remove the EUROSTAR ES102W Single Burner from its packaging. Retain all packaging materials for future storage or transport.
2. **Placement:** Place the burner on a stable, flat, heat-resistant surface. Ensure there is adequate clearance around the appliance for ventilation. The non-skid rubber feet provide stability during use.
3. **Power Connection:** Ensure the temperature control knob is set to the "OFF" position. Plug the power cord into a standard electrical outlet.
4. **Initial Burn-off:** Before first use, operate the burner at its highest setting for approximately 5-10 minutes without any cookware. This will burn off any manufacturing residues and odors. A small amount of smoke or odor during this process is normal. Ensure the area is well-ventilated.



Image: The EUROSTAR ES102W Single Burner showing its spiral heating element and temperature control knob.

Operating Instructions

1. **Prepare Cookware:** Place your desired cookware (pots, pans) onto the spiral heating plate. Ensure the cookware has a flat bottom and is suitable for electric cooktops. The burner plate diameter is 140mm (5.51 inches).
2. **Adjust Temperature:** Turn the adjustable temperature control knob clockwise to select the desired heat setting. The knob typically ranges from "MIN" (low) to "MAX" (high).
3. **Power Indicator Light:** The power indicator light will illuminate when the burner is heating. It will

cycle on and off as the burner maintains the selected temperature.

4. **Cooking:** Allow the burner to preheat for a few minutes before adding food. Cook food as desired, adjusting the temperature as needed.
5. **After Use:** Once cooking is complete, turn the temperature control knob counter-clockwise to the "OFF" position. The power indicator light will turn off.
6. **Cool Down:** Allow the burner to cool completely before cleaning or storing. The heating element will remain hot for some time after being turned off.



Image: The EUROSTAR ES102W Single Burner in operation with a pan of vegetables.

Maintenance and Cleaning

Proper maintenance ensures the longevity and safe operation of your EUROSTAR ES102W Single Burner.

- **Always Unplug:** Before cleaning, always ensure the burner is unplugged from the power outlet and has completely cooled down.
- **Cleaning the Heating Plate:** For light spills, wipe the spiral heating element with a damp cloth. For stubborn stains, a non-abrasive cleaner designed for cooktops can be used. Ensure no liquid enters the internal components.
- **Cleaning the Body:** Wipe the exterior body of the burner with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- **Do Not Immerse:** Never immerse the burner, cord, or plug in water or any other liquid.
- **Storage:** Store the appliance in a dry place when not in use. Ensure it is clean and completely dry before storing.

Troubleshooting

If you encounter issues with your EUROSTAR ES102W Single Burner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Burner does not heat up.	Not plugged in. Power outlet malfunction. Temperature knob set to "OFF" or too low.	Ensure the burner is securely plugged into a working outlet. Test the outlet with another appliance. Turn the temperature knob to a higher setting.
Power indicator light is off, but burner is hot.	Normal operation (thermostat cycling).	The light cycles on and off to maintain the set temperature. This is not a malfunction.
Smoke or odor during first use.	Manufacturing residues burning off.	This is normal during the initial burn-off. Ensure good ventilation. It should dissipate after a few minutes.
Burner heats slowly or unevenly.	Incorrect cookware. Low heat setting.	Use cookware with a flat bottom that makes full contact with the heating element. Increase the temperature setting.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Model Number	ES102W
Power	1000 Watts
Burner Plate Diameter	140mm (5.51 inches)
Product Dimensions	9.49 x 9.49 x 3.5 inches
Item Weight	1.25 pounds
Features	Adjustable Temperature Control, Power Indicator Light, Non-skid Rubber Feet

Warranty and Support

EUROSTAR products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or contact the retailer where the product was purchased. Please have your model number (ES102W) and purchase date available when contacting support.

© 2024 EUROSTAR. All rights reserved.