Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ECORELAX YK-E138C

ECORELAX Gooseneck Electric Kettle YK-E138C User Manual

Model: YK-E138C

1. Introduction

Thank you for choosing the ECORELAX Gooseneck Electric Kettle. This manual provides essential information for the safe and efficient operation of your new kettle. Please read these instructions thoroughly before first use and retain them for future reference.

This electric kettle is designed for precise temperature control, ideal for brewing coffee, tea, and other hot beverages. It features a gooseneck spout for controlled pouring, an OLED display for temperature monitoring, and a keep-warm function.



Image 1.1: ECORELAX Gooseneck Electric Kettle (Model YK-E138C)

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact manufacturer for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The kettle is equipped with an automatic shut-off function and boil-dry protection for safety.
- Ensure the lid is securely closed during operation.

3. Product Components

The ECORELAX Gooseneck Electric Kettle consists of the following main components:

- **Kettle Body:** Stainless steel construction with a gooseneck spout and ergonomic handle.
- **Lid:** Anti-scald design for safe handling.
- **Power Base:** Features an OLED display and control buttons for temperature settings and functions.



Image 3.1: Internal and External Components of the Kettle

This kettle is constructed from 100% food-grade stainless steel, ensuring durability and safety for water contact.

4. Setup

1. **Unpacking:** Carefully remove all packaging materials from the kettle and its base.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the MAX fill line. Boil the water and then discard it. Repeat this process 1-2 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

5.1 Filling the Kettle

- Remove the kettle from its base.
- Open the lid and fill the kettle with fresh, cold water. Do not fill below the MIN mark or above the MAX mark (1 Liter capacity).
- Securely close the lid.
- Place the kettle back onto the power base.

5.2 Temperature Control and Boiling

The kettle features an OLED display and control buttons for precise temperature selection.



Image 5.1: OLED Display and Control Buttons

1. **Power On:** Press the On/Off button (power symbol) to activate the kettle. The OLED display will show the current water temperature.
2. **Set Temperature:** Use the '+' and '-' buttons to adjust the desired target temperature. The temperature can be set with ±1℉ precision.
3. **Start Boiling:** Press the 'Boil' button (water droplet symbol) to begin heating. The kettle will heat the water to the set temperature.
4. **Automatic Shut-off:** Once the target temperature is reached, the kettle will automatically turn off.

5.3 Keep Warm Function

The kettle can maintain your desired water temperature for an extended period.



Image 5.2: Keep Warm and Safety Features

- After setting your desired temperature and initiating heating, the kettle will automatically enter 'Keep Warm' mode once the target temperature is reached.
- The built-in NTC thermistor keeps the water warm for up to 2 hours.
- After 2 hours, the kettle will automatically shut off.

5.4 Pouring

The gooseneck spout is designed for optimal pour-over flow control.



Image 5.3: Precise Pouring with Gooseneck Spout

- Carefully lift the kettle from its base using the ergonomic handle.
- Tilt the kettle to pour water slowly and steadily, allowing for precise control, especially beneficial for pour-over coffee or delicate teas.
- Return the kettle to its base after pouring.

6. Cleaning and Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
3. **Interior Cleaning:** For the interior, rinse with clean water. If mineral deposits (limescale) accumulate, use a descaling solution specifically designed for kettles, following the product instructions. Alternatively, you can use a

mixture of white vinegar and water (1:2 ratio), boil it, let it sit for an hour, then rinse thoroughly several times.

4. **Do Not Immerse:** Never immerse the kettle body or the power base in water or any other liquid.
5. **Storage:** When not in use, store the kettle in a dry place. The cord can be wrapped around the base for tidy storage.

7. Troubleshooting

If you encounter any issues with your ECORELAX Gooseneck Electric Kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power outage; kettle not properly seated on base.	Ensure plug is securely in outlet; check household power; reseat kettle firmly on base.
Kettle heats but does not reach desired temperature.	Lid not closed properly; incorrect temperature setting.	Ensure lid is securely closed; verify temperature setting on OLED display.
Kettle automatically shuts off prematurely.	Boil-dry protection activated (insufficient water).	Ensure water level is above MIN mark. If activated, allow kettle to cool before refilling.
Water has an unusual taste or odor.	New appliance residue; mineral deposits.	Perform initial cleaning steps again. Descale the kettle if mineral deposits are present.

If the problem persists after attempting these solutions, please contact ECORELAX customer support for further assistance.

8. Specifications

Feature	Detail
Brand	ECORELAX
Model Name	YK-E138C
Power	1200 W
Capacity	1 Liter
Temperature Control	±1°F Precision, OLED Display
Keep Warm Function	Up to 2 hours
Safety Features	Automatic Shut-Off, Boil-Dry Protection
Material	Food Grade Stainless Steel
Product Dimensions	8.5"L x 7.5"W x 12"H
Item Weight	4.25 pounds

9. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact

ECORELAX customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

© 2023 ECORELAX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRF951GC

More documents and user manuals: **https://manuals.plus/**