Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RC1910

XINFUTE RC1910 Remote Control User Manual

Model: RC1910 | Brand: XINFUTE

1. Introduction

This manual provides comprehensive instructions for the XINFUTE RC1910 replacement remote control, designed for use with specific Vestel and Toshiba LCD TV models. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

1.1 Product Overview

The XINFUTE RC1910 is a replacement remote control unit made from durable ABS material. It is designed to function as effectively as the original remote for compatible television models.



Figure 1: Front view of the XINFUTE RC1910 Remote Control.

This image displays the front of the RC1910 remote control, highlighting its ergonomic design and the layout of all functional buttons, including power, channel, volume, number pad, and navigation controls.

1.2 Compatibility

This remote control is specifically compatible with the following Vestel and Toshiba LCD TV models:

- UE55ES6300SXXH
- UE43J5550

Please ensure your TV model matches one of the listed compatible models for optimal performance.

2. Setup

2.1 Battery Installation

The XINFUTE RC1910 remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 2: Battery compartment of the RC1910 remote control.

This image illustrates the open battery compartment on the back of the remote, clearly showing the slots for two AAA batteries and the correct polarity markings.

No programming is required for this replacement remote control; it is ready for use once batteries are installed.

3. Operating Instructions

The XINFUTE RC1910 remote control features standard buttons for TV operation. Point the remote directly at your television's infrared receiver for best performance.

3.1 Key Functions

- **Power Button (●):** Turns the TV on or off.
- **Number Pad (0-9):** Directly selects channels.
- **CH +/-:** Changes channels up or down.
- **VOL +/-:** Adjusts volume up or down.
- **Mute:** Silences the TV audio.
- **Source:** Selects input sources (HDMI, AV, etc.).
- **Menu:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **OK Button:** Confirms selections in menus.
- **Return:** Goes back to the previous screen or menu.
- **EPG:** Displays the Electronic Program Guide.
- **Info:** Displays information about the current program.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within certain TV menus or applications.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Controls media playback if supported by your TV.

For detailed functionality of specific buttons, refer to your television's original user manual.

4. Maintenance

4.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

4.2 Storage

When not in use for extended periods, it is recommended to remove the batteries from the remote control to prevent battery leakage, which can cause damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

5.1 Common Issues and Solutions

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old or depleted batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV.
- **Certain buttons not working:**
  - Clean the remote control surface, especially around the non-working buttons, to remove any dirt or debris.
  - If only specific buttons are unresponsive, the remote may be damaged.
- **TV not responding to remote, but remote light flashes:**
  - This indicates the remote is sending a signal. The issue might be with the TV's infrared receiver or its

settings. Consult your TV's user manual.

- Verify that your TV model is listed as compatible with this remote control.

If you continue to experience issues after attempting these troubleshooting steps, please refer to the Customer Support section.

6. Specifications

Feature	Detail
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Model Number	RC1910
Batteries Required	2 AAA batteries (not included)
Material	ABS Material
Connectivity Technology	Infrared
Compatible Devices	Television (Vestel, Toshiba LCD TV models UE55ES6300SXXH, UE43J5550)
Special Feature	Ergonomic, No Programming Required

7. Warranty and Support

7.1 Warranty Information

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as described under normal use.

7.2 Customer Support

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receiving your product. For further assistance, you may also visit the XINFUTE Store on Amazon: XINFUTE Store.

© 2024 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRJM684Y

More documents and user manuals: **https://manuals.plus/**