Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo DT2401-BK

ChooChoo 47.2 Inch Round Farmhouse Dining Table Instruction Manual

Model: DT2401-BK

Safety Information Parts List Assembly Operation Maintenance Troubleshooting Specifications Warranty & Support

Introduction

Thank you for choosing the ChooChoo 47.2 Inch Round Farmhouse Dining Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new table. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The ChooChoo 47.2 Inch Round Farmhouse Dining Table, showcasing its black finish and sturdy design, suitable for various room settings.

Safety Information

- Always assemble the table on a soft, clean surface to prevent scratches.
- Ensure all screws and bolts are securely tightened before use.
- Do not stand or sit on the table.
- Keep small parts away from children during assembly to prevent choking hazards.
- Distribute weight evenly on the tabletop to maintain stability.
- Regularly check all connections to ensure they remain tight.

Parts List

Please verify that all components are present before beginning assembly. Refer to the included assembly guide for detailed part identification.

Part	Description	Quantity
Tabletop Halves	Two semi-circular MDF panels forming the round tabletop.	2
Legs	Four cross-carbon steel legs for the base.	4
Central Connector	Metal piece connecting the legs at the center.	1
Adjustable Foot Pads	Non-slip pads for leveling and floor protection.	4
Hardware Kit	Screws, bolts, Allen key, and wrench for assembly.	1 set



Image: Detailed diagram illustrating the dimensions of the table, including its 47.2-inch diameter and 29.5-inch height.

Assembly Instructions

Follow these steps to assemble your ChooChoo dining table. An additional Phillips head screwdriver (not included) may be required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent damage. Verify all parts against the parts list.
2. **Assemble the Base:** Attach the four cross-carbon steel legs to the central connector using the provided hardware. Ensure all connections are finger-tight at this stage.
3. **Attach Foot Pads:** Screw the adjustable foot pads into the bottom of each leg. These can be adjusted later to level the table.

4. **Secure Tabletop Halves:** Place the two semi-circular tabletop halves upside down on your soft surface. Align them carefully to form a complete circle.
5. **Connect Base to Tabletop:** Position the assembled leg base onto the underside of the tabletop, aligning the pre-drilled holes. Secure the base to the tabletop using the appropriate screws. Tighten all screws firmly but do not overtighten.
6. **Final Tightening:** Once the base is securely attached to the tabletop, go back and fully tighten all screws and bolts on the leg assembly.
7. **Upright the Table:** With assistance, carefully flip the table upright.
8. **Adjust Leveling:** Adjust the foot pads as needed to ensure the table is stable and level on your floor.

Your browser does not support the video tag.

Video: Official ChooChoo Furniture video demonstrating the assembly process and showcasing the finished dining table.



Image: Close-up views highlighting the table's construction features: reinforced firmness at connections, adjustable foot pads for balance, and a stable base design.

Operation and Usage

The ChooChoo 47.2 Inch Round Farmhouse Dining Table is designed for versatile use in various settings.

- **Seating Capacity:** Comfortably seats 4 individuals. Depending on chair size, a fifth chair may be accommodated.
- **Multi-Purpose:** Ideal as a dining table, kitchen table, conference table, or a large coffee table.
- **Placement:** Suitable for indoor use only. Avoid prolonged exposure to direct sunlight or extreme humidity.



Image: The dining table arranged with place settings and food, demonstrating its capacity and suitability for meals.

Care and Maintenance

- **Cleaning:** Wipe the tabletop and legs with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the MDF tabletop.
- **Heat Protection:** Use placemats or coasters under hot dishes to protect the tabletop surface from heat damage.
- **Weight Distribution:** Avoid placing excessively heavy items on one section of the table.

- **Regular Checks:** Periodically inspect all screws and connections and tighten them if necessary to maintain stability.



Image: A detailed view of the tabletop, showcasing its wood grain texture and black finish, emphasizing the need for proper care.

Troubleshooting

Problem	Possible Cause	Solution
Table is wobbly	Uneven floor or loose connections.	Adjust the foot pads on the bottom of the legs until stable. Check and tighten all assembly screws.
Tabletop not flush	Tabletop halves not perfectly aligned during assembly.	Loosen the screws connecting the tabletop to the base, realign the halves, and then retighten.
Scratches or marks on surface	Impact or abrasive cleaning.	Use placemats/coasters. For minor scratches, consider a furniture repair pen matching the finish. Avoid abrasive cleaners.

Specifications

- **Brand:** ChooChoo
- **Model:** DT2401-BK
- **Shape:** Round
- **Color:** Black
- **Product Dimensions:** 47.2"D x 47.2"W x 29.5"H
- **Tabletop Thickness:** 1 inch (25mm)
- **Item Weight:** Approximately 39.11 Pounds
- **Frame Material:** Metal (Cross-carbon steel legs)
- **Top Material:** Engineered Wood (MDF)
- **Seating Capacity:** 4
- **Assembly Required:** Yes
- **Indoor/Outdoor Usage:** Indoor Only

Warranty and Support

For specific warranty details and customer support, please refer to the warranty card included with your product or contact ChooChoo customer service directly through their official website or the retailer where the product was purchased. Please have your model number (DT2401-BK) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRNBGLN2

More documents and user manuals: **https://manuals.plus/**