**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**XINFUTE ELE-3**

# XINFUTE Replacement Remote Control User Manual

Model: ELE-3

## Introduction

This manual provides comprehensive instructions for the XINFUTE replacement remote control. It is designed to function as a direct replacement for your original remote, offering full compatibility with various LCD TV models. Please read this manual carefully before use to ensure proper operation and to maximize your remote control's lifespan.

**Compatible TV Models:** ELDFW406, ELCFT262, ELDFW322, ELCFW326, ELCFW329, ELEFS191, ELEFS241, ELEFT326, ELEFW401A.

## Setup

### 1. Installing Batteries

The remote control requires two (2) AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.




Image: Back of the remote control with the battery compartment open, illustrating the correct insertion of two AAA batteries.

### 2. Initial Use

This remote control is a replacement unit and is designed to work immediately with the specified compatible TV models without requiring any programming. Simply insert the batteries and point the remote towards your television.

## Operating Instructions

Familiarize yourself with the buttons on your XINFUTE remote control. The layout is designed for intuitive navigation of your television's functions.




Image: Front view of the XINFUTE remote control, displaying the arrangement and labeling of all operational buttons.

## Key Functions:

- **Power Button (●):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **CH+/CH-:** Changes channels sequentially.
- **VOL+/VOL-:** Adjusts the volume level.
- **Mute:** Silences the TV audio.
- **Source/Input:** Selects the input source (HDMI, AV, etc.).
- **Menu:** Accesses the TV's main menu.
- **Navigation (Up/Down/Left/Right) & OK:** Navigates through menus and confirms selections.
- **Exit:** Exits the current menu or function.
- **Info:** Displays information about the current program or input.
- **Aspect:** Changes the screen aspect ratio.
- **Sleep:** Sets a sleep timer for the TV.

- **USB:** Accesses media from a connected USB device.
- **V-CHIP:** Accesses V-Chip parental control settings.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

*Note: Specific button functions may vary slightly depending on your TV model.*

## Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in water.

## Troubleshooting

| Problem | Solution |
|---|---|
| Remote control is not working. | • Ensure batteries are inserted correctly with the correct polarity (+/-).<br>• Replace old batteries with new AAA batteries.<br>• Check for any obstructions between the remote control and the TV's infrared sensor.<br>• Ensure you are within the effective range and pointing the remote directly at the TV. |
| Some buttons are not responding. | • Clean the remote control, especially around the unresponsive buttons, to remove dirt or debris.<br>• Ensure the TV is powered on and not in a menu that restricts certain functions.<br>• Verify that the specific function is supported by your TV model. |
| TV is not responding consistently. | • Replace batteries.<br>• Minimize strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the IR signal.<br>• Ensure no other devices are emitting IR signals that could cause interference. |

## Specifications

| | |
|---|---|
| **Brand** | XINFUTE |
| **Model Number** | ELE-3 |
| **Compatible Devices** | Television (Specific LCD TV models: ELDFW406, ELCFT262, ELDFW322, ELCFW326, ELCFW329, ELEFS191, ELEFS241, ELEFT326, ELEFW401A) |
| **Power Source** | 2 x AAA Batteries (not included) |

| | |
|---|---|
| **Product Dimensions** | 6 x 3 x 1 inches |
| **Item Weight** | 2.82 ounces |
| **Special Feature** | Ergonomic design |

## Warranty Information

XINFUTE offers a one-year warranty on all purchases of this replacement remote control. This warranty covers manufacturing defects and ensures your satisfaction with the product.

For warranty claims or issues, please retain your proof of purchase and contact customer support.

## Customer Support

If you encounter any problems or have questions regarding your XINFUTE replacement remote control, please do not hesitate to contact our customer support team.

All products are inspected before shipment. If you are not satisfied with your purchase, you may contact us within 24 hours of receipt.

For support, please refer to the contact information provided with your purchase or visit the official XINFUTE store page on Amazon: XINFUTE Store

© 2024 XINFUTE. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0DRP3FWZ6**

More documents and user manuals: **https://manuals.plus/**