JELLYPIG B0DRP7QTZ9

JELLYPIG Cordless Vacuum Cleaner User Manual

Model: B0DRP7QTZ9

1. Product Overview & Features

The JELLYPIG Cordless Vacuum Cleaner is designed for efficient and convenient cleaning across various surfaces. Its powerful motor, long-lasting battery, and intelligent features make it an ideal solution for maintaining a clean home.



Figure 1.1: JELLYPIG Cordless Vacuum Cleaner and included accessories.

Key Features:

- **45KPA Powerful Suction & 3 Suction Modes:** Equipped with a 550W high-efficiency motor, delivering 45,000PA suction for effective cleaning on carpets and hard floors. Features Eco, Mid, and Max modes for versatile cleaning.



Figure 1.2: Demonstrating 45KPA powerful suction on various debris.

- **Max 60 Mins Running Time:** High-capacity battery provides up to 60 minutes of continuous power in eco-mode, suitable for cleaning large areas.



Figure 1.3: Visual representation of the vacuum's extended runtime.

- **Tangle-Free V-Shaped Brush & Dual-Handheld Design:** Unique V-shaped brush minimizes hair wrap, while the ergonomic dual-handle design allows for easy cleaning under furniture.



Figure 1.4: The anti-tangle V-shaped brush effectively collects debris.



Figure 1.5: The dual-handle design allows for easy maneuverability under low furniture.

- **7-Layer High-efficiency Filtration & 1.6L Dust Cup:** Filtration cyclone system captures 99.99% of fine dust with a built-in HEPA filter. The large dust cup reduces the frequency of emptying.
- **Smart LED Display:** Advanced OLED display provides real-time updates on battery level, suction mode, and dustbin capacity.



Figure 1.6: The intelligent LED display provides essential operational information.

2. Safety Instructions

Please read all safety warnings and instructions before using this appliance. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the appliance.
- Recharge only with the charger specified by the manufacturer.

3. Package Contents

Carefully unpack your JELLYPIG Cordless Vacuum Cleaner and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Cordless Vacuum Main Unit
- Extension Wand
- Motorized Floor Brush (V-shaped)
- Short Brush Head
- Long Crevice Nozzle
- Inlet HEPA Filter (1 installed, 1 spare)
- Outlet HEPA Filter (1 installed, 1 spare)
- Wall Mount Bracket
- Power Adapter/Charger
- User Manual (this document)

4. Assembly

Follow these steps to assemble your vacuum cleaner:

1. **Attach the Extension Wand:** Align the electrical contacts on the extension wand with those on the main unit. Push

firmly until it clicks into place.

2. **Attach the Floor Brush:** Connect the motorized floor brush to the other end of the extension wand, ensuring the electrical contacts align and it clicks securely.
3. **Install the Battery:** Slide the battery pack into the slot on the main unit until it locks.
4. **Optional Attachments:** For handheld use, detach the extension wand and attach the short brush head or long crevice nozzle directly to the main unit.



Figure 4.1: The vacuum assembled in stick mode with various attachments shown.

5. Charging the Battery

Before first use, fully charge the battery. A full charge takes approximately 4 hours and provides up to 60 minutes of

runtime in Eco mode.

1. Connect the power adapter to the charging port on the main unit or directly to the battery if removed.
2. Plug the adapter into a wall outlet.
3. The LED display will show the charging status. When fully charged, the battery indicator will show 100%.



Figure 5.1: The LED display indicates battery level during charging and operation.

6. Operating Instructions

Your JELLYPIG Cordless Vacuum Cleaner offers flexible cleaning options.

Power On/Off and Suction Modes:

- Press the Power button on the handle to turn the vacuum on or off.
- Use the Mode button on the LED display to cycle through the three suction modes: Eco, Mid, and Max. The display will show the current mode.

Using Attachments:

- **Stick Vacuum Mode:** Use with the extension wand and motorized floor brush for general floor cleaning. The LED lights on the brush head illuminate dark areas.
- **Handheld Vacuum Mode:** Detach the extension wand and attach the short brush head for upholstery, car interiors, or pet hair, or the long crevice nozzle for tight corners and gaps.



Figure 6.1: The vacuum easily converts to a handheld unit for versatile cleaning.

Your browser does not support the video tag.

Video 6.1: Official product video demonstrating the JELLYPIG Cordless Vacuum Cleaner's features and operation.

7. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dust Cup:

The 1.6L dust cup is designed for no-touch emptying.

1. Hold the main unit over a trash bin.
2. Press the dust cup release button (usually located near the bottom of the dust cup) to open the bottom flap and release debris.
3. Close the flap securely after emptying.



Figure 7.1: Easy, no-touch dust cup emptying process.

Cleaning the Filters:

The 7-layer filtration system includes HEPA filters that require regular cleaning.

1. Twist and pull to remove the dust cup from the main unit.
2. Remove the internal filter components, including the HEPA filter.

3. Tap the filters gently to remove loose dust. For thorough cleaning, rinse the filters under cold running water.
4. Allow all filter components to air dry completely for at least 24 hours before reassembling. Do not use heat to dry.
5. Reassemble the filters and dust cup, ensuring all parts are securely in place.

Cleaning the Brush Roll:

The V-shaped brush roll is designed to be anti-tangle, but occasional cleaning may be necessary.

1. Turn off the vacuum and detach the motorized floor brush.
2. Locate the release mechanism for the brush roll (refer to diagrams in the physical manual if needed).
3. Remove the brush roll and carefully cut away any tangled hair or debris using scissors.
4. Reinsert the brush roll and secure it in place.

8. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely inserted.
Low suction power	Dust cup is full, filters are clogged, or brush roll is tangled.	Empty dust cup, clean/replace filters, clear brush roll.
Brush roll not spinning	Brush roll is tangled or obstructed.	Turn off vacuum, remove brush roll, and clear any obstructions.
Vacuum stops suddenly	Overheating due to prolonged use or blockage.	Turn off vacuum, allow to cool for 30 minutes, check for blockages.

9. Specifications

Detailed technical specifications for your JELLYPIG Cordless Vacuum Cleaner.

Specification	Value
Brand	JELLYPIG
Special Feature	Upgraded 550W brushless motor, 45KPA powerful suction, Up to 60 Mins Runtime, 3 suction modes, LED Screen, HEPA Washable
Filter Type	HEPA Filter
Is Cordless?	Yes

Specification	Value
Capacity	1.5 Liters
Wattage	450 watts
Runtime	1 hour (60 minutes)
Charging Time	4 Hours
Form Factor	Stick
Color	Red
Product Dimensions	11"L x 6"W x 45"H
Battery Description	Lithium-Ion
Item Weight	5.77 pounds
ASIN	B0DRP7QTZ9

10. Warranty and Support

JELLYPIG offers comprehensive support for your product.

- **Warranty:** Enjoy 24 Months of Protection from the date of purchase.
- **Customer Service:** Our 24/7 Service Team is available to assist you with any questions or concerns. Please refer to the contact information provided in your product packaging or on the official JELLYPIG website for support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question