Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fullwill KZD60-170

Fullwill 6QT Air Fryer Instruction Manual

Model: KZD60-170 | Brand: Fullwill

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. Product Overview

The Fullwill 6QT Air Fryer (Model KZD60-170) is a versatile 5-in-1 kitchen appliance designed for healthy and convenient cooking. It features a spacious 6-quart capacity, a transparent viewing window, and intuitive touch controls with 7 one-touch presets.

Components Included:

- Fullwill Air Fryer Unit (x1)
- 6 Quart Nonstick Basket (x1)
- Crisper Plate (x1)
- 28-Recipe Booklet (x1)

Key Features:

- **Built-in Viewing Window:** Monitor cooking progress without opening the basket, preserving heat and flavor.
- **5-in-1 Versatility:** Air Fry, Roast, Bake, Reheat, and Dehydrate.
- **7 One-Touch Presets:** Dedicated settings for Chicken, Fries, Steak, Custard Tart, Wings, Seafood, and Vegetables.
- **Generous 6QT Capacity:** Ideal for family meals and gatherings.
- **Healthy Cooking:** Advanced air circulation technology reduces fat by up to 95%.
- **Easy Cleanup:** Non-stick basket and crisper plate are dishwasher safe.



The Fullwill Air Fryer in a kitchen setting, showcasing its viewing window with food cooking inside.



Detailed view of the digital touch control panel with various cooking functions and presets.



The non-stick basket and crisper plate are easily removable and dishwasher safe for convenient cleaning.

3. Setup

1. **Unpack:** Carefully remove all packaging materials, stickers, and labels from the air fryer.
2. **Clean Components:** Wash the non-stick basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the interior and exterior of the appliance with a damp cloth.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 4 inches (10 cm) of free space on the back and sides, and 4 inches (10 cm) above the appliance to allow for proper air circulation.
4. **Initial Run (Optional but Recommended):** Before first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. Ensure the area is well-ventilated during this process.

4. Operating Instructions

Basic Operation:

1. **Plug In:** Connect the power cord to a grounded wall outlet. The control panel will illuminate.
2. **Place Food:** Insert the crisper plate into the non-stick basket, then place your ingredients into the basket. Slide the basket back into the air fryer until it clicks into place.
3. **Select Function:** Use the 'Menu' button to cycle through the 7 preset functions (Chicken, Fries, Steak, Custard Tart, Wings, Seafood, Vegetables) or manually set the time and temperature.
4. **Adjust Time/Temperature:** Use the '+' and '-' buttons to adjust the cooking time and temperature as needed.
5. **Start Cooking:** Press the 'Start/Cancel' button to begin the cooking cycle.
6. **Monitor Progress:** Utilize the built-in viewing window and the internal light (activated by the light bulb icon) to check on your food without opening the basket.
7. **Shake/Flip (if needed):** For even cooking, some recipes may require shaking or flipping ingredients halfway through. The air fryer will pause when the basket is removed and resume when reinserted.

8. **Finish Cooking:** The air fryer will beep when the cooking cycle is complete. Carefully remove the basket and transfer food to a serving dish.

Preset Functions:

The Fullwill Air Fryer comes with 7 convenient one-touch presets for common dishes:

- Chicken
- Fries
- Steak
- Custard Tart
- Wings
- Seafood
- Vegetables

Refer to the included 28-Recipe Booklet for detailed instructions and recommended settings for each preset.

Official Product Videos:

Your browser does not support the video tag.

This video provides an overview of the Fullwill 6QT Air Fryer with Window, highlighting its 12-in-1 multi-function capabilities and transparent cooking window.

Your browser does not support the video tag.

A short video showcasing the Fullwill 6QT Air Fryer with Window and its 12-in-1 functions, emphasizing its versatility.

Your browser does not support the video tag.

This video demonstrates the Fullwill 12-in-1 Air Fryer, highlighting its 6-quart capacity and non-stick basket with a viewing window.

5. Cooking Tips

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes before adding food.
- **Oil Usage:** While air frying requires significantly less oil, a light spray or toss with oil can enhance crispiness and flavor for some foods.
- **Do Not Overcrowd:** Avoid filling the basket too much. Cook in batches if necessary to ensure even cooking and crispiness.
- **Shake/Flip Regularly:** For foods like fries or chicken wings, shaking the basket or flipping items halfway through the cooking process promotes uniform browning.
- **Check Doneness:** Always ensure food is cooked to a safe internal temperature. The viewing window helps monitor browning.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your Fullwill Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Dishwasher Safe Parts:** The non-stick basket and crisper plate are dishwasher safe. For stubborn residue, soak them in warm, soapy water before washing.
3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
4. **Clean Exterior:** Wipe the exterior with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped.	Cook in smaller batches. Shake or flip food halfway through cooking.
Food is not crispy.	Not enough oil; temperature too low; cooking time too short.	Lightly spray food with oil. Increase temperature or cooking time.
White smoke coming from appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and crisper plate thoroughly. Remove excess fat from food.

8. Specifications

- **Model Name:** KZD60-170
- **Brand:** Fullwill
- **Capacity:** 6 Quarts
- **Product Dimensions:** 12.24"D x 15.51"W x 14.92"H
- **Item Weight:** 9.68 Pounds
- **Material:** Metal, Polypropylene (PP)
- **Output Wattage:** 1700 Watts
- **Voltage:** 120 Volts
- **Control Method:** Touch
- **Max Temperature Setting:** 400 Degrees Fahrenheit
- **Special Feature:** Programmable, Temperature Control, Viewing Window

- **Nonstick Coating:** Yes
- **Dishwasher Safe Parts:** Yes (Basket, Crisper Plate)

9. Warranty and Support

Fullwill products are manufactured with quality and reliability in mind. For any questions regarding your Fullwill Air Fryer, including warranty information or technical support, please contact Fullwill customer service. Contact details can typically be found in the included product documentation or on the official Fullwill website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DS45CHPL

More documents and user manuals: **https://manuals.plus/**