LOKMAT Appllp 5 Max

LOKMAT 4G Smart Watch User Manual

Model: Appllp 5 Max
Brand: LOKMAT

Product Overview

The LOKMAT 4G Smart Watch (Model: Appllp 5 Max) is a versatile Android-powered smartwatch designed for comprehensive connectivity and functionality. It features a large display, robust processing capabilities, and integrated communication features, making it suitable for various daily activities.

- **Display:** Large 2.4-inch HD touchscreen with vibrant color display and customizable watch faces for clear visibility.
- **Connectivity:** 4G LTE support enables standalone calling, messaging, and internet access without a phone nearby.
- **Operating System:** Runs on Android platform allowing access to various apps and games from supported app stores.
- **Battery Life:** Long-lasting battery provides up to 48 hours of regular use with optimized power management.
- **Design:** Rugged construction with durable black metal frame and comfortable silicone strap for daily wear.



The LOKMAT 4G Smart Watch, showcasing its large display and capability to run applications.

What's in the Box

Verify that all items are present in the package:

- Smart Watch (LOKMAT Appllp 5 Max)
- Watch Band
- Charging Cable
- User Manual (this document)

Setup

1. Initial Power On

1. Press and hold the Power Button (located on the side of the watch) for approximately 3 seconds until the LOKMAT logo appears.
2. Follow the on-screen prompts to select your preferred language and complete the initial setup process.

2. SIM Card Installation

The LOKMAT Smart Watch supports Nano SIM cards for 4G LTE connectivity. Ensure the watch is powered off before inserting or removing the SIM card.

1. Locate the SIM card slot on the side of the watch.
2. Use the provided SIM ejector tool to open the SIM card tray.
3. Carefully place the Nano SIM card into the tray with the gold contacts facing down, ensuring proper orientation.

4. Gently push the SIM card tray back into the slot until it clicks into place.
5. Power on the watch. The device will automatically detect the SIM card and attempt to connect to the network.



Illustration of SIM card installation for 4G connectivity.

3. Charging the Smart Watch

Before first use, fully charge the watch. Use only the provided charging cable.

1. Connect the magnetic end of the charging cable to the charging contacts on the back of the watch. Ensure it snaps securely into place.
2. Connect the USB-A end of the charging cable to a compatible USB power adapter (not included) or a computer USB port.
3. The watch display will show a charging indicator. A full charge typically takes approximately 2-3 hours.



The LOKMAT Smart Watch being charged via its magnetic charging cable.

Operating the Smart Watch

Basic Navigation

- **Touchscreen:** Swipe left/right, up/down to navigate through menus and screens. Tap to select items or open applications.
- **Power Button:** Press to wake/sleep the screen. Press and hold to power on/off or restart.
- **Back Button:** (If applicable, refer to specific model button layout) Typically returns to the previous screen.



The LOKMAT Smart Watch displaying its Android application interface.

Connectivity

The watch supports multiple connectivity options:

- **4G LTE:** With a Nano SIM card installed, the watch can make and receive calls, send messages, and access mobile data independently.
- **Wi-Fi:** Connect to Wi-Fi networks for internet access. Navigate to Settings > Network & Internet > Wi-Fi to connect.
- **Bluetooth:** Pair with Bluetooth headphones, speakers, or other devices. Navigate to Settings > Connected devices > Bluetooth.
- **GPS:** Built-in GPS allows for location tracking and navigation.

Applications and Features

The Android operating system allows for a wide range of applications.

- **Play Store:** Download and install various Android applications directly from the Google Play Store.
- **Dual Cameras:** The watch features dual cameras for taking photos and video calls. Access the Camera app from the main

menu.

- **Health Monitoring:** Monitor your heart rate, blood oxygen, and track sleep patterns through dedicated health applications.
- **Customizable Watch Faces:** Personalize your watch with a variety of pre-installed or downloadable watch faces.



The LOKMAT Smart Watch features dual cameras for photography and video calls.



The large screen of the LOKMAT Smart Watch is suitable for viewing multimedia content.



The LOKMAT Smart Watch running a mobile game, demonstrating its processing capabilities.

Official Product Videos

Watch these official videos for a visual guide to the LOKMAT 4G Smart Watch's features and operation.

6GB+128GB Android Smartwatch Phone Call

Your browser does not support the video tag.

This video provides an overview of the LOKMAT 4G Smart Watch's capabilities, highlighting its 6GB RAM and 128GB storage, and its ability to function as a standalone phone for calls.

Specifications

Feature	Detail

Feature	Detail
Model Number	Appllp 5 Max
Screen Size	2.4 Inches
Operating System	Android
RAM Memory Installed Size	6 GB
Memory Storage Capacity	128 GB
Battery Capacity	1500 mAh (Amp Hours)
Connectivity Technology	Wi-Fi, 4G LTE
Wireless Communication Standard	Bluetooth, 802.11a/b/g/n/ac
Special Features	Camera, GPS
Item Weight	9.6 ounces
Manufacturer	LOKMAT
Country of Origin	China

Maintenance

Cleaning

To maintain the appearance and functionality of your smartwatch:

- Wipe the screen and watch body with a soft, lint-free cloth.
- For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the charging contacts regularly to ensure proper connection.

Battery Care

Proper battery care can extend the lifespan of your device:

- Avoid extreme temperatures, as they can degrade battery performance.
- Do not allow the battery to fully discharge frequently. Charge it before it drops to very low levels.
- If storing the watch for an extended period, charge it to about 50% before turning it off.

Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Updates can typically be found in the watch's Settings menu under "System" or "About device."

Troubleshooting

This section addresses common issues you might encounter.

Watch Does Not Power On

- Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- Try pressing and holding the Power Button for a longer duration (10-15 seconds) to force a restart.

No Network Connection (4G)

- Verify that the Nano SIM card is correctly inserted and activated with your carrier.
- Check signal strength in your current location.
- Restart the watch.
- Ensure "Airplane Mode" is not enabled in the quick settings or network settings.

Apps Crashing or Slow Performance

- Close background applications to free up RAM.
- Clear the cache of problematic apps (Settings > Apps & notifications > [App Name] > Storage & cache > Clear cache).
- Ensure the watch's software is up to date.
- If issues persist, consider a factory reset (Settings > System > Reset options), but back up important data first.

Screen Unresponsive

- Restart the watch by holding the Power Button.
- Ensure the screen is clean and dry.

Warranty and Support

For warranty information and technical support, please refer to the official LOKMAT website or contact their customer service. Keep your purchase receipt as proof of purchase.
Manufacturer: LOKMAT
ASIN: B0DS49J7WW
Date First Available: January 3, 2025

© 2025 LOKMAT. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question