Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fanvace 12

Fanvace HiFi MP3 Player Model 12 User Manual

Your guide to an exceptional high-resolution audio experience.

1. Introduction

Thank you for choosing the Fanvace HiFi MP3 Player Model 12. This device is designed to deliver a superior audio experience with its advanced DSD decoding technology, Bluetooth 5.3 connectivity, and support for a wide range of lossless audio formats. Please read this manual carefully to understand the features and operation of your new player.

Package Contents

Ensure all items are present in the box:

- 1 x Fanvace HiFi MP3 Player
- 1 x USB-C Cable
- 1 x Audio Cable (3.5mm to 3.5mm)
- 1 x 64GB Micro SD Card
- 1 x Leather Case
- 1 x User Manual (this document)



Image: All items included in the Fanvace HiFi MP3 Player package, neatly arranged.

2. Setup

Charging the Device

Before first use, fully charge your MP3 player. Connect the included USB-C cable to the player's USB-C port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status. A full charge typically takes 3-4 hours.

Inserting the Micro SD Card

The player comes with a pre-installed 64GB Micro SD card. If you wish to use a different card or expand storage, gently insert the Micro SD card into the designated slot until it clicks into place. The player supports up to 256GB Micro SD cards.



Image: The Fanvace MP3 Player with a Micro SD card partially inserted into its slot, illustrating the storage expansion capability.

Transferring Music Files

Connect the MP3 player to your computer using the USB-C cable. The player will appear as a removable storage device. You can then drag and drop your music files directly onto the Micro SD card. The player supports various formats including MP3, AAC, FLAC, APE, WAV, PCM, WMA, OGG, ALAC, MS-ADPCM, AIFF, IMA, DSF, DFF, and native DSD256.



Image: The Fanvace MP3 Player connected to a laptop via a USB-C cable, demonstrating the ease of music file transfer.

3. Operating Instructions

Power On/Off

Press and hold the power button (usually on the side) for a few seconds to turn the player on or off.

Navigating the Interface

The player features a 2.8-inch HD touchscreen. Swipe and tap to navigate through menus, select songs, and adjust settings. A retro mechanical knob is also available for precise volume control.

Playing Music

1. From the main menu, select 'Music' or 'Files'.

2. Browse your music by artist, album, genre, or folder.
3. Tap on a song to begin playback.
4. Use the on-screen controls or physical buttons for play/pause, skip tracks, and volume adjustment.

Bluetooth Connectivity

The player supports Bluetooth 5.3 for wireless audio transmission to headphones, speakers, or car audio systems (A2DP profile). It functions as a transmitter only.

1. Go to 'Settings' and select 'Bluetooth'.
2. Turn Bluetooth 'On'.
3. The player will scan for available devices.
4. Select your desired device from the list to pair.



Image: The Fanvace MP3 Player displaying music playback, with wireless earbuds nearby, illustrating its Bluetooth 5.3 capabilities.

Audio Output Options

The player features both a 3.5mm headphone jack and a line output. Use the 3.5mm jack for direct headphone connection. The line output allows connection to external amplifier devices such as home audio systems, speakers, or car audio via the included AUX cable.



Image: A close-up of the Fanvace MP3 Player's audio output ports, with diagrams showing connections to headphones, speakers, and car audio systems.

4. Maintenance

Cleaning

Wipe the device with a soft, dry cloth. Do not use liquid cleaners or solvents, as they may damage the screen or casing.

Storage

Store the player in a cool, dry place away from direct sunlight and extreme temperatures. Use the provided leather case

for protection against scratches and minor impacts.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

5. Troubleshooting

Device Not Turning On

- Ensure the battery is charged. Connect the player to a power source and try again after a few minutes.
- If the device is unresponsive, try a hard reset (refer to the device's specific reset procedure if available, or hold the power button for 10-15 seconds).

No Sound

- Check the volume level.
- Ensure headphones or external audio devices are properly connected.
- If using Bluetooth, ensure the device is paired correctly and the volume on both the player and the connected device is adequate.
- Test with different headphones or audio cables.

Cannot Transfer Files

- Ensure the USB-C cable is securely connected to both the player and the computer.
- Try a different USB port or cable.
- Verify that the player is recognized as a storage device on your computer.
- Check if the Micro SD card is properly inserted and not corrupted.

6. Specifications

Feature	Specification
Model Name	Fanvace HiFi MP3 Player Model 12
Display	2.8-inch HD Touchscreen (240*320 resolution)
Audio Decoding	DSD (up to DSD256), 24bit/192kHz PCM
DAC Chip	ES9018K2M
SNR	127dB/kHz
THD+N	< 0.001%

Feature	Specification
Bluetooth	Version 5.3 (Transmitter only, A2DP profile)
Supported Audio Formats	MP1/2/3, AAC, FLAC, APE, WAV, PCM, WMA, OGG, ALAC, MS-ADPCM, AIFF, IMA, DSF, DFF, DSD256
Internal Storage	None (relies on Micro SD)
Expandable Storage	Micro SD card up to 256GB (64GB included)
Battery	2000mAh rechargeable lithium battery
Battery Life	Up to 50 hours (wired), 60 hours (Bluetooth)
Charging Port	USB-C
Audio Output	3.5mm Headphone Jack, Line Output
Wired Headphone Output Power	10mW/32 Ω, 20mW/16 Ω
Dimensions	3.36 x 2.56 x 0.6 inches
Weight	5.9 oz

7. Warranty and Support

Warranty Information

The Fanvace HiFi MP3 Player Model 12 comes with a 1-year limited warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support

If you encounter any issues or have questions regarding your Fanvace MP3 player, please contact our customer support team. You can typically find contact information on the product packaging or the official Fanvace website. Please have your purchase details and model number ready when contacting support.
We aim to respond to all inquiries within 24 hours.

© 2023 Fanvace. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DS5ZBR78

More documents and user manuals: **https://manuals.plus/**