Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OLIXIS OLXDCCZ-63RT-1

OLIXIS Computer Office Desk 63 Inch Instruction Manual

Model: OLXDCCZ-63RT-1

Introduction

Thank you for purchasing the OLIXIS Computer Office Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new desk. Please read this manual thoroughly before beginning assembly or use.
The OLIXIS Computer Office Desk is designed for versatility and durability, featuring a spacious desktop, sturdy metal frame, and convenient storage options. It is suitable for various environments including home offices, bedrooms, living rooms, classrooms, and study rooms.

Safety Information

- Always follow assembly instructions carefully.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the desk. The maximum weight capacity is **176 lbs**.
- Keep liquids away from electrical equipment on the desk.
- Regularly inspect the desk for any loose parts or damage.
- Keep small parts away from children during assembly to prevent choking hazards.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact OLIXIS customer support.

Part	Description	Quantity
Desktop Panel	Main wooden desktop surface	1
Left Leg Frame (A)	Metal frame for left side	1
Right Leg Frame (B)	Metal frame for right side	1
Top Crossbar (C)	Metal bar connecting top frames	1
Bottom Crossbar (D)	Metal bar connecting bottom frames	1

Part	Description	Quantity
Diagonal Support Bars (F)	Metal bars for enhanced stability	2
Adjustable Feet (E)	Plastic feet for leveling	4
Headphone Hook (H)	Metal hook for headphones/bag	1
Storage Bag (G)	Fabric storage bag	1
M6x40 Screws (L)	Long screws for frame assembly	13
M6x15 Screws (K)	Short screws for attachments	16
Allen Wrench (I)	Assembly tool	1

Note: Quantities are approximate and may vary slightly. Refer to the included hardware pack for exact counts.

Setup and Assembly

Assembly typically takes approximately 20 minutes. It is recommended to have two people for easier assembly, especially when attaching the desktop.

Step 1: Assemble the Side Frames

Connect the Left Leg Frame (A) and Right Leg Frame (B) using the Top Crossbar (C) and Bottom Crossbar (D). Secure them with M6x40 screws (L) using the Allen Wrench (I). Ensure all connections are firm but do not fully tighten yet.

Video: Assembly of the desk frame, showing the connection of side frames and crossbars.



Image: Visual representation of connecting the desk frame components.

Step 2: Attach Adjustable Feet

Insert the four Adjustable Feet (E) into the bottom of each leg frame. These feet help to level the desk on uneven surfaces and protect your floor.



Image: Illustration showing how to attach the adjustable feet to the desk legs.

Step 3: Install Diagonal Support Bars

Attach the two Diagonal Support Bars (F) to the inner corners of the desk frame using M6x15 screws (K). These bars provide enhanced stability and prevent wobbling. Fully tighten all screws from Step 1 and Step 3 now.



Image: Visual guide for attaching the diagonal support bars to the desk frame.

Step 4: Attach Storage Bag and Headphone Hook

The Storage Bag (G) and Headphone Hook (H) can be attached to either the left or right side of the desk frame, depending on your preference. Secure them using M6x15 screws (K).



Image: The removable side storage bag, shown attached to the desk frame, providing additional space for books and files.



Image: Illustration demonstrating the attachment of the storage bag to the desk frame.



Image: Diagram showing the installation of the headphone hook on the desk frame.

Step 5: Attach Desktop Panel

Carefully place the Desktop Panel onto the assembled metal frame, aligning the pre-drilled holes. Secure the desktop to the frame using the remaining M6x15 screws (K). Ensure all screws are tightened for a stable surface.



Image: Illustration of attaching the desktop panel to the assembled metal frame.



Image: The OLIXIS Computer Office Desk fully assembled, showcasing its rustic brown desktop and black metal frame.

Operating Instructions

The OLIXIS Computer Office Desk is designed for straightforward use as a stable work surface. No complex operations are required.

- **Placement:** Position the desk on a flat, stable surface. Use the adjustable feet to compensate for any unevenness in the floor.
- **Weight Distribution:** Distribute weight evenly across the desktop. Avoid placing heavy items solely on one side or corner.
- **Storage Bag:** Utilize the side storage bag for organizing documents, books, magazines, or other office supplies.
- **Headphone Hook:** Hang headphones, bags, or other accessories on the integrated hook to keep your desktop clear and organized.



Image: The OLIXIS desk in a home office environment, demonstrating its use with a computer setup and side storage.

Video: A product video demonstrating the features of the desk, including the headphone hook and storage bag, and showing it in use.

Maintenance

Proper maintenance will extend the life and appearance of your OLIXIS Computer Office Desk.

- **Cleaning:** Wipe the desktop and metal frame with a *dry cloth*. For spills, use a slightly damp cloth and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Water Resistance:** The particleboard desktop is designed to be water-resistant and anti-scratch. While it can withstand minor spills, it is not fully waterproof. Clean up spills promptly to prevent damage.
- **Screw Tightness:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Environmental Factors:** Avoid prolonged exposure to direct sunlight or extreme temperatures, which can affect the material's integrity.



Image: Close-up of the desktop surface demonstrating its water-resistant properties with water droplets.

Troubleshooting

This section addresses common issues you might encounter with your desk.

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose screws or uneven floor.	Ensure all assembly screws are fully tightened. Adjust the leveling feet on the bottom of the legs to stabilize the desk on uneven surfaces.
Parts do not align during assembly.	Incorrect orientation of parts or screws not fully loosened.	Review the assembly diagrams to ensure correct part orientation. Loosen all screws slightly, align parts, then re-tighten.
Desktop appears scratched or damaged.	Heavy use or sharp objects.	The desktop is anti-scratch, but extreme force can cause damage. Use desk mats or coasters for protection. Minor scratches may be concealed with furniture repair markers.
Storage bag or headphone hook is loose.	Mounting screws are loose.	Re-tighten the M6x15 screws (K) that secure the storage bag and headphone hook to the frame.

Specifications

Feature	Detail
Brand	OLIXIS
Model Number	OLXDCCZ-63RT-1
Product Dimensions	23.62"D x 63"W x 29.8"H
Color	Rustic Brown (Desktop), Black (Frame)
Style	Modern
Base Material	Metal
Top Material Type	Wood (Particleboard, Laminated)
Maximum Weight Capacity	176 lbs
Special Features	Storage Bag, Headphone Hook, Compact, Water-resistant, Anti-scratch
Assembly Required	Yes
Included Components	Home Office Desk, Assembly Tools, Instruction Manual



Image: Diagram illustrating the key dimensions of the OLIXIS Computer Office Desk.

Warranty and Support

For any questions, concerns, or issues regarding your OLIXIS Computer Office Desk, please contact OLIXIS customer support. While specific warranty details are not provided in this manual, OLIXIS is committed to customer satisfaction.
You can visit the official OLIXIS Store for more information and support:
OLIXIS Store on Amazon

© 2025 OLIXIS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DS93CW9D

More documents and user manuals: **https://manuals.plus/**