Coleshome HRO-r26

Coleshome Desk with Storage Instruction Manual

Model: HRO-r26

1. Introduction

Product Overview

The Coleshome Desk with Storage (Model: HRO-r26) is a versatile and functional computer desk designed to optimize your workspace. It features integrated power outlets and USB charging ports for convenience, along with three fabric drawers for ample storage. Its sturdy construction and elegant design make it suitable for various settings, including home offices, study rooms, and living areas.

Overall view of the Coleshome Desk with Storage, highlighting its clean design and integrated features.

Key Features

- **Spacious Storage with Fabric Drawers:** Three easy-to-assemble fabric drawers provide ample storage space for documents, office supplies, gaming equipment, and more, helping to keep your workspace clutter-free.
- **Integrated Charging Station:** Equipped with 2 AC outlets and 2 USB ports, ideally placed for charging laptops, phones, and other devices. Integrated cable management helps keep wires tidy, ensuring a clean setup for work or play.
- **Versatile Workstation:** Offers plenty of space for a laptop, books, and accessories. Additional legroom and robust construction make it ideal for long study sessions, remote work, or intense gaming.
- **Sturdy and Elegant Design:** Combines a metal frame with a wooden top, offering unwavering stability – no wobbling during typing, writing, or gaming. Its industrial-chic look perfectly integrates with modern home or office decor.
- **Easy Assembly and After-Sales Service:** Comes with detailed instructions and clearly labeled parts for straightforward assembly.

2. Package Contents

Please check the package contents carefully against the list below. If any items are missing or damaged, please contact customer support.

- Desk Tabletop with Integrated Power Strip
- Metal Desk Legs (Frame Components)
- Fabric Drawers (3 units)
- Headphone Hook
- Assembly Hardware (Screws, Allen Wrench)
- Power Cable
- Instruction Manual (this document)

3. Setup and Assembly

Before You Begin

- Unpack all components and verify them against the package contents list.
- Ensure you have sufficient space for assembly.
- Keep children and pets away from the assembly area to prevent accidents.

Assembly Steps

1. **Attach the Metal Frame:** Secure the metal leg frames to the underside of the desk tabletop using the provided screws and Allen wrench. Ensure all connections are tight and stable.
2. **Install the Headphone Hook:** Locate the designated holes on the side of the desk frame and attach the headphone hook using the appropriate hardware.
3. **Assemble Fabric Drawers:** Fold and assemble the three fabric drawers according to the diagrams. Insert the bottom panel to create a sturdy box.
4. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots under the desk tabletop.
5. **Connect Power Cable:** Plug the desk's integrated power cable into a standard wall outlet.
6. **Position the Desk:** Carefully move the assembled desk to its desired location.

Illustration of fabric drawer assembly and their placement within the desk.

4. Operating Instructions

Using the Integrated Charging Station

The desk is equipped with a convenient charging station built into the tabletop.

- Ensure the desk's power cable is securely plugged into a live wall outlet.
- Use the **2 AC Outlets** for devices requiring standard power plugs (e.g., monitor, laptop charger).
- Use the **2 USB Ports (5V/2A)** to charge mobile devices such as smartphones, tablets, or other USB-powered accessories.

Detail of the integrated power outlets and USB charging ports.

Utilizing Storage Drawers

The three fabric drawers provide organized storage for your items.

- Simply pull the drawer handles to open and access the contents.
- Push the drawers back in until they are flush with the desk front to keep your workspace tidy.

Using the Headphone Hook

The sturdy metal hook on the side of the desk is designed for convenience.

- Hang your headphones, backpack, or other small items on the hook to keep them easily accessible and off the desk surface.

The convenient headphone hook keeps your accessories organized.

5. Maintenance

Cleaning

- **Desk Surface:** Wipe the desk surface with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Fabric Drawers:** Spot clean the fabric drawers with a mild detergent and a damp cloth if necessary. Allow to air dry completely. Do not machine wash.

Care

- Avoid placing extremely hot or cold items directly on the desk surface without a coaster or protective pad.
- Do not overload the drawers to prevent damage or deformation.
- Periodically check all screws and connections to ensure they remain tight. Retighten if any looseness is detected.

6. Troubleshooting

Common Issues and Solutions

Issue	Possible Cause	Solution

Issue	Possible Cause	Solution
Desk wobbles or is unstable.	Loose screws; uneven floor.	Ensure all assembly screws are tightened securely. Move the desk to a level surface or use shims if necessary.
Integrated charging ports (AC/USB) are not working.	Desk power cable not connected; power outlet issue.	Verify the desk's power cable is fully plugged into a functional wall outlet. Test the wall outlet with another device.
Fabric drawers are difficult to open/close or get stuck.	Improper assembly; overloaded drawer; obstruction.	Ensure drawers are assembled correctly and not overfilled. Check for any items obstructing the drawer's movement.

7. Specifications

Feature	Detail
Brand	Coleshome
Model Number	HRO-r26
Color	White
Product Dimensions (L x W x H)	100 x 48 x 79 cm (39.4 x 18.9 x 31.1 inches)
Item Weight	9.9 Kilograms (21.8 lbs)
Number of Drawers	3
Included Components	Integrated USB Port (as part of the power strip)
Assembly Required	Yes

Detailed dimensions of the Coleshome Desk.

8. Warranty and Support

Warranty Information

Please refer to your purchase documentation or the retailer's website for specific warranty details regarding your Coleshome Desk. Warranty terms typically cover manufacturing defects.

Customer Support

If your desk arrives damaged, with a missing part, or scratched, please do not hesitate to contact Coleshome customer support. Our professional customer support team is dedicated to assisting you and will help resolve the issue within 24 hours.
For support, please visit the official Coleshome website or contact the seller directly through your purchase platform.