CalExotics SE-4575-01-3

CalExotics Couture Collection Rumble Wand Massager User Manual

Model: SE-4575-01-3

1. Product Overview

The CalExotics Couture Collection Rumble Wand Massager is a rechargeable personal massager designed for deep, rumbling vibrations. It features a soft, flexible neck and is crafted from 100% waterproof silicone for versatile use and easy cleaning. This device offers 10 distinct speeds of vibration to customize your experience.



Front view of the CalExotics Couture Collection Rumble Wand Massager, showcasing its ergonomic design and textured head.

Key Features:

- Powerful, deep rumbling vibrations with a soft and flexible neck.
- Ridged design for enhanced sensation.
- Constructed from 100% waterproof silicone.
- 10 speeds of intense vibration.
- Equipped with a memory chip that resumes on the last function used.
- Security travel lock feature: hold the power button for 3 seconds to turn on or off.
- USB rechargeable for convenience.
- Includes a 1-year limited manufacturer warranty.

2. Safety Information

Please read all instructions carefully before using this product. Keep this manual for future reference.

- This product is intended for adult use as a non-medical pleasure device only. Not for medical use.
- Discontinue use in the event of any medical condition or pain. Consult a healthcare professional if discomfort persists.
- Do not use if the product appears damaged or defective.
- Keep out of reach of children.
- Avoid prolonged exposure to direct sunlight or extreme temperatures.

3. Getting Started

Initial Charge:

Before first use, fully charge your Rumble Wand Massager. Refer to the 'Charging' section for detailed instructions.

First Use Cleaning:

Clean the massager thoroughly before its initial use. Refer to the 'Care and Maintenance' section for cleaning guidelines.

4. Operation

Power On/Off and Travel Lock:

To turn the device **ON** or **OFF**, press and hold the power button for 3 seconds. This action also activates or deactivates the security travel lock feature.



The control button on the massager for power and mode selection.

Adjusting Vibration Speeds:

Once the device is on, press the power button repeatedly to cycle through the 10 available vibration speeds. Each press will advance to the next speed setting.

Official product video demonstrating the features and operation of the CalExotics Couture Collection Rumble Wand Massager.

5. Charging

The Rumble Wand Massager is USB rechargeable. Use the included charging cord for optimal performance.

Charging Instructions:

1. Insert the small end of the USB charging cord into the charging port located at the base of the massager.
2. Plug the USB end of the cord into a compatible USB power source (e.g., computer, USB wall adapter).
3. The LED light on the massager will flash while charging.

4. Once fully charged, the LED light will glow solid.



The massager connected to its USB charging cord, illustrating the charging port location.

Charging Time and Run Time:

- A complete charge takes approximately 2 hours.
- The device runs for up to 60 minutes on high speed.
- The device runs for up to 90 minutes on low speed.

6. Care and Maintenance

Proper care ensures the longevity and hygiene of your massager.

Cleaning:

- The massager is 100% waterproof (IPX7 submersible), allowing for easy cleaning.
- Wash the device with warm water and a mild soap or a specialized toy cleaner after each use.
- Rinse thoroughly to remove all soap residue.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

Drying and Storage:

- Pat the massager dry with a lint-free cloth.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep separate from other toys made of different materials to prevent material degradation.

7. Troubleshooting

If you encounter any issues with your Rumble Wand Massager, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted or travel lock is engaged.	Charge the device fully. Press and hold the power button for 3 seconds to disengage the travel lock.
Device is not charging.	Loose connection or faulty USB port/charger.	Ensure the charging cable is securely connected. Try a different USB port or power adapter.
Vibrations are weak.	Low battery.	Recharge the device until the LED light glows solid.

If these steps do not resolve the issue, please contact customer support.

8. Specifications

- **Product Dimensions:** 7 x 2 x 2 inches; 14.2 ounces
- **Item Model Number:** SE-4575-01-3
- **Material:** Silicone
- **Color:** Blue
- **Manufacturer:** California Exotic Novelties
- **Power Source:** USB Rechargeable
- **Vibration Modes:** 10 speeds
- **Waterproof Rating:** IPX7 Submersible

9. Warranty and Support

Warranty Information:

This CalExotics Couture Collection Rumble Wand Massager is backed by a**1-year limited manufacturer warranty**. Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, concerns, or warranty claims, please contact CalExotics customer support directly. Refer to the product packaging or the official CalExotics website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question