Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COOKLEE food processor

COOKLEE 600W 12-Cup Food Processor Instruction Manual

Model: Food Processor

1. Introduction

Thank you for choosing the COOKLEE 600W 12-Cup Food Processor. This versatile appliance is designed to simplify your food preparation tasks, offering multiple functions including chopping, mincing, dicing, shredding, slicing, pureeing, and dough making. With its powerful 600-watt motor and intuitive controls, you can achieve consistent results efficiently. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. Important Safety Information

Please read and understand all safety instructions before using this appliance.

- Always unplug the food processor from the power outlet before assembling, disassembling, cleaning, or when not in use.
- Keep hands and utensils away from moving blades or discs while processing food to prevent serious injury. Use the food pusher provided.
- Ensure the processing bowl and lid are securely locked in place before operating the appliance. The dual-lock safety design prevents operation if not properly assembled.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- Avoid contact with moving parts. Blades are sharp; handle with extreme care.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Use only attachments and accessories recommended or sold by the manufacturer.

3. What's in the Box

Your COOKLEE Food Processor package includes the following components:

- Main Motor Body
- 12-Cup Processing Bowl
- Lid with Food Chute
- Food Pusher
- S.S. Chopping Blade (S-shaped)
- Kneading Blade
- Reversible S.S. Slicing/Shredding Disc (Fine)
- Reversible S.S. Slicing/Shredding Disc (Coarse)
- S.S. French Fries Disc
- Long Shaft for Discs



Figure 3.1: All components included in the COOKLEE Food Processor package.

4. Assembly and Setup

Follow these steps to assemble your food processor before use:

1. **Step 1: Attach the Bowl.** Place the 12-cup processing bowl onto the motor base. Turn the bowl clockwise until you hear a "click" sound, indicating it is securely locked and the safety switch is triggered.
2. **Step 2: Insert the Blade/Disc.** Select the desired blade (chopping or kneading) or disc (slicing, shredding, or french fries) and place it onto the long shaft inside the bowl. Ensure it sits firmly.
3. **Step 3: Secure the Lid.** Place the lid onto the processing bowl. Turn the lid clockwise until it locks into place with a "click" sound. The dual-lock safety design ensures the appliance will not operate unless both the bowl and lid are correctly secured. An "E1" error may display if not properly locked.
4. **Step 4: Plug In.** Connect the power cord to a suitable electrical outlet. The LED display will show "OFF" or a timer.



Figure 4.1: Dual-Lock Safety Design ensures secure assembly.



Figure 4.2: Visual guide for assembly and initial use.

5. Operation

5.1 Control Panel Overview

The COOKLEE Food Processor features an intuitive LED smart display and touchpad controls with a central knob for operation.



Figure 5.1: LED Display and Touchpad Controls.

The control panel includes:

- **Time/Speeds Display:** Shows current time or speed setting.
- **Mode Icons:** Ice-crushing, Kneading, Chopping, Cleaning, Timer, Speed.
- **Knob:** Used to start, pause, or cancel operations. Rotate to adjust speed or time.

5.2 Using the Functions

The food processor offers 6 modes and 11 speeds to handle various tasks. To operate:

1. Ensure the appliance is properly assembled and locked.
2. Select the desired mode by pressing the corresponding icon on the touchpad. The light for the selected mode will illuminate.
3. Adjust the speed or time using the central knob if needed (for manual mode). For pre-set modes, the appliance will run for a default duration.
4. Press the central knob to start the operation.
5. To stop, press the knob again. To cancel and reset, long-press the knob for three seconds.

5.2.1 Chopping/Mincing

Use the S.S. Chopping Blade for chopping vegetables, mincing meat, or pureeing ingredients. Recommended maximum meat quantity is 500g. For chopping, select the 'Chopping' mode and press the knob to start. The default time is 30 seconds.



Figure 5.2: S-Shaped Blades for Chopping and Dough Making.

5.2.2 Slicing/Shredding/Dicing

Attach the appropriate reversible S.S. Slicing/Shredding Disc (fine or coarse) or the S.S. French Fries Disc. Insert food through the food chute using the pusher. Select the 'Speed' mode and adjust to desired speed (8-11) for optimal results.



Figure 5.3: Reversible Slicing & Shredding Discs.

5.2.3 Kneading Dough

Use the Kneading Blade for preparing dough. Select the 'Kneading' mode. The appliance will run for a default time of 2 minutes 30 seconds. For best results, follow a flour to water ratio of approximately 2:1 (e.g., 360g flour, 120g water).



Figure 5.4: Kneading dough with the specialized blade.

5.2.4 Ice Crushing

For ice crushing, use the S.S. Chopping Blade. Select the 'Ice-crushing' mode. The appliance will run for a default time of 60 seconds. For optimal results, use white ice cubes placed in the middle of the bowl.

Figure 5.5: Ice crushing using the S.S. chopping blade.

5.3 Official Product Video

Watch this video for a demonstration of the COOKLEE Food Processor's powerful motor and various blade options.

Your browser does not support the video tag.

Video 5.1: Demonstration of the COOKLEE Food Processor's motor and blade options by a seller.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your COOKLEE Food Processor.

6.1 Self-Cleaning Mode

For quick and easy cleaning of the bowl and blades:

1. Fill the processing bowl with warm water and a small amount of dish soap.
2. Secure the lid.
3. Press the 'Cleaning' mode icon on the touchpad. The appliance will run for a default time of 2 minutes.
4. After the cycle, unplug the unit and rinse the bowl and blades thoroughly.



Figure 6.1: Activating the self-cleaning mode.

6.2 Manual Cleaning

- Always unplug the appliance before cleaning.
- All removable parts (bowl, lid, blades, discs, pusher) are dishwasher safe. Place them on the top rack of your dishwasher.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- Handle blades and discs with extreme care as they are very sharp.



Figure 6.2: Dishwasher-safe accessories for easy cleaning.

6.3 Storage

The appliance features a winding storage design for the power cord to prevent tangling. Wrap the cord around the designated area on the base and position the plug for easy access.



Figure 6.3: Winding storage design for the power cord.

7. Troubleshooting

If you encounter issues with your COOKLEE Food Processor, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	1. Power cord not securely plugged in. 2. Bowl or lid not properly locked (E1 error). 3. Power outage.	1. Ensure the power cord is firmly plugged into a working outlet. 2. Twist the bowl and lid clockwise until they click securely into place. 3. Check your household's power supply.
Motor runs, but food is not processing.	Blade/disc not properly installed on the shaft.	Unplug the unit, then re-install the blade or disc, ensuring it sits firmly on the shaft.

Problem	Possible Cause	Solution
Appliance stops during operation.	Overload protection activated.	Unplug the unit, remove some food, and let the motor cool down for 15-20 minutes before restarting.
Loud noise or vibration.	Improper assembly or uneven load.	Ensure all parts are securely assembled. Distribute food evenly in the bowl.

If the problem persists after trying these solutions, please contact COOKLEE Customer Support.

8. Specifications

Feature	Detail
Brand	COOKLEE
Model Name	Food Processor
Wattage	600 watts
Bowl Capacity	12 cups
Number of Speeds	11
Functions	Chopping, Mincing, Dicing, Shredding, Slicing, Purees, Dough, Ice-crushing
Special Features	All-in-One Powerhouse, Dual-lock design, 6 modes, LED Display, Touchpad Controls, Versatile Attachments
Product Dimensions	14.49"D x 10.59"W x 9.45"H
Color	Black
Material	Plastic (body), Stainless Steel (blades/discs)
Care Instructions	Dishwasher Safe (removable parts)

9. Warranty and Support

COOKLEE is committed to providing quality products and lifelong support. If you have any questions, encounter missing parts, or experience damage concerns, our 24/7 Customer Service Team is ready to assist you. Your satisfaction is our priority.
For support, please visit the official COOKLEE website or contact our customer service team through the platform where you purchased the product.

© 2023 COOKLEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSDCT5RV

More documents and user manuals: **https://manuals.plus/**