Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RG10B(B)/BGEF

XINFUTE Midea A/C Remote Control RG10B(B)/BGEF User Manual

Model: RG10B(B)/BGEF | Brand: XINFUTE

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your XINFUTE RG10B(B)/BGEF replacement remote control for Midea air conditioning units. Please read this manual thoroughly before using the remote control to ensure proper function and longevity.

Product Overview

The XINFUTE RG10B(B)/BGEF is a replacement remote control designed for various Midea air conditioner models. It features a clear LCD display and intuitive button layout for easy control of your A/C unit.



Image 1: Front and back view of the XINFUTE RG10B(B)/BGEF remote control. The front shows the LCD screen and control buttons, while the back displays product information and battery compartment details.

Button Functions



Image 2: Detailed front view of the remote control, highlighting the LCD display and various function buttons.

- **Power Button (Orange):** Turns the air conditioner on or off.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Fan, Dry, Heat - depending on A/C unit).
- **Sleep Button (Moon icon):** Activates or deactivates sleep mode.
- **SET / OK Buttons:** Used for confirming settings or navigating menus.
- **Up/Down Arrows:** Adjusts temperature, fan speed, or navigates options.
- **Timer Button (Clock icon):** Sets or cancels the timer function.
- **Fan Button:** Adjusts fan speed.
- **Swing Button:** Controls the louver swing function.
- **Favorite Button (Heart icon):** Saves or recalls preferred settings.

- **Turbo Button:** Activates rapid cooling/heating.
- **LED Button:** Controls the display light on the A/C unit.
- **Clean Button:** Initiates the self-clean function (if supported by A/C unit).

Setup

Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 3: Back of the remote control with the battery compartment open, showing where to insert two AAA batteries.

Note: This remote control is a direct replacement and typically does not require programming for compatible Midea A/C units. Simply install batteries and point it towards your air conditioner.

Operation

To operate your Midea air conditioner using this remote control, ensure there is a clear line of sight between the remote and the A/C unit's receiver.

- **Turning On/Off:** Press the orange Power button.
- **Changing Mode:** Press the Mode button repeatedly to cycle through available modes (e.g., Cool, Fan, Dry). The

current mode will be displayed on the remote's LCD screen.

- **Adjusting Temperature:** Use the Up and Down arrow buttons to set your desired temperature. The temperature is displayed in Celsius only. This remote does not support Fahrenheit display.
- **Fan Speed:** Press the Fan button to adjust the fan speed (e.g., Auto, Low, Medium, High).
- **Swing Function:** Press the Swing button to activate or deactivate the automatic louver swing.
- **Timer Function:** Press the Timer button to set a timer for the unit to turn on or off. Refer to your A/C unit's manual for specific timer settings.
- **Sleep Mode:** Press the Sleep button to enter a power-saving mode that adjusts temperature gradually for comfortable sleep.
- **Turbo Mode:** Press the Turbo button for rapid cooling or heating.
- **LED Display:** Use the LED button to turn the A/C unit's display light on or off.
- **Clean Function:** If your A/C unit supports it, press the Clean button to activate the self-cleaning feature.



Image 4: Close-up view of the remote's LCD screen, displaying the set temperature (26°C) and the 'Cool' mode icon.

Maintenance

Battery Replacement

When the remote control's display becomes dim or it stops responding, it's time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

- Always replace both batteries at the same time.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's finish or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the A/C unit's receiver.
  - Make sure you are within the effective operating range of the A/C unit.
- **Temperature display is only in Celsius:**
  - This remote control is designed to display temperature in Celsius only. There is no option to switch to Fahrenheit.
- **Some buttons do not work:**
  - Verify that your specific Midea A/C model supports the function associated with the button. Not all A/C units have every feature (e.g., Clean, Turbo).

Specifications

Model	RG10B(B)/BGEF
Brand	XINFUTE
Type	Air Conditioner Remote Control
Material	ABS Material
Color	White
Batteries Required	2 x AAA (not included)
Rated Voltage	3VDC
Temperature Display	Degrees Celsius Only
Product Dimensions	Approximately 4 x 3 x 1 inches
Item Weight	Approximately 2.4 ounces
Compatible Models	RG10B(D)/BGEF, RG10B(D1)/BGEFU1, RG10B1(D)/BGEF, RG10B2(D)/BGCEF, RG10B10(D)/BGEF, RG10A4(D)/BGEF, RG10A4(D1)/BGEFU1, RG10A5(D)/BGEF, RG10A5(D1)/BGEFU1, RG10A5(D1)/BGCEFU1, RG10A5(D)/BGCEF, RG10A11(D)/BGEF, RG10B(B1)/BGEFU1, RG10A(B2S)/BGEFU1, RG10A5(B1)/BGCEFU1, RG10A4(B1)/BGEFU1, RG10L(2HS)/BGEFU1, RG10M(2HS)/BGEF



Image 5: Back of the remote control with a label indicating the model type RG10B(B)/BGEF and rated voltage of 3VDC.

Warranty and Support

Warranty Information

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use.

Customer Support

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please

contact the seller within 24 hours of receiving your product for assistance. For further support or inquiries, please refer to the seller's contact information provided at the time of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSFZHCKF

More documents and user manuals: **https://manuals.plus/**