COLAMY MK01

COLAMY MK01 Ergonomic Mesh Office Chair

Instruction Manual

Introduction

Thank you for choosing the COLAMY MK01 Ergonomic Mesh Office Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most comfortable and supportive experience from your new chair. The COLAMY MK01 features an adjustable headrest, 4D armrests, adjustable lumbar support, height adjustment, a 3-position tilt lock, and a sliding seat, all designed to enhance your seating experience.

Safety Information

- Always assemble the chair according to the instructions provided.
- Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- Keep the chair away from heat sources and sharp objects to prevent damage to the mesh material.
- Ensure all bolts are securely tightened before use and periodically check for looseness.

Setup and Assembly

The COLAMY MK01 chair is designed for straightforward assembly. Please follow the steps below carefully. An Allen wrench is typically included for assembly.

Assembly Video Guide

Your browser does not support the video tag.

Video Description: This video provides a visual guide for assembling the COLAMY Ergonomic Mesh Office Chair (MK model). It demonstrates the step-by-step process of attaching components and securing them with the provided tools.

Key Assembly Steps (General)

1. **Attach Arms to Seat Cushion:** Secure the left and right arms to the bottom of the seat cushion using the provided bolts and Allen wrench. Ensure arms are correctly oriented (L for left, R for right).
2. **Connect Backrest to Seat:** Attach the backrest to the seat mechanism, aligning the holes and tightening the bolts.
3. **Install Gas Lift:** Insert the gas lift cylinder into the center hole of the chair base.
4. **Attach Casters:** Press the casters firmly into the holes at the end of each leg of the chair base.
5. **Mount Seat onto Base:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is

seated securely.

Image Description: A close-up view showing a person wearing gloves attaching the chair arms to the underside of the seat cushion using bolts and an Allen wrench. This illustrates a typical step in the assembly process.

Operating Instructions

The COLAMY MK01 chair offers multiple adjustments to customize your seating experience for optimal comfort and support.

1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side under the seat. Pull the lever up while standing to raise the seat. To lower the seat, pull the lever up while seated. Release the lever at the desired height.



Image Description: An illustration highlighting the 8 key adjustment points on the COLAMY MK01 chair, including seat depth, armrest height, armrest angle/width, adaptive headrest, lumbar adjustment, seat height, tilt & tilt lock, and 360° swivel.

2. Seat Depth (Slide Seat) Adjustment

To adjust the seat depth, locate the lever or button under the seat (often on the left side). Engage the mechanism to slide the seat forward or backward to achieve the desired depth, ensuring your back is against the backrest and there is a comfortable gap between the seat edge and your knees. Release the lever/button to lock the position.

3. Backrest Tilt and Tilt Lock

The chair features a 3-position tilt lock (107°, 117°, 127°). To recline, lean back. To lock the tilt at a desired angle, engage the tilt lock lever (typically on the left side). To unlock and return to an upright position, disengage the lever and lean forward slightly.



Image Description: A diagram illustrating the multifunctional tilting mechanism of the chair, showing recline angles (107°, 117°, 127°) and the locations of the recline lock, seat height adjustment, and seat depth adjustment controls.

4. 4D Armrest Adjustment

The 4D armrests allow for extensive customization:

- **Height:** Press the button on the side of the armrest and slide it up or down.
- **Forward/Backward:** Slide the armrest pad forward or backward.
- **Left/Right (Width):** Slide the armrest pad left or right.
- **Pivot (Angle):** Rotate the armrest pad inward or outward.



Image Description: A detailed graphic demonstrating the four-dimensional adjustments of the chair's armrests, including left/right movement (3.15"), up/down movement (3.94"), rotation (150°), and front/back movement (1.97").

5. Adjustable Headrest

The headrest can be adjusted vertically to provide optimal neck and head support. Grasp the headrest and slide it up or down to your preferred height.



Image Description: A side profile of a person seated in the chair, showing the adaptive adjustable headrest positioned to support the neck and head. An arrow indicates the vertical adjustment range of 3.94 inches (10 cm).

6. Adjustable Lumbar Support

The lumbar support is integrated into the backrest and can be adjusted to fit the curve of your lower back. Adjust the lumbar support by sliding it up or down to align with your natural spinal curve.



Image Description: A side view of a person sitting in the ergonomic office chair, highlighting the dynamic headrest support and adjustable lumbar support. Green arrows indicate the areas of support provided by the chair's design.

7. 360-Degree Swivel

The chair base allows for a full 360-degree rotation, providing flexibility and ease of movement within your workspace.

Product Overview Video

Your browser does not support the video tag.

Video Description: This video provides an overview of the COLAMY Ergonomic Mesh Office Chair (MK model), showcasing its various features and adjustments in action, including the 4D armrests and seat slide.

Maintenance and Care

Proper care will extend the life and appearance of your COLAMY office chair.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn stains on mesh or fabric, use a mild soap solution and a soft

brush, then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.

- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary.
- **Casters:** Keep casters free of hair and debris to ensure smooth rolling.
- **Avoid Damage:** Do not expose the chair to direct sunlight for prolonged periods, as this may cause fading. Avoid placing sharp objects on the mesh or seat cushion.

Troubleshooting

If you encounter any issues with your COLAMY MK01 chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder is faulty or lever is not engaged correctly.	Ensure the height adjustment lever is fully engaged. If the problem persists, the gas lift may need replacement.
Chair wobbles or is unstable	Loose bolts or uneven floor.	Check and tighten all assembly bolts. Ensure the chair is on a flat, even surface.
Armrests slide too easily or do not lock	Internal mechanism wear or design characteristic.	While 4D armrests offer flexibility, some movement is inherent. Ensure no debris is obstructing the locking mechanism if applicable.
Casters do not roll smoothly	Debris (hair, dust) caught in casters.	Turn the chair over and remove any debris from the caster wheels.
Backrest does not tilt or lock	Tilt mechanism is jammed or lock is not engaged/disengaged properly.	Ensure the tilt lock lever is fully engaged or disengaged. Check for any obstructions under the seat mechanism.

Specifications

Feature	Detail
Model Name	MK01
Brand	COLAMY
Material	Mesh (back, seat), Foam (fill), Metal (frame)
Product Dimensions (D x W x H)	30.31" x 24.02" x 51.38" (77cm x 61cm x 130.5cm)
Item Weight	32.2 pounds (14.6 kg)
Maximum Weight Recommendation	300 pounds (136 kg)
Seat Height	Adjustable, up to 22.64 inches (57.5 cm)
Seat Depth	Adjustable, 19.29 inches (49 cm)
Arm Height	Adjustable, up to 33.27 inches (84.5 cm)
Backrest Width	18.7 inches (47.5 cm)
Reclining Position Count	3 (107°, 117°, 127°)

Feature	Detail
Certifications	BIFMA, SGS Class 4 Gas Cylinder



Image Description: A detailed diagram showing the various dimensions of the COLAMY MK01 office chair, including height, width, depth, seat height, seat depth, and armrest height, along with the maximum weight capacity of 300 lbs.

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or visit the official COLAMY website. If you require further assistance, have questions about assembly, or need to report a defect, please contact COLAMY customer support through their official channels.

COLAMY Official Store: Visit the COLAMY Store on Amazon

© 2024 COLAMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question