Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MUUEGM CDLY-LYZJ-TS02-W-0107-35

MUUEGM Fluted TV Stand Instruction Manual

Model: CDLY-LYZJ-TS02-W-0107-35

1. Setup and Assembly

This section provides general guidelines for assembling your MUUEGM Fluted TV Stand. For detailed, step-by-step instructions, please refer to the assembly manual included in your product packaging. Ensure all parts are present before beginning assembly.

1.1 Unpacking and Part Identification

- Carefully unpack all components from the packaging.
- Verify that all parts listed in the included assembly manual are present and undamaged.
- Lay out all hardware and panels on a clean, soft surface to prevent scratches.

1.2 Assembly Overview

The TV stand is designed for straightforward assembly. Follow the numbered steps in your physical manual. Typically, assembly involves:

1. Attaching the base and legs.
2. Assembling the main cabinet structure.
3. Installing the back panel.
4. Attaching the doors and hinges.
5. Inserting the adjustable shelves.



Image: Front view of the assembled MUUEGM Fluted TV Stand, showcasing its modern design and fluted doors.



Image: Detailed view highlighting the spacious tabletop, fluted door design, and solid metal leg support of the TV stand.

2. Operating Instructions

Your MUUEGM Fluted TV Stand is designed to provide functional storage and a stable platform for your television and media devices.

2.1 Placing Your Television

- Ensure the TV stand is placed on a level surface.
- Carefully place your television on the spacious tabletop. This stand can accommodate TVs up to 70 inches.
- Distribute the weight evenly to maintain stability.



Image: Illustration showing the MUUEGM Fluted TV Stand accommodating televisions of various sizes, up to 70 inches.

2.2 Utilizing Storage Space

The stand features internal compartments with adjustable shelves for organized storage.

- **Adjustable Shelves:** The shelves can be set to three different heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf.
- **Cable Management:** Utilize the cable holes in the back panel to route wires and cables neatly, keeping them out of sight and preventing tangles.



Image: Interior view of the MUUEGM Fluted TV Stand with doors open, showing the adjustable shelves and ample storage space for media equipment and decorative items.



Image: Close-up demonstrating the adjustable shelf feature, allowing users to customize storage height.

2.3 Adjusting Door Hinges

If the doors are not aligning correctly, the hinges can be adjusted. Refer to the video below for a visual guide.

Your browser does not support the video tag.

Video: This video demonstrates how to adjust the hinges on the cabinet doors to ensure proper alignment and smooth operation.

3. Maintenance and Care

Proper care will help maintain the appearance and longevity of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the laminate finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Protection:** Use coasters or protective pads under items that may scratch the surface or leave moisture rings.
- **Stability Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to

maintain structural integrity.

- **Under-cabinet Cleaning:** The design includes sufficient space underneath for robotic vacuum cleaners, facilitating easy floor cleaning.

4. Troubleshooting

If you encounter any issues with your TV stand, refer to the following common solutions:

Problem	Possible Cause	Solution
Wobbly or unstable stand	Loose fasteners; uneven floor	Ensure all screws are tightened. Place the stand on a level surface or use shims if necessary.
Doors do not align or close properly	Hinges require adjustment	Adjust the door hinges using a screwdriver. Refer to the 'Adjusting Door Hinges' video in the Operating section.
Scratches or marks on surface	Sharp objects; abrasive cleaning	Use protective pads for items. Clean with a soft, damp cloth only. Minor marks may be concealed with furniture repair pens.

If the issue persists or is not listed here, please contact customer support.

5. Product Specifications

Key specifications for the MUUEGM Fluted TV Stand:



Image: Diagram illustrating the dimensions (70"W x 15.75"D x 25"H) and maximum load capacity (70 lbs) of the MUUEGM Fluted TV Stand.

- **Brand:** MUUEGM
- **Model Number:** CDLY-LYZJ-TS02-W-0107-35
- **Color:** White
- **Material:** Engineered Wood
- **Product Dimensions (D x W x H):** 15.75" x 70" x 25"
- **Item Weight:** 96 pounds
- **Maximum Load Capacity:** 70 lbs (for tabletop)
- **Accommodates TV Size:** Up to 70 inches
- **Number of Shelves:** 3 (adjustable)
- **Number of Doors:** 2
- **Installation Type:** Freestanding
- **UPC:** 740946219080

6. Warranty Information

Specific warranty details for the MUUEGM Fluted TV Stand are typically provided with your purchase documentation. Please refer to the warranty card or information included in your product packaging for terms, conditions, and duration of coverage. In general, warranties cover manufacturing defects under normal use.

Keep your proof of purchase for any warranty claims.

7. Customer Support

For further assistance, questions, or to report any issues, please contact MUUEGM customer support.

- **Online Support:** Visit the official MUUEGM store on Amazon:MUUEGM Store
- **Manufacturer:** MUUEGM

When contacting support, please have your model number (CDLY-LYZJ-TS02-W-0107-35) and proof of purchase readily available.

© 2023 MUUEGM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSHZJNSJ

More documents and user manuals: **https://manuals.plus/**