Moosum B0DSJ5WHCB

MOOSUM 1.8L Electric Rice Cooker and Steamer User Manual

Model: B0DSJ5WHCB | Brand: Moosum

Important Safety Instructions

Please read all instructions carefully before using this appliance to ensure safe and efficient operation. Keep this manual for future reference.

- Always ensure the appliance is unplugged from the power outlet before cleaning or when not in use.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- This appliance is for household use only. Do not use outdoors.
- Close supervision is necessary when the appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Exercise extreme caution when moving an appliance containing hot oil or other hot liquids.
- The inner pot and steamer are designed with a ceramic non-stick coating, free from BPA, PFAS, and Cadmium, ensuring food safety.
- Ensure the lid is properly closed during operation to prevent steam burns.

Product Overview and Components

The MOOSUM Electric Rice Cooker and Steamer comes with essential components for convenient cooking.



Image: Main components of the MOOSUM Electric Rice Cooker, including the main unit, removable inner pot, steamer basket, rice spoon, and measuring cup.

Included Accessories:

- **Main Unit:** The primary housing with control panel.
- **Removable Inner Pot:** Features a durable ceramic non-stick coating for easy cooking and cleaning.
- **Plastic Steamer Basket:** For steaming vegetables, fish, or other foods simultaneously with rice.
- **Rice Spoon:** Designed to prevent scratching the non-stick coating.
- **Measuring Cup:** Standard cup for precise rice and water measurements.



Image: The rice cooker with its lid open, showing vegetables inside the inner pot, emphasizing the ceramic non-stick coating and its safety features (BPA-Free, PFAS-Free, Cadmium-Free).

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the inner pot, steamer basket, rice spoon, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Ensure the power cord is securely plugged into the appliance and then into a suitable electrical outlet. The appliance operates on standard household voltage.
5. **First Test Run (Recommended):** It is advisable to perform a test run with just water before cooking food. Fill the inner pot with 1.5 liters of water, close the lid, and initiate a cooking cycle. This helps to eliminate any initial manufacturing odors and ensures the unit functions correctly. After the cycle, discard the water and clean the inner pot again.

Operating Instructions

Cooking Rice:

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. One cup typically yields enough cooked rice for one person.
2. **Rinse Rice:** Rinse the rice thoroughly under cold water until the water runs clear. This removes excess starch and results in fluffier rice.
3. **Add Rice to Inner Pot:** Place the rinsed rice into the removable inner pot.
4. **Add Water:** For best results, use a 1:1 ratio of rice to water (e.g., 1 measuring cup of rice to 1 measuring cup of water). Note: Using significantly more water than a 1:1 ratio may cause the pot to overflow during cooking.
5. **Place Inner Pot:** Insert the inner pot into the main unit, ensuring it sits correctly.
6. **Close Lid:** Close the lid securely.
7. **Start Cooking:** Plug in the appliance. Press the single button or lever down to the "Cook" position. The "Cook" indicator light will illuminate.
8. **Automatic Keep Warm:** Once the rice is cooked, the appliance will automatically switch to the "Keep Warm" mode, and the "Keep Warm" indicator light will illuminate. This function maintains the rice at an optimal serving temperature for up to 24 hours. However, for best taste and to prevent rice from drying out or sticking, it is recommended to serve within a few hours.
9. **Serve:** Open the lid carefully to avoid steam. Use the provided rice spoon to fluff and serve the rice.



Image: The rice cooker demonstrating its one-touch operation, capable of cooking whole grain rice, white rice, slow cooking, steaming, making yogurt, and sautéing.

Using the Steamer Function:

1. **Prepare Water:** Add water to the inner pot (typically 1-2 cups, depending on steaming time).
2. **Place Food in Steamer Basket:** Arrange vegetables, fish, or other items in the plastic steamer basket.
3. **Insert Steamer Basket:** Place the steamer basket onto the inner pot.
4. **Close Lid and Start:** Close the lid and press the button/lever to "Cook".
5. **Monitor Steaming:** Steaming time varies based on the food type and quantity. Monitor the food and remove the steamer basket once done. The unit will switch to "Keep Warm" when the water boils away or the main cooking cycle finishes.



Image: The rice cooker on a kitchen counter, surrounded by several bowls of cooked rice, illustrating its large 1.8L capacity, suitable for up to 20 bowls of rice.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your rice cooker.

1. **Always Unplug:** Before cleaning, always unplug the rice cooker from the power outlet and allow it to cool completely.
2. **Inner Pot and Steamer Basket:** The removable inner pot and steamer basket are dishwasher safe. Alternatively, wash them with warm, soapy water using a soft sponge to protect the ceramic non-stick coating. Rinse thoroughly and dry completely.
3. **Rice Spoon and Measuring Cup:** Wash with warm, soapy water, rinse, and dry.
4. **Main Unit Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water.
5. **Lid and Condensation Collector:** The lid has an internal condensation collector. After each use, carefully wipe down the inside of the lid. If your model has a removable condensation collector, empty and clean it regularly. Be mindful of water near the power cord connection point when cleaning the lid area.



Image: The inner pot and steamer basket placed in a dishwasher, indicating they are dishwasher-safe for easy cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Rice sticks to the bottom or burns.	Too little water; rice left on "Keep Warm" for too long; inner pot not clean.	Ensure correct rice-to-water ratio (1:1). Serve rice promptly after cooking or switch off the unit if not serving immediately. Ensure inner pot is clean before use.
Water overflows during cooking.	Too much water; too much rice; lid not sealed properly.	Do not exceed the maximum fill line. Use the recommended 1:1 rice-to-water ratio. Ensure the lid is securely closed.
Rice is too hard or undercooked.	Not enough water; cooking cycle interrupted.	Add slightly more water next time. Ensure the unit is not unplugged or switched off during the cooking cycle.
Appliance does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Check if the power cord is securely plugged into both the unit and the wall outlet. Test the outlet with another appliance. If the problem persists, contact customer support.
Initial strong odor during first use.	New appliance odor from manufacturing.	This is normal. Perform a test run with water only (as described in Setup) to help dissipate the odor. Ensure good ventilation.

Specifications

Model Number: B0DSJ5WHCB

Brand: Moosum

Capacity: 1.8 Liters (suitable for 3-10 people)

Color: Black

Dimensions: Approximately 28.1 cm (depth) x 26.8 cm (width) x 28.6 cm (height)

Power Source: Electric

Special Features: One-button operation, Automatic Keep Warm function, Ceramic non-stick inner pot, BPA-Free, PFAS-Free, Cadmium-Free.

Included Components: Plastic steamer, durable non-stick inner pot, rice spoon, measuring cup.



Image: Diagram illustrating the 1.8L capacity and physical dimensions (height and width) of the MOOSUM Electric Rice Cooker.

Warranty and Support

Moosum products are manufactured with quality and customer satisfaction in mind. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Moosum website.
If you encounter any issues or have questions regarding your MOOSUM Electric Rice Cooker and Steamer, please contact our customer support team. Have your model number (B0DSJ5WHCB) and purchase details ready for faster assistance.
Customer Support: Please refer to the contact information provided on the product packaging or the official Moosum website for the most up-to-date support channels.

© 2025 Moosum. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question