kangten 1

kangten 3-Burner Propane Gas BBQ Grill User Manual

Model: 1 (SC-J33)

Introduction

Thank you for purchasing the kangten 3-Burner Propane Gas BBQ Grill. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your grill. Please read it thoroughly before use and retain it for future reference.

Important Safety Information

WARNING: For outdoor use only. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

- Always operate the grill on a level, stable, non-combustible surface.
- Keep children and pets away from the grill at all times.
- Do not move the grill while it is in use or hot.
- Ensure proper ventilation. Never use the grill in an enclosed space.
- Check for gas leaks before each use. Use a soapy water solution to check connections.
- Do not obstruct the flow of combustion and ventilation air.
- Always turn off the gas supply at the cylinder after use.
- Wear protective gloves when handling hot components.

Package Contents

Verify that all components are present before assembly:

- 1 x 3-Burner BBQ Gas Grill Unit

- 1 x BBQ Grill Net
- 1 x Oil Catching Pan
- 1 x Food Pan
- 2 x Lifting Frames
- 3 x Burner Covers
- 2 x Control Knobs
- 1 x English User Manual (this document)



This image displays all the individual parts included in the package, ensuring you have everything needed for assembly. It shows the main grill body, the wire grill grate, the rectangular oil drip pan, a flat food pan, two vertical lifting frames, three burner covers, and two control knobs.

Setup and Assembly

1. Unpack all components and ensure they are free from damage.
2. Place the main grill unit on a stable, flat surface.
3. Insert the three burner covers over the burners inside the grill chamber.
4. Place the oil catching pan into its designated slot beneath the burners.
5. Position the BBQ grill net on top of the grill chamber, resting on the support edges.
6. Attach the two lifting frames to the sides of the grill net, if desired, for height adjustment.

7. Connect the propane gas cylinder (not included) to the grill's gas inlet (9mm/0.35inch) securely. Ensure all connections are tight.
8. Perform a leak test: Apply a soapy water solution to all gas connections. Bubbles indicate a leak. Tighten connections or replace parts as necessary. Do not use the grill if a leak is detected.



This diagram illustrates the overall dimensions of the grill: 47cm (18.5 inches) in length, 42cm (16.5 inches) in width, and 19.5cm (7.7 inches) in height. The grill net measures 45cm (17.7 inches) by 25cm (9.8 inches).

Operating Instructions

Ignition

1. Ensure the propane gas cylinder is connected and the gas supply valve is open.
2. Turn one of the control knobs to the 'HIGH' position while simultaneously pressing the integrated ignition button (if applicable, or use a long lighter).
3. Once the burner ignites, release the knob. If it doesn't ignite within 5 seconds, turn the knob to 'OFF', wait 5 minutes, and repeat the process.
4. Repeat for other burners as needed.

Cooking

Adjust the flame intensity using the control knobs to achieve desired cooking temperature. The grill supports low-pressure combustion for fast and uniform heating.



This image shows the grill actively cooking a variety of foods, including meat and vegetable skewers, a whole crab, and baked scallops, demonstrating its capacity and versatility for different culinary preparations.



This image depicts the grill in an outdoor setting, suggesting its suitability for social gatherings and backyard barbecues. It shows the grill in action with food being prepared, while people are visible in the background, creating a lively atmosphere.

Maintenance and Care

Cleaning

- Allow the grill to cool completely before cleaning.
- The detachable electroplated grill mesh, oil collection tray, and stainless steel body are designed for easy cleaning.
- Remove the grill net and oil pan. Wash them with warm, soapy water. Rinse thoroughly and dry.
- Wipe the stainless steel body with a damp soft cloth. For stubborn stains, use a non-abrasive stainless steel cleaner.
- Do not use abrasive cleaners or sharp objects that could scratch the surfaces.

Storage

- Store the grill in a dry, protected area when not in use.
- Disconnect the propane cylinder and store it upright in a well-ventilated area, away from direct sunlight or heat sources.

Troubleshooting

Problem	Possible Cause	Solution
Burner fails to ignite	No gas flow	Check propane cylinder connection, ensure gas valve is open, check for empty cylinder.
Low flame or uneven heating	Low gas pressure or partially clogged burner	Check gas supply. Clean burner ports if necessary.
Gas odor	Gas leak	Immediately turn off gas supply. Perform leak test with soapy water. Do not use if leak persists. Contact qualified service personnel.
Grill not heating sufficiently	Burner issues or incorrect gas pressure	Ensure all burners are lit. Verify gas pressure (2800Pa).

Product Specifications

Feature	Detail
Model	SC-J33
Material	430 Steel, Iron (Electroplated Grill Surface)
Power Source	LPG (Liquefied Petroleum Gas)
Intensity of Pressure	2800Pa
Mounting Type	Free Standing
Color	Silver
Number of Burners	3
Number of Switches	3
Grill Net Size	45 x 25 cm (17.7 x 9.8 inches)
Gas Inlet Diameter	9 mm (0.35 inches)

Feature	Detail
Product Dimensions (L x W x H)	47 x 42 x 19.5 cm (18.5 x 16.5 x 7.7 inches)
Net Weight	6 kg (13.2 lbs)
Gross Weight	6.5 kg (14.3 lbs)

Warranty and Support

This kangten 3-Burner Propane Gas BBQ Grill comes with a**1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, replacement parts, or warranty inquiries, please contact your retailer or the manufacturer directly. Refer to the contact information provided with your purchase.

For more information, visit the official product page:Amazon Product Page

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question