ALLIMITY RM-C3612

ALLIMITY RM-C3612 Remote Control User Manual

Model: RM-C3612





Image: Front view of the ALLIMITY RM-C3612 remote control, showcasing its button layout and ergonomic design.

1. Introduction

This manual provides instructions for the ALLIMITY RM-C3612 remote control. This remote is designed as a replacement or secondary control unit for various television models, offering full functionality without the need for complex programming.

Compatibility: The RM-C3612 remote control is compatible with the following TV models:

- K40FV
- K32HV
- RM-C3612
- LT-50VD3300S
- BSL-24T2SV
- BSL-32T2SV
- BSL-43T2SV
- BSL-65T2SV
- BSL-42T2SV
- BSL-50T2SV

To ensure compatibility, compare your original remote or TV model number with the list provided. The full model number is typically found on a label on the back of your television.

2. Product Features

- **Easy to Use:** No programming or setup required. Insert batteries and it's ready for use.
- **Full Functionality:** Designed to replicate all functions of your original remote control.
- **Ergonomic Design:** Lightweight and comfortable to hold, ensuring ease of use.
- **Stable Performance:** Offers a reliable and stable remote control experience with a maximum range of 10 meters.





Image: The ALLIMITY RM-C3612 remote control shown with its dimensions: 18 cm (7.09 in) in length and 4.5 cm (1.77 in) in width.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.





Image: Rear view of the ALLIMITY RM-C3612 remote control, highlighting the battery compartment cover.

3.2 Initial Use

Once batteries are installed, the remote control is ready for immediate use with compatible TV models. No pairing or programming steps are required.

---

4. Operating Instructions

The ALLIMITY RM-C3612 remote control features a standard layout for intuitive operation of your television. Below is a general guide to its buttons and functions:



Image: Angled view of the ALLIMITY RM-C3612 remote control, providing a clear perspective of all buttons.

- **Power Button ( ):** Turns the TV on or off.
- **INPUT:** Selects the input source (HDMI, AV, etc.).
- **Number Buttons (0-9):** Directly select TV channels.
- **GUIDE:** Accesses the electronic program guide.
- **CH.LIST:** Displays the channel list.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and context (e.g., teletext, interactive features).
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back (↩):** Returns to the previous menu or screen.
- **EXIT:** Exits the current menu or application.
- **VOL (+/-):** Adjusts the volume level.
- **Mute ( ):** Mutes or unmutes the TV sound.
- **CH (∧ / ∨):** Changes TV channels up or down.
- **Home ( ):** Accesses the TV's home screen or smart TV interface.
- **TEXT:** Activates teletext.

- **SUBTITLE:** Toggles subtitles on or off.
- **INFO:** Displays information about the current program or input.
- **Dedicated App Buttons (NETFLIX, YouTube, prm video, plex, BROWSER, Disny, free, deezer):** Provides direct access to these streaming services or functions.

---

5. Maintenance

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or buttons.

5.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries.

5.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

---

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly inserted with the correct polarity.
  - Replace the batteries with fresh ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Point the remote directly at the TV.
- **Limited range:**
  - Ensure batteries are fresh.
  - Check for strong light sources (like direct sunlight or bright fluorescent lights) that might interfere with the infrared signal.
- **Specific buttons not working:**
  - Clean the remote control, especially around the non-working buttons, to remove any dirt or debris.
  - If only certain app buttons are not working, ensure your TV is connected to the internet and the apps are installed and updated.

If issues persist after following these steps, the remote control may be faulty, or there might be an issue with your television's infrared receiver.

---

7. Specifications

Feature	Specification
Brand	ALLIMITY
Model Name	RM-C3612
Connectivity Technology	Infrared (IR)
Color	Black
Special Feature	Ergonomic
Maximum Range	10 Meters
Item Weight	59 Grams
Compatible Devices	K40FV, K32HV, RM-C3612, LT-50VD3300S, BSL-24T2SV, BSL-32T2SV, BSL-43T2SV, BSL-65T2SV, BSL-42T2SV, BSL-50T2SV
Number of Supported Devices	10 (referring to the number of distinct TV models it can control, not simultaneous devices)

8. Warranty and Support

Specific warranty information for the ALLIMITY RM-C3612 remote control is not provided in the product details. For warranty claims or technical support, please refer to the retailer where the product was purchased or contact ALLIMITY customer service directly if contact information is available on the product packaging or their official website.
Please retain your proof of purchase for any warranty-related inquiries.

© 2025 ALLIMITY. All rights reserved.