Primal Hatch 6072462

Primal Hatch Jurassic World Interactive Toy Dinosaur & Egg Instruction Manual

Model: 6072462

Introduction

Welcome to the world of Primal Hatch! This interactive toy dinosaur and egg allows you to experience the excitement of hatching and training your very own baby T-Rex. Designed for children aged 5 and up, this toy features over 100 sounds and reactions, providing a dynamic and engaging play experience.
Please read this manual carefully to ensure proper setup, operation, and maintenance of your Primal Hatch T-Rex.

What's in the Box

- 1 Primal Hatch Egg
- 1 Interactive T-Rex Dinosaur
- 1 Clicker Accessory
- 1 Toy Meat Accessory
- 3 AA Batteries (included)



Image: The Primal Hatch T-Rex, its egg, the clicker, and the toy meat accessory.

Setup and Initial Hatching

1. **Unboxing the Egg:** Carefully remove the Primal Hatch Egg from its packaging. The egg is designed to crack and reveal the dinosaur inside.
2. **Initiating Hatching:** To begin the hatching process, gently tap the egg repeatedly. The egg will start to crack and move on its own. Continue tapping until the T-Rex begins to emerge.



Image: The Primal Hatch egg, ready for hatching.

3. **Dinosaur Emergence:** As the egg cracks further, the baby T-Rex will push its way out. This process is designed to be interactive and may involve some gooey membrane, which is part of the realistic hatching experience.



Image: The baby T-Rex's head peeking out from the cracked eggshell.

4. **Assembling the T-Rex:** Once the T-Rex has fully emerged from the egg, you may need to attach its tail. Ensure it is securely fastened.
5. **Battery Installation:** The toy requires 3 AA batteries, which are included. Ensure they are correctly installed in the battery compartment, usually located on the underside of the dinosaur.

Operating Your Interactive T-Rex

Your Primal Hatch T-Rex is an interactive toy with over 100 sounds and reactions. Its behavior can be influenced by how you interact with it, allowing you to train it to be friendly or fierce.

Interaction Modes:

- **Using the Clicker:** The included clicker accessory can be used to grab your T-Rex's attention and initiate various reactions. Press the button on the clicker to make a sound.
- **Feeding:** Offer the toy meat accessory to your T-Rex. It will react with sounds and movements, indicating whether it is happy or hungry.



Image: The T-Rex interacting with the toy meat accessory.

- **Petting:** Gently pet the T-Rex's head to elicit friendly responses.
- **Tail Interaction:** Pulling the T-Rex's tail may provoke a different reaction, potentially making it more agitated or fierce.

T-Rex Temperaments (Indicated by Eye Color):

- **Green Eyes:** Indicates a happy or friendly temperament.



Image: The T-Rex displaying a friendly temperament with green eyes.

- **Yellow/Orange Eyes:** Indicates a neutral or curious temperament.
- **Red Eyes:** Indicates an angry or fierce temperament.



Image: The T-Rex displaying a fierce temperament with red eyes.

Maintenance

- **Cleaning:** After hatching, some gooey residue may remain. Wipe the T-Rex and egg pieces with a damp cloth. Do not submerge the electronic components in water.
- **Battery Replacement:** When the T-Rex's reactions become sluggish or sounds are distorted, it's time to replace the 3 AA batteries. Use a screwdriver to open the battery compartment, replace the old batteries with new ones, and secure the cover.
- **Storage:** Store the toy and its accessories in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

- **T-Rex Not Hatching:** Ensure the egg has been tapped sufficiently. The hatching process is designed to be gradual and interactive. If the T-Rex is still not emerging, check for any obstructions or ensure the pull tabs (if any were present during initial setup) have been removed.
- **No Sound/Movement:** Check if the batteries are correctly installed and fully charged. Replace batteries if necessary. Ensure the toy's power switch is in the "ON" position.
- **Inconsistent Reactions:** The T-Rex's temperament can change based on interaction. Refer to the "Operating Your Interactive T-Rex" section for guidance on how different interactions affect its mood and responses.

Specifications

- **Product Dimensions:** 11.18 x 7.32 x 6.26 inches
- **Item Weight:** 0.035 ounces
- **Item Model Number:** 6072462
- **Manufacturer Recommended Age:** 5 years and up
- **Batteries:** 3 AA batteries required (included)
- **Manufacturer:** Spin Master

Safety Information

As indicated by the manufacturer, this product is suitable for ages 5 years and up. Adult supervision is recommended during play, especially during the initial hatching process and when handling small parts. Keep away from small children due to potential choking hazards.

Warranty and Support

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question