Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE SKYWORTH MTS

User Manual for XINFUTE Replacement Remote Control

Model: SKYWORTH MTS

Introduction

This user manual provides comprehensive instructions for the XINFUTE Replacement Remote Control, designed for SKYWORTH LCD LED Android TVs. This remote is a direct replacement for original units and requires no programming.
Compatible TV Models: 24E3A11G, 32E3A11G

Product Overview



Figure 1: Front view of the remote control, showing all buttons and their labels.



Figure 2: Back view of the remote control, showing the battery compartment cover.

Setup

The XINFUTE Replacement Remote Control is designed for immediate use with compatible SKYWORTH TV models without any programming required.

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.



Figure 3: Battery compartment with batteries inserted.

Note: Batteries are not included with the remote control. Always use new batteries for optimal performance.

Operating Instructions

Once batteries are installed, the remote control is ready to operate your compatible SKYWORTH TV. Point the remote control directly at the TV's infrared receiver.

Key Functions:

- **POWER:** Turns the TV on or off.
- **P.M. (Picture Mode):** Adjusts picture settings.
- **S.M. (Sound Mode):** Adjusts sound settings.

- **ZOOM:** Adjusts screen zoom level.
- **Number Buttons (0-9):** Direct channel selection.
- **RETURN/BACK:** Returns to the previous screen or menu.
- **QUICK:** Quick access function (may vary by TV model).
- **MENU:** Opens the main menu.
- **SOURCE:** Selects input source (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **OK:** Confirms selection.
- **EXIT:** Exits the current menu or function.
- **LIST:** Displays channel list.
- **INFO:** Displays program information.
- **VOL +/-:** Adjusts volume up or down.
- **CH +/-:** Changes channels up or down.
- **HOME:** Returns to the TV's home screen.
- **MTS (Multi-channel Television Sound):** Selects audio modes.
- **3D:** Activates/deactivates 3D mode (if supported by TV).
- **REC:** Starts recording (if supported by TV).
- **GUIDE:** Opens the electronic program guide.
- **FAV:** Accesses favorite channels.
- **C.C. (Closed Caption):** Toggles closed captions.
- **Media Playback Controls (Play/Pause, Stop, Rewind, Fast Forward, Previous, Next):** Controls media playback.
- **FREEZE:** Freezes the current screen.
- **Color Buttons (Red, Green, Yellow, Blue):** Functions vary by TV application or menu.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Environment:** Avoid exposing the remote control to extreme temperatures, direct sunlight, or high humidity.

Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new AAA batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor. Point the remote directly at the TV.
- **Infrared Interference:** Bright lights or other infrared devices might interfere. Try using the remote in a different lighting condition or away from other IR sources.
- **TV Compatibility:** Confirm that your TV model (24E3A11G or 32E3A11G) is listed as compatible. While this remote is

a replacement, some specific TV firmware versions might behave differently.

Specific Buttons Not Working:

- Ensure the remote is pointed correctly.
- Check for any physical damage or debris under the button.
- If only certain buttons fail, it might indicate a defect. Refer to the warranty section.

Specifications

Feature	Detail
Model Number	SKYWORTH MTS
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 x AAA (not included)
Connectivity Technology	Infrared
Compatible Devices	Television (SKYWORTH LCD LED Android TV models 24E3A11G, 32E3A11G)
Special Features	Ergonomic, No Programming Required

Warranty and Support

Warranty: Enjoy a one-year warranty on all purchases of this product.
Customer Support: All products are inspected before shipment. If you are not satisfied with your purchase, please contact us within 24 hours of receipt. For further assistance or warranty claims, please refer to the seller's contact information on the platform where the purchase was made.
For more information, visit the XINFUTE Store.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSLFMC2F

More documents and user manuals: **https://manuals.plus/**