Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE Pensonic

XINFUTE Replacement Remote Control User Manual

For Pensonic and Hisense Smart TV Models

1. Product Overview

This manual provides instructions for the XINFUTE replacement remote control, designed for seamless operation with various Pensonic and Hisense Smart TV models. This remote offers a full range of functions, replicating the original remote's capabilities.

Compatible TV Models:

- Pensonic/Hisense 3237
- Pensonic/Hisense 3257
- Pensonic/Hisense 3277
- Pensonic/Hisense 4057
- Pensonic/Hisense 4237
- Pensonic/Hisense 4257



Image 1.1: Front view of the XINFUTE replacement remote control, showing all buttons including power, number keys, navigation, volume, channel, and dedicated app buttons.

2. Setup and Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image 2.1: Rear view of the remote control with the battery cover removed, showing the two AAA battery slots.



Image 2.2: Full back view of the XINFUTE remote control, showing the smooth ergonomic design and the battery compartment cover.

3. Operating Your Remote Control

This remote control is pre-programmed and ready to use with compatible Pensonic and Hisense Smart TVs. No additional setup or pairing is required.

Basic Functions:

- **Power (Red Button):** Turns the TV on or off.
- **Number Keys (0-9):** Directly select channels.
- **SOURCE:** Cycles through input sources (HDMI, AV, etc.).

- **VOL +/-:** Adjusts the volume level.
- **CH ^/v:** Changes channels up or down.
- **MUTE:** Mutes or unmutes the TV audio.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **MENU:** Opens the TV's main menu.
- **EXIT:** Exits the current menu or function.
- **HOME:** Returns to the Smart TV home screen.

Smart TV and Media Functions:

- **NETFLIX:** Direct access to the Netflix application.
- **YouTube:** Direct access to the YouTube application.
- **USB MEDIA:** Accesses media files from a connected USB device.
- **Play/Pause, Stop, Rewind, Fast Forward:** Controls media playback.

4. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Ensure the TV is powered on.
- **Buttons not working:**
  - Clean the remote control buttons and surface with a soft, dry cloth to remove any dirt or residue.
  - If only specific buttons are not working, the remote may be damaged and require replacement.
- **Remote range is limited:**
  - Ensure batteries are fresh.
  - Reduce the distance between the remote and the TV.
  - Remove any potential sources of infrared interference.

5. Care and Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as they may damage the remote.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Product Specifications

Brand	XINFUTE
Model Number	Pensonic
Material	ABS Material
Color	As Shown (Black)
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 x AAA (not included)
Compatible Devices	Television (Pensonic/Hisense Smart TVs)

7. Warranty and Customer Support

This XINFUTE remote control comes with a one-year warranty from the date of purchase, covering manufacturing defects. This warranty ensures your satisfaction with the product's quality and performance.
All products undergo inspection before shipment. If you are not satisfied with your purchase or encounter any issues, please contact customer support within 24 hours of receiving your product. Our team is available to assist with troubleshooting or provide further guidance.
For warranty claims or customer support, please refer to the contact information provided by your retailer or visit the official XINFUTE store page on Amazon for assistance.

Thank you for choosing XINFUTE.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSW4RV5H

More documents and user manuals: **https://manuals.plus/**