ALLIMITY DG11J1-72

ALLIMITY DG11J1-72 Replacement Remote Control User Manual

For Hisense Air Conditioners

Introduction

This manual provides comprehensive instructions for the ALLIMITY DG11J1-72 replacement remote control, designed for use with various Hisense Air Conditioner models. This remote control is an infrared (IR) replacement and does not require any programming or pairing. Simply install batteries to begin operation.

Setup

Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

Initial Use

Once batteries are installed, the remote is ready for use. No programming or pairing is required. Ensure there are no obstructions between the remote control and the air conditioner's receiver for proper signal transmission.

Operating Instructions

Familiarize yourself with the buttons and their functions for optimal control of your Hisense Air Conditioner.




ON/OFF
MODE
FAN
SWING
SLEEP
SUPER
SMART
IFEEL
DIMMER
TIMER ON
TIMER OFF
CLOCK
SWING
MUTE
8°HEAT

Image: Front view of the remote control, displaying the layout of all function buttons and the LCD screen.

Basic Functions

- **ON/OFF:** Press to turn the air conditioner on or off.
- **MODE:** Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Temperature Up/Down (▲/▼):** Adjusts the desired temperature setting.

Special Functions

- **SWING:** Activates or deactivates the automatic louver swing function.
- **SLEEP:** Engages the sleep mode, which adjusts temperature for comfort during sleep and saves energy.
- **SUPER:** Activates rapid cooling or heating for quick temperature changes.
- **SMART:** Automatically selects the optimal operating mode based on the room temperature.
- **IFEEL:** Activates the 'I Feel' function, which measures the temperature at the remote control's location for more precise comfort.
- **DIMMER:** Adjusts the brightness of the air conditioner's display panel.
- **TIMER ON/OFF:** Sets a specific time for the air conditioner to turn on or off.
- **CLOCK:** Sets the current time on the remote control.
- **MUTE:** Silences the air conditioner's operational beeps.
- **8°HEAT:** Activates a low-temperature heating mode, typically used to prevent freezing in unoccupied rooms.

Fahrenheit/Celsius Toggle

To switch the temperature display between Fahrenheit (°F) and Celsius (°C), simultaneously press and hold the**MODE** button and the **TEMPERATURE-** (down arrow) button for 3 seconds.

Maintenance

Battery Replacement

Replace batteries when the remote control's display becomes dim or when the air conditioner no longer responds to commands. Always replace both batteries at the same time with new AAA alkaline batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstacles between the remote control and the air conditioner's signal receiver.
  - Confirm the remote control is pointed directly at the air conditioner.
- **Temperature unit not changing:**

- Ensure you are simultaneously pressing and holding both the **MODE** and **TEMPERATURE-** buttons for at least 3 seconds.

SPECIFICATIONS



Image: Front view of the remote control with its approximate dimensions indicated.

Feature	Detail
Model Number	DG11J1-72 (sub DG11J1-71)
Brand	ALLIMITY
Compatible Devices	Hisense Air Conditioners (e.g., AP10CR1W, AP10CW2G, AP14CR2WG, AP08CR2W, AP10CR2W, AP12CR2G, AP13HR2G, AP10CR1SEJS, AP08CR1W, AP14DR1SFJS2, AP12CR1SEPS, AP13HR1SEJS00, AP12CR1G, AP14DR1G, AP14CR1WG, AP13HR1G, AP08CR1SEJS, CAP14DR1SFJS2, AP10CW1G, ABSEM4H4S12, ABSCI4H4S18)
Power Source	2 x AAA Alkaline Batteries (not included)
Product Dimensions	5 x 1 x 0.5 inches (approx. 12.7 x 2.54 x 1.27 cm)
Item Weight	2.26 ounces (approx. 64 grams)
Color	Gray
Special Feature	Ergonomic design

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question