Samsung SM-A166M/DS

Samsung Galaxy A16 5G Smartphone User Manual

Model: SM-A166M/DS

Introduction

This manual provides essential information for setting up, operating, and maintaining your Samsung Galaxy A16 5G smartphone. The Samsung Galaxy A16 5G offers a solid mix of features tailored for budget-conscious users while maintaining the quality expected of the Galaxy A series. It boasts a vibrant 6.7-inch Super AMOLED display with a smooth 90Hz refresh rate and a resolution of 1080x2340, delivering excellent clarity and color reproduction. It runs on Android 14 with Samsung's One UI 6.1, supported by six promised major software updates, ensuring long-term usability.

Device Overview



Figure 1: Front view of the Samsung Galaxy A16 5G, showcasing the 6.7-inch display and front camera notch.



Figure 2: Back view of the Samsung Galaxy A16 5G in Blue Black, highlighting the triple camera setup and Samsung branding.



Figure 3: Side view of the Samsung Galaxy A16 5G, showing the volume rocker and power button with integrated fingerprint sensor.



Figure 4: Bottom view of the Samsung Galaxy A16 5G, displaying the USB-C charging port and speaker grille.

Setup

1. Unboxing and Initial Inspection

Carefully remove your Samsung Galaxy A16 5G from its packaging. Inspect the device for any physical damage. The box typically contains the smartphone, a USB-C cable, and a SIM ejection pin. Note that a power adapter is not included and may require a separate purchase.

Your browser does not support the video tag.

Video 1: An unboxing video of the Samsung Galaxy A16 5G, showing the contents of the retail box and initial handling of the device.

2. SIM Card and MicroSD Card Installation

Locate the SIM tray on the side of your device. Use the provided SIM ejection pin to open the tray. Insert your Nano-SIM card(s) and/or a microSD card (up to 1TB for expandable storage) into the designated slots. Ensure the cards are correctly oriented before gently pushing the tray back into the device.



Figure 5: Close-up of the SIM card tray on the Samsung Galaxy A16 5G, indicating where to insert Nano-SIM and microSD cards.

3. Powering On and Initial Configuration

Press and hold the Power/Lock button (located on the side, also serving as the fingerprint sensor) until the Samsung logo appears. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account. You will also be guided through setting up security features like the fingerprint sensor.

Operating Your Device

1. Display Features

The Galaxy A16 5G features a 6.7-inch Super AMOLED display with a 90Hz refresh rate. This technology provides deep blacks, vivid colors, and smoother scrolling and animations compared to typical LCD screens. The display offers 800 nits (HBM) brightness for clear visibility even in bright conditions.

2. Performance and Software

Your device runs on Android 14 with Samsung's One UI 6.1, offering a user-friendly interface. It is powered by either the Exynos 1330 or MediaTek Dimensity 6300 chipset (depending on region) and comes with 6GB of RAM, providing stable everyday performance for multitasking and applications. Samsung has committed to providing up to six major Android OS updates for this model, ensuring long-term software support.

3. Connectivity

The Samsung Galaxy A16 5G supports 5G connectivity, offering faster speeds for streaming and downloading. It is compatible with most US networks and various GSM networks outside the United States. For specific carrier compatibility, please contact your service provider. The device also supports Dual SIM functionality (Nano-SIM and eSIM).

- **5G Bands:** 1, 3, 7, 8, 20, 28, 38, 40, 41, 77, 78 SA/NSA/Sub6
- **4G LTE Bands:** 1, 2, 3, 4, 5, 7, 8, 12, 17, 20, 28, 38, 40, 41, 66

Camera Features

The Galaxy A16 5G is equipped with a versatile triple-lens camera system on the rear and a capable front-facing camera.

- **Main Camera:** 50 MP, f/1.8, (wide), 1/2.76", 0.64µm, AF. This high-resolution sensor captures detailed and pleasing photos in good lighting conditions.
- **Ultra-Wide Lens:** 5 MP. Offers a wider field of view for capturing landscapes or group shots.
- **Macro Sensor:** 2 MP, f/2.4. Suitable for close-up shots of small objects.
- **Front-Facing Camera:** 13 MP. Ideal for selfies and video calls.

For optimal photo quality, ensure good lighting conditions. The main camera performs well, but image quality from the ultra-wide and macro lenses may be less impressive, especially in low light or when zooming.

Battery Management

Your Samsung Galaxy A16 5G is powered by a large 5000 mAh non-removable battery, designed to easily deliver a full day of use under typical conditions.

- **Charging:** The device supports 25W wired fast charging. When the battery is low, connect the provided USB-C cable to a compatible 25W power adapter (sold separately) for quick recharging.
- **Battery Life Tips:** To maximize battery life, reduce screen brightness, disable unnecessary background apps, and use power-saving modes when needed.

Maintenance

To ensure the longevity and optimal performance of your device, follow these maintenance guidelines:

- **Software Updates:** Regularly check for and install software updates to benefit from the latest features, security patches, and performance improvements.
- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid harsh chemicals or abrasive materials.
- **Protection:** Consider using a protective case and screen protector to guard against drops and scratches.
- **Storage Management:** Periodically clear unnecessary files and apps to free up storage space and maintain performance.

Troubleshooting

If you encounter issues with your Samsung Galaxy A16 5G, try the following basic troubleshooting steps:

- **Restart Device:** A simple restart can often resolve minor software glitches.
- **Check Connections:** For connectivity issues (Wi-Fi, 5G), ensure your network settings are correct and you are within range.
- **Software Updates:** Verify that your device is running the latest software version.
- **Factory Reset:** As a last resort, if problems persist, you may perform a factory reset. Back up all important data before proceeding, as this will erase all data on your device.

Specifications

Feature	Specification
Model Name	Samsung Galaxy A16 5G (SM-A166M/DS)
Display	6.7 inches Super AMOLED, 90Hz, 800 nits (HBM), 1080 x 2340 pixels
Processor	Exynos 1330 or MediaTek Dimensity 6300 (region dependent)
RAM	6 GB
Internal Storage	128 GB
Expandable Storage	microSDXC (up to 1 TB)
Rear Camera	50 MP (wide, AF) + 5 MP (ultrawide) + 2 MP (macro)
Front Camera	13 MP
Battery	5000 mAh, non-removable
Charging	25W wired fast charging
Operating System	Android 14, One UI 6.1
Dimensions	3.07 x 0.31 x 6.47 inches
Weight	9.9 ounces
SIM Type	Dual SIM (Nano-SIM, eSIM)

Warranty and Support

For warranty information, please refer to the documentation included with your device or visit the official Samsung support website. Samsung provides extensive software support for the Galaxy A16 5G, including major Android OS updates for up to six years from

its release.
For further assistance, you can visit the Samsung Store on Amazon or contact Samsung customer support directly.

© 2025 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question