Dragon Touch Modern 10 Charm

Dragon Touch 10.1 Inch WiFi Digital Photo Frame

Model: Modern 10 Charm

User Manual

Introduction

The Dragon Touch Modern 10 Charm is a 10.1-inch WiFi digital photo frame designed to display your cherished photos and videos. With its HD IPS touch screen, 16GB internal memory, and auto-rotate feature, it offers a convenient way to share and view memories with family and friends instantly via the free VPhoto app.

Package Contents

Please check the box for the following items:

- Dragon Touch Modern 10 Charm Digital Photo Frame
- Power Adapter
- Stand
- USB Cable
- User Manual

Image: Contents of the product package, including the digital photo frame, power adapter, stand, USB cable, and user manual.

Product Overview

The Modern 10 Charm features a 10.1-inch HD IPS touch screen display with a resolution of 1280x800 and a 16:10 aspect ratio. It includes 16GB of internal storage, supporting approximately 80,000 photos. The frame supports Wi-Fi connectivity (2.4 GHz only) for instant sharing and features an auto-rotate function for flexible placement.



Image: Overview of key features including Wi-Fi, 16GB storage, support for photos and videos, VPhoto app, weather display, touch screen, and sleep mode.

Setup

1. **Power On and Connect to Wi-Fi:** Plug in the power adapter to activate the frame. Follow the on-screen instructions to connect the device to your 2.4 GHz Wi-Fi network.
2. **Download the VPhoto App:** On your smartphone (iOS or Android), download the free "VPhoto" app from your device's app store.
3. **Create an Account:** Open the VPhoto app and create a new user account.
4. **Pair the Frame:** Follow the app's instructions to pair your digital photo frame with your VPhoto account. This typically involves scanning a QR code displayed on the frame.
5. **Upload Photos:** Once paired, you can begin uploading photos and short videos directly from your smartphone to the frame via the app.



Image: Visual guide for the initial setup process, showing the three main steps to get the frame operational and sharing content.

Operating Instructions

Sharing Photos and Videos

The primary method for sharing content is through the VPhoto app. You can send photos and short videos directly from your smartphone to the frame from anywhere in the world, provided the frame is connected to Wi-Fi.



Image: Demonstrates how to share photos wirelessly from a smartphone using the VPhoto app to the digital photo frame.

Multiple User Connection

The VPhoto app allows multiple users to connect to a single frame, enabling family and friends to share their memories to your frame. Each user will need to download the app and be invited to share with your frame.



Image: Illustrates the multi-user sharing capability, allowing several individuals to contribute photos to the same digital frame.

Alternative Photo Upload Methods

In addition to the VPhoto app, you can upload photos using:

- **Email:** Send photos directly to the frame's unique email address.
- **TF Card (MicroSD):** Insert a TF card into the designated slot to display photos or transfer them to internal storage.
- **USB Drive:** Connect a USB drive to view photos or transfer them to the frame's internal memory.



Image: Shows the four different methods available for uploading photos to the digital frame.

Auto-Rotate Feature

The frame automatically adjusts the photo orientation based on how it is positioned (portrait or landscape). This allows for flexible placement on a desk or mounted on a wall.



Image: The auto-rotate function is illustrated with the frame displaying an image correctly in both vertical and horizontal positions.

Sleep Mode

Customize the sleep mode settings to conserve energy and prevent the screen from being on during specific hours, such as overnight.

Internal Storage

The frame comes with 16GB of built-in memory, capable of storing approximately 80,000 photos. This ensures ample space for a large collection of memories.



Image: Visual representation of the frame's 16GB internal storage, capable of holding a vast number of photos.

Product Video Overview

Your browser does not support the video tag.

Video: A brief overview demonstrating the ease of sharing photos and the auto-rotate feature of the Dragon Touch digital photo frame.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screen and frame. Avoid abrasive cleaners or sprays directly on the screen.
- **Placement:** Place the frame on a stable surface, away from direct sunlight, heat sources, and moisture.
- **Software Updates:** Ensure your frame's firmware is up to date for optimal performance. Check for updates in the settings menu.

Troubleshooting

- **Frame not powering on:** Ensure the power adapter is securely connected to both the frame and a working power outlet.

- **Cannot connect to Wi-Fi:** Verify that your Wi-Fi network is 2.4 GHz. Ensure the password is correct. Try restarting your router and the photo frame.
- **Photos not appearing on frame:** Check if the frame is connected to Wi-Fi and if the VPhoto app shows successful upload. Ensure the frame is correctly paired with your app account.
- **TF card/USB drive not recognized:** Ensure the external device is inserted correctly. If issues persist, try formatting the card/drive on a computer (backing up data first) or using a different card/drive. **Note:** Always remove external devices before performing a factory reset on the frame.
- **Screen unresponsive:** Try restarting the frame by unplugging and re-plugging the power adapter. If the issue continues, a factory reset might be necessary (refer to settings for this option).

Specifications

Brand	Dragon Touch
Model	Modern 10 Charm
Screen Size	10.1 Inches
Resolution	1280x800 (WXGA)
Aspect Ratio	16:10
Digital Storage Capacity	16 GB
Connectivity	Wi-Fi (2.4 GHz)
Human Interface Input	Touchscreen
Power Source	Corded Electric
Product Dimensions	24.2 x 30 x 2.51 cm; 510 g

Warranty and Support

For warranty information and technical support, please refer to the warranty card included in your package or visit the official Dragon Touch website. You can also contact customer service through the contact information provided on the product packaging or the brand's official channels.