Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-L1508

XINFUTE RM-L1508 Replacement TV Remote Control User Manual

Model: RM-L1508 | Brand: XINFUTE

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your new XINFUTE RM-L1508 Replacement TV Remote Control. This remote is designed as a direct replacement for various TCL, Thomson, and iFFALCON TV models, offering universal compatibility for most models without requiring complex programming.

Product Overview

The XINFUTE RM-L1508 remote control is constructed from durable ABS material and features an ergonomic design for comfortable handling. It provides all essential functions for controlling your television.



Figure 1: Front view of the XINFUTE RM-L1508 replacement TV remote control, showing all buttons including number pad, navigation, volume, channel, and media controls, with a prominent Netflix button at the bottom.



Figure 2: Close-up of the top half of the remote, highlighting the power, mute, number pad (0-9), PRE-CH, and LIST buttons, along with volume and channel controls.



Figure 3: Close-up of the bottom half of the remote, showing the central OK button surrounded by navigation arrows, along with EXIT, GUIDE, TEXT, SUBT., colored function buttons, media playback controls (REC, Play, Pause, Stop, Fast Forward, Rewind), and the dedicated Netflix button.



Figure 4: Back view of the XINFUTE RM-L1508 remote control, showing the smooth, ergonomic casing and the location of the battery compartment cover.

Setup Guide

Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control. Always use new batteries and dispose of old batteries responsibly.

Initial Use

The XINFUTE RM-L1508 is designed as a universal replacement remote control. It typically requires no programming and can be used directly with most compatible TCL, Thomson, and iFFALCON TV models once batteries are installed. Simply point the remote at your TV and begin using it.

Operating Your Remote Control

This remote control provides all the necessary functions for navigating your television. Below is a guide to common buttons and their uses:

- **Power Button ( ):** Turns the TV on or off.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Number Buttons (0-9):** Directly input channel numbers.
- **PRE-CH:** Switches to the previously viewed channel.
- **LIST:** Accesses the channel list or program guide.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P ∧ /P ∨):** Changes TV channels.
- **Navigation Arrows (∧ , ∨ , <, >):** Move cursor or selection in menus.
- **OK Button:** Confirms a selection or enters a menu.
- **Home Button ( ):** Returns to the TV's home screen or smart TV interface.
- **Menu Button (≡):** Opens the TV's main menu.
- **Exit Button:** Exits the current menu or application.
- **Guide Button:** Displays the electronic program guide (EPG).
- **TEXT Button:** Activates or deactivates Teletext.
- **SUBT. Button:** Toggles subtitles on or off.
- **Colored Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or applications, as indicated on screen.
- **Media Control Buttons (REC, Rewind, Play, Pause, Fast Forward, Stop):** Control playback of media content (e.g., USB, streaming apps).
- **Netflix Button:** Direct access to the Netflix application.

Maintenance and Care

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in water.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal components.
- **Liquid Exposure:** Keep the remote away from liquids to prevent damage.

Troubleshooting

If you encounter issues with your XINFUTE RM-L1508 remote control, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly installed batteries. Obstruction between remote and TV. Remote is out of range.	Replace batteries with new AAA batteries, ensuring correct polarity. Remove any objects blocking the line of sight to the TV's IR receiver. Move closer to the TV.
Some buttons are unresponsive.	Dirt or debris under buttons. Battery low.	Clean the remote surface. Replace batteries. If problem persists, the button mechanism may be faulty.
TV does not respond to remote.	TV's IR receiver is blocked or faulty. Remote is not compatible with the specific TV model.	Ensure nothing is blocking the TV's IR sensor. Verify your TV model is listed as compatible. Try restarting the TV by unplugging it for a few minutes.
Remote works intermittently.	Low battery power. Weak IR signal.	Replace batteries. Ensure a clear line of sight to the TV.

Product Specifications

Feature	Specification
Model Number	RM-L1508
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 x AAA batteries (not included)
Connectivity Technology	Infrared (IR)
Compatible Devices	Television (TCL, Thomson, iFFALCON and most other models)
Special Features	Ergonomic, No Programming Required
Max Number of Supported Devices	1
Manufacturer	XINFUTE

Warranty and Customer Support

Your XINFUTE RM-L1508 Replacement TV Remote Control comes with a**one-year warranty** from the date of purchase, covering manufacturing defects.
All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receiving your product. For further assistance or warranty claims, please refer to your purchase platform for direct contact information with the seller, Xinfute.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT4BGQ48

More documents and user manuals: **https://manuals.plus/**