Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE QT141

XINFUTE QT141 RE01Z Remote Control User Manual

For SONIQ TV Models: E46Z10A, E46Z11A, E55Z11A, E55Z11A-AU

1. Introduction

This manual provides comprehensive instructions for the XINFUTE QT141 RE01Z replacement remote control. It is designed to operate specific SONIQ TV models, including E46Z10A, E46Z11A, E55Z11A, and E55Z11A-AU. Please read this manual carefully to ensure proper setup and operation of your remote control.

2. Setup: Battery Installation

The XINFUTE QT141 RE01Z remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. Slide the battery cover back into place until it clicks securely.



Image 2.1: Front and back view of the remote control, showing the battery compartment on the rear.

After installing the batteries, the remote control is ready for use with your compatible SONIQ TV.

3. Operating Instructions

This section outlines the general functions of the buttons on your XINFUTE QT141 RE01Z remote control. Point the remote directly at your TV's infrared sensor for optimal performance.



Image 3.1: Front view of the remote control, displaying all functional buttons.

- **POWER (Red Button):** Turns the TV on or off.
- **INPUT:** Cycles through available input sources (e.g., HDMI, AV, USB).
- **Number Buttons (0-9):** Directly select TV channels or input numerical values.
- **INFO:** Displays current channel information or program details.
- **MENU:** Accesses the TV's main menu for settings and adjustments.
- **Navigation Buttons (Up, Down, Left, Right):** Navigate through menus and options.
- **OK/REC LIST:** Confirms selections in menus or accesses the recording list.
- **EXIT:** Exits the current menu or on-screen display.
- **VOL +/-:** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the TV audio.

- **PROG +/-:** Changes TV channels sequentially.
- **DTV/HDMI/USB/ASPECT:** Dedicated buttons for quick access to digital TV, HDMI inputs, USB media, and aspect ratio settings.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within certain TV menus or interactive services.
- **Playback Controls (e.g., Play, Pause, Stop, Fast Forward, Rewind):** Control media playback when using USB or other media sources.

For detailed functions of specific buttons, refer to your SONIQ TV's original user manual.

4. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

5. Troubleshooting

If you experience issues with your remote control, try the following solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm you are within the effective range of the TV's sensor.
- **Intermittent Operation:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure the remote's infrared emitter is clean and free of debris.
- **Specific Buttons Not Working:**
  - If only certain buttons are unresponsive, try replacing the batteries.
  - Ensure the remote is compatible with your specific SONIQ TV model (E46Z10A, E46Z11A, E55Z11A, E55Z11A-AU).

If problems persist after trying these steps, please refer to the Warranty and Support section.

6. Specifications

Feature	Specification
Model Number	QT141 (RE01Z)

Compatible TV Models	SONIQ E46Z10A, E46Z11A, E55Z11A, E55Z11A-AU
Material	ABS Material
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Manufacturer	XINFUTE

7. Warranty and Support

Your XINFUTE QT141 RE01Z remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
If you encounter any issues or require assistance, please contact the seller directly through your purchase platform. When contacting support, please provide your order details and a clear description of the problem to facilitate a prompt resolution.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT6RCKKH

More documents and user manuals: **https://manuals.plus/**