Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SOBERNA M10

SOBERNA Portable Bluetooth Speaker Sonic Bass V4

Model: M10
User Instruction Manual

1. Introduction

Thank you for purchasing the SOBERNA Portable Bluetooth Speaker Sonic Bass V4. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read this manual thoroughly before use to ensure proper functionality and to extend the lifespan of your device.

2. Package Contents

Please check the box for the following items:

- SOBERNA Portable Bluetooth Speaker Sonic Bass V4
- Wireless Microphone
- Earbuds
- Charging Cable (USB-C)
- User Manual

3. Product Overview

The Sonic Bass V4 is a versatile portable speaker designed for high-quality audio and karaoke. It features a robust design with intuitive controls and dynamic lighting.



Image: The SOBERNA Portable Bluetooth Speaker Sonic Bass V4, showcasing its cylindrical shape, mesh grille, illuminated end cap, and control panel with power, play/pause, skip, and EQ buttons. Water splashes around the speaker indicate its water-resistant design.

Control Panel and Ports:

- **Power Button:** Press and hold to turn the speaker ON/OFF.
- **Play/Pause Button:** Press to play or pause audio.
- **Skip Buttons (Previous/Next):** Press to skip tracks.
- **EQ Button:** Press to cycle through different equalizer modes.
- **Microphone Input:** For connecting the included wireless microphone.
- **Charging Port (DC 5V):** For charging the speaker.
- **AUX Input:** For wired audio connection.

4. Setup

4.1 Charging the Speaker

1. Connect the provided USB-C charging cable to the speaker's DC 5V port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.

4.2 Powering On/Off

- To power ON, press and hold the Power button until you hear an audible prompt and the indicator lights illuminate.
- To power OFF, press and hold the Power button again until you hear an audible prompt and the lights turn off.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered ON and in Bluetooth pairing mode (indicated by a flashing Bluetooth light).
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "SOBERNA Sonic Bass V4" from the list of devices.
4. Once connected, the speaker will provide an audible confirmation, and the Bluetooth indicator light will become solid.

5. Operating Instructions

5.1 Music Playback

- **Play/Pause:** Press the Play/Pause button.
- **Next Track:** Press the Next Track button.
- **Previous Track:** Press the Previous Track button.
- **Volume Control:** Adjust volume directly from your connected device.

5.2 Using the Microphone (Karaoke Function)

1. Ensure the wireless microphone is charged and powered on.
2. The microphone should automatically pair with the speaker. If not, refer to the microphone's specific instructions for pairing.
3. Adjust the microphone volume as needed.
4. Begin singing along to your music!

5.3 Equalizer (EQ) Modes

Press the EQ button to cycle through different sound equalization modes (e.g., Bass Boost, Vocal, Standard) to optimize audio for various content types.

5.4 AUX Input Mode

To use a wired connection, connect an audio cable (not included) from your device's audio output to the speaker's AUX input. The speaker will automatically switch to AUX mode.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.
- **Water Resistance:** While the speaker is designed to be water-resistant, do not submerge it in water. Ensure all ports are securely closed before exposure to splashes.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.

Problem	Possible Cause	Solution
No sound from speaker.	Volume too low; Device not connected; Incorrect mode.	Increase volume on speaker and device; Re-pair Bluetooth; Ensure correct input mode (Bluetooth/AUX).
Bluetooth connection unstable or fails.	Too far from device; Interference; Device Bluetooth issue.	Move speaker closer to device; Avoid obstacles; Restart speaker and device's Bluetooth.
Microphone not working.	Microphone not powered on/paired; Low microphone battery.	Ensure microphone is ON and paired; Charge microphone.

8. Specifications

Feature	Detail
Model Name	M10
Brand	SOBERNA
Speaker Type	3D
Connectivity Technology	Bluetooth
Speaker Maximum Output Power	180 Watts
Product Dimensions	3"D x 3"W x 5"H
Mounting Type	Shelf Mount
Number of Items	1 (referring to the main product unit)
Included Components	Earbuds (and speaker, microphone as per product title)

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2024 SOBERNA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DT6W3139

More documents and user manuals: **https://manuals.plus/**