Azwok YKR-Q/002E

Azwok YKR-Q/002E Replacement Remote Control Instruction Manual

For AUX and Rinnai Air Conditioners

Introduction

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Azwok YKR-Q/002E replacement remote control. This remote is designed to function as a direct replacement for various AUX and Rinnai air conditioner models, including YKR-Q/001E, RC-F23HN, RC-F27HN, RC-F37HN, RC-F57HN, RC-F76HN, RC-F86HN, RC-V24HN, RC-V29HN, RCI-M27HN, RCI-M33HN, RCI-M50HN, RINV25RB, RINV35RB, RINV52RB, RINV70RB. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

1. Setup

1.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote control will not be used for an extended period.

1.2. Initial Use

This replacement remote control is pre-programmed and ready for immediate use with compatible AUX and Rinnai air conditioner models. No additional programming or pairing is required. Simply install the batteries, point the remote towards your air conditioner, and begin operation.

2. Operating Instructions

Familiarize yourself with the buttons and their functions as illustrated below. The remote control's display will show current settings.





Figure 1: Azwok YKR-Q/002E Replacement Remote Control. This image displays the front of the remote control, showing its LCD screen at the top, followed by various control buttons. The LCD screen shows temperature, mode, fan speed, and 'ON' status. Below the screen are the '°C/°F', 'MODE', and power buttons, along with temperature adjustment arrows. The lower section features a grid of function buttons including 'SPEED', 'TURBO', 'TIMER', 'iFavor', 'SWING', 'iFeel', 'HEALTH', 'SWING↑', 'SLEEP', 'iClean', 'Anti-FUNGUS', and 'DISPLAY'.

2.1. Power On/Off

- Press the **Power button** (typically marked with a circle and a vertical line) to turn the air conditioner on or off.

2.2. Mode Selection

- Press the **MODE button** to cycle through available operating modes: Auto, Cool, Dry, Fan, Heat (if applicable to your AC unit). The current mode will be displayed on the LCD.

2.3. Temperature Adjustment

- Use the **Up (▲)** and **Down (▼)** arrow buttons to increase or decrease the desired temperature. The temperature range is typically between 16°C and 30°C (60°F and 86°F).
- Press the **°C/°F button** to switch between Celsius and Fahrenheit temperature display.

2.4. Fan Speed Control

- Press the **SPEED button** to adjust the fan speed. Options typically include Auto, Low, Medium, and High.
- Press the **TURBO button** for maximum fan speed and rapid cooling/heating (depending on mode).

2.5. Swing Function

- Press the **SWING button** (SWING→ or SWING↑) to activate or deactivate the automatic louver swing function, which distributes air evenly.

2.6. Timer Function

- Press the **TIMER button** to set the auto-on or auto-off timer. Refer to your air conditioner's specific manual for detailed timer setting procedures, as this remote acts as a universal interface.

2.7. Special Functions

- **iFavor:** Activates a pre-set preferred operating mode.
- **iFeel:** Activates a function that senses the temperature at the remote control's location for more precise temperature regulation.
- **HEALTH:** Engages air purification or health-related functions of the air conditioner.
- **SLEEP:** Adjusts temperature and fan speed for comfortable sleep conditions, often increasing temperature slightly over time.
- **iClean:** Initiates a self-cleaning cycle for the indoor unit.

- **Anti-FUNGUS:** Activates a function to prevent mold and mildew growth within the air conditioner.
- **DISPLAY:** Controls the display lights on the air conditioner unit.

Note: The availability and specific functionality of these special features depend on your air conditioner model. Refer to your air conditioner's original manual for detailed explanations of these functions.

3. Maintenance

3.1. Cleaning

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

3.2. Battery Replacement

- Replace batteries when the remote's response becomes sluggish or the display dims.
- Follow the battery installation steps outlined in Section 1.1.
- Dispose of used batteries according to local regulations.

3.3. Storage

- Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the batteries to prevent leakage.

4. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly inserted with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Display is dim or blank:**
  - Replace the batteries.
- **Certain functions do not work:**
  - Verify that your specific air conditioner model supports the function you are trying to use. Some advanced features may not be available on all compatible units.
  - Refer to your air conditioner's original manual for feature compatibility.

5. Specifications

- **Model:** YKR-Q/002E
- **Brand:** Azwok
- **Compatible Devices:** AUX and Rinnai Air Conditioners (specific models listed in Introduction)
- **Connectivity Technology:** Infrared (IR)
- **Special Feature:** No Programming Required
- **Power Source:** 2 x AAA Batteries (not included)

- **Dimensions:** Approximately 5.51 x 1.97 x 0.79 inches (14 x 5 x 2 cm)
- **Weight:** Approximately 2.11 ounces (60 grams) without batteries

6. Warranty and Support

This Azwok replacement remote control comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described. If you encounter any issues or believe the remote is defective, please contact your retailer or the manufacturer for assistance.

For further support or inquiries regarding compatibility with specific air conditioner models not listed, please reach out to the seller or manufacturer's customer service. They will be able to assist you in verifying suitability or finding the correct replacement.