Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE UM-4 IECR03

User Manual for XINFUTE UM-4 IECR03 Projector Remote Control

Model: UM-4 IECR03

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your XINFUTE UM-4 IECR03 Projector Remote Control. This remote is designed for use with BenQ Projectors and is made from durable ABS material.

Setup

Battery Installation

The XINFUTE UM-4 IECR03 remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.



Image: Back view of the remote control, highlighting the battery compartment.

Operating Instructions

This remote control is designed to provide intuitive control over your compatible BenQ projector. Ensure the remote is pointed towards the projector's IR receiver for optimal performance.



Image: Front view of the remote control, displaying all buttons and their labels.

Button Functions

Button Name	Function
Power	Turns the projector on or off.
Switch	Toggles between different display modes or functions.
Source	Selects the input source (e.g., HDMI, VGA, S-Video).
Re-SYNC	Resynchronizes the projector's signal.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
Enter	Confirms selections within menus.

Button Name	Function
Keystone	Adjusts the keystone correction to square the image.
Volume	Adjusts the audio output volume.
Brightness	Adjusts the image brightness.
Menu	Opens or closes the projector's on-screen display (OSD) menu.
ZOOM	Adjusts the digital zoom of the projected image.
Numeric Keypad (0-9)	Used for direct input or specific functions as defined by the projector.
HDMI, S-Video, VGA	Directly selects the corresponding input source.
Freeze	Pauses the current projected image.
AV mute	Mutes both audio and video output.
3D	Activates or deactivates 3D mode (if supported by projector).
Page+ / Page-	Navigates through pages in presentations or documents.

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, abrasive cleaners, or solvents.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote control's range decreases or it becomes unresponsive, replace the batteries promptly. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Avoid Drops:** While made of durable ABS material, avoid dropping the remote control as this can damage internal components.

Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote control is unresponsive.	• **Batteries:** Check if batteries are inserted correctly. Replace with new AAA batteries. • **Line of Sight:** Ensure there are no obstructions between the remote and the projector's IR receiver. • **Distance:** Move closer to the projector.
Some buttons do not work.	• **Compatibility:** Verify that the button function is supported by your specific BenQ projector model. • **Dirt/Debris:** Clean the remote control, especially around the unresponsive buttons.

Problem	Possible Cause / Solution
Projector responds intermittently.	• **Low Batteries:** Replace batteries. • **Interference:** Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	UM-4 IECR03
Brand	XINFUTE
Compatible Devices	BenQ Projectors
Material	ABS Material
Color	As Shown (Black)
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 AAA batteries (not included)
Special Feature	Ergonomic design

Warranty and Support

Warranty Information

All purchases of the XINFUTE UM-4 IECR03 Projector Remote Control come with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

Customer Support

If you have any questions, problems, or are not satisfied with your purchase, please contact us directly for assistance. Our goods are inspected before shipment to ensure quality. You can contact us within 24 hours of receipt of your purchase for any issues.
For support, please refer to the contact information provided by your retailer or visit the official XINFUTE store page on Amazon: XINFUTE Store

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTD6VK2W

More documents and user manuals: **https://manuals.plus/**