Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rebecco 05d92bd3-cb47-4ff8-b2c3-480c03ffe40b

Rebecco Android Tablet User Manual

Model: Rebecco RM (05d92bd3-cb47-4ff8-b2c3-480c03ffe40b)

1. Introduction

Welcome to the user manual for your new Rebecco Android Tablet. This 10-inch tablet features the latest Android 14 operating system, an 1.8 GHz octa-core processor, 10(4+6)GB RAM, and 128GB of internal storage, expandable up to 1TB. Designed for seamless multitasking, entertainment, and productivity, it includes Wi-Fi 6G, Bluetooth 5.3, and dual cameras (8MP rear, 5MP front). This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

2. What's in the Box

Upon opening your Rebecco Android Tablet package, you should find the following items:

- 1 x Rebecco Android Tablet
- 1 x Power Adapter
- 1 x USB Cable
- 1 x USB Type-C Data Cable
- 1 x User Manual



Figure 2.1: Rebecco Android Tablet and its standard accessories.

3. Product Overview & Features

The Rebecco Android Tablet is engineered for a responsive and immersive user experience. Key features include:

- **Operating System:** Android 14, offering enhanced privacy controls and optimized performance.
- **Processor:** 1.8 GHz Octa-Core CPU (A523), ensuring smooth operation and efficient multitasking.
- **Display:** 10.1-inch 1280x800 IPS display with Widevine L1 support for high-definition streaming.
- **Memory & Storage:** 10(4+6)GB RAM and 128GB ROM, expandable up to 1TB via TF card (not included).
- **Cameras:** 8MP rear camera and 5MP front camera for photos and video calls.
- **Battery:** Large 6000mAh battery providing up to 6-8 hours of usage.
- **Connectivity:** Dual-band Wi-Fi (2.4GHz/5GHz) with Wi-Fi 6 support and Bluetooth 5.3.



Figure 3.1: Tablet components and ports.



Figure 3.2: Enduring 6000mAh Battery.



Figure 3.3: Widevine L1 Support for HD Streaming.

Your browser does not support the video tag.

Video 3.1: 10 Inch Android 14 Showcase Video - K70. This video highlights the tablet's key features and performance.

4. Setup

Follow these steps to set up your Rebecco Android Tablet for the first time:

1. **Charge the Tablet:** Connect the provided USB Type-C cable to the tablet's USB-C port and the power adapter. Plug the adapter into a wall outlet. Allow the tablet to charge fully before first use.
2. **Power On:** Press and hold the Power ON/OFF button (refer to Figure 3.1) until the Rebecco logo appears on the screen.
3. **Initial Setup Wizard:** Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
4. **Google Account:** Sign in with your Google account or create a new one. This is necessary to download apps from the Google Play Store.
5. **Complete Setup:** Continue following the prompts to set up security features (PIN, pattern, or password) and other preferences.

Your browser does not support the video tag.

Video 4.1: Rebecco Android Tablet Product Descriptions - This video provides a visual guide to unboxing and initial setup.

5. Operating Instructions

Your Rebecco tablet runs on Android 14, offering an intuitive and customizable experience.

5.1 Basic Navigation

- **Home Screen:** Swipe left or right to navigate between home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and access quick settings toggles (Wi-Fi, Bluetooth, etc.).
- **Multitasking:** Tap the square navigation button (or swipe up and hold from the bottom) to view recently opened apps.

5.2 App Management

- **Installing Apps:** Open the "Play Store" app to browse and download applications.

- **App Permissions:** Android 14 emphasizes privacy. You can manage app permissions (e.g., access to camera, microphone, location) in Settings > Apps > [App Name] > Permissions.

5.3 Camera Usage

The tablet features an 8MP rear camera and a 5MP front camera. Open the "Camera" app to capture photos and videos. You can switch between front and rear cameras, and adjust settings within the app.



Figure 5.1: Tablet Dual Cameras.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your tablet.

6.1 Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- For optimal battery health, avoid frequently draining the battery completely or keeping it at 100% charge for extended periods.

- Use only the provided charger and cable.

6.2 Storage Management

Your tablet comes with 128GB of internal storage. If you need more space, you can expand it up to 1TB using a microSD card (not included). Regularly clear unnecessary files and uninstall unused apps to maintain performance.



Figure 6.1: Storage and Expansion Capabilities.

7. Troubleshooting

If you encounter issues with your tablet, try the following common solutions:

Problem	Possible Cause	Solution
Tablet won't turn on	Low battery; System crash	Charge the tablet for at least 30 minutes. Press and hold the power button for 10-15 seconds to force restart.
Apps freezing or crashing	Insufficient RAM; App bug	Close background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the tablet.
Wi-Fi connection issues	Incorrect password; Router issue; Tablet Wi-Fi disabled	Ensure Wi-Fi is enabled. Re-enter Wi-Fi password. Restart your Wi-Fi router.
Slow performance	Too many apps; Low storage	Uninstall unused apps. Clear cache and data for frequently used apps. Consider adding a microSD card for more storage.

If these solutions do not resolve your issue, please refer to the Warranty and Support section for further assistance.

8. Specifications

Detailed technical specifications for your Rebecco Android Tablet:

Feature	Specification
Brand	Rebecco

Feature	Specification
Model Name	Rebecco RM
Operating System	Android 14
Screen Size	10.1 inches
Screen Resolution	1280 x 800 pixels (IPS)
Processor	1.8 GHz Octa-Core (Qualcomm)
RAM	10(4+6)GB
Internal Storage	128GB
Expandable Storage	Up to 1TB (MicroSD card)
Rear Camera	8MP
Front Camera	5MP
Battery Capacity	6000mAh
Wireless Type	802.11ac (Wi-Fi 6G)
Bluetooth	5.3
Dimensions (LxWxH)	9 x 6 x 0.2 inches
Item Weight	2.55 pounds

9. Warranty and Support

Rebecco offers a **one-year warranty** for your tablet, covering manufacturing defects. Additionally, a **30-day return policy** is available to ensure your satisfaction.
For product support, questions, or warranty claims, please contact Rebecco customer service. You can typically find contact information through your purchase platform or by visiting the official Rebecco store page on Amazon. Most questions will be answered within 24 hours to ensure a good product experience.
To contact support:

- Find your order on Amazon and click "Get Product Support."
- Visit the Rebecco Store on Amazon for more information and contact options.

© 2024 Rebecco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTHSQLJQ

More documents and user manuals: **https://manuals.plus/**