Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON B0DTP5XXN9

GAOMON White 6-Drawer Dresser with LED Light and Charging Station

Model: B0DTP5XXN9

Instruction Manual

1. Introduction

Thank you for choosing the GAOMON White 6-Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. Safety Information

To ensure safe use and prevent injury or damage, please observe the following:

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Anti-Tip Device:** It is crucial to install the included anti-tip device to prevent the dresser from tipping over, especially in households with children. Securely fasten the dresser to the wall as instructed.
- Do not overload drawers. Distribute weight evenly.
- Keep small parts and packaging materials away from children during assembly.



Image: Proper installation of the anti-tip device is essential for stability and safety, preventing accidental tipping.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer service immediately.

- 1 x GAOMON 6-Drawer Dresser (unassembled components)
- 1 x Hardware Pack (containing screws, dowels, and other fasteners)
- 1 x Installation Manual (with clear diagrams and numbered accessories)
- 1 x Anti-Tip Tool Kit

4. Setup and Assembly

Assembly of the GAOMON dresser requires following the detailed instructions provided in the included installation manual. All parts are numbered, and diagrams illustrate each step. It is recommended to have two people for

assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to avoid scratches.
2. **Identify Parts:** Match each component with its corresponding number in the installation manual.
3. **Follow Step-by-Step Instructions:** Assemble the dresser frame, then install the drawer slides and construct the drawers.
4. **Install Anti-Tip Device:** Securely attach the anti-tip device to the dresser and the wall as per the manual's instructions. This step is critical for safety.
5. **Connect Power Outlet and LED Light:** Follow the specific instructions for connecting the built-in power outlet and LED light bar.



Image: Product dimensions for the GAOMON 6-drawer dresser, including overall size and individual drawer measurements.



Image: Key features of the dresser, including sturdy wood legs, smooth drawer slides, integrated power outlets, and the double handle design.

5. Operating Instructions

5.1 LED Light Bar

The dresser features a multi-color LED light bar with various customization options:

- **Control:** The LED light bar can be controlled via an app or key control.
- **Color Options:** Choose from 16 static color options.
- **Dynamic Modes:** Access 21 dynamic modes for varied lighting effects.
- **Music Sync:** The lights can sync with music via microphone or music input.
- **Timing Function:** Set timers for the lights to turn on or off automatically.



Image: The adjustable RGB light strips offer various control methods and color/mode options to enhance room ambiance.

5.2 Built-in Power Outlet

The dresser includes a built-in charging station on the tabletop for convenient power access:

- **Outlets:** Features 2 AC outlets (125V/12A).
- **USB Ports:** Includes 2 USB ports (5V/2A).
- **Power Cord:** Equipped with a 6.56-foot power cord for flexible placement.
- **Usage:** Plug in electronic devices such as lamps, phone chargers, or other small appliances.



Image: The integrated charging station provides convenient access to power with AC outlets and USB ports.

5.3 Storage and Display

Utilize the six spacious drawers and the open top shelf for organizing and displaying items:

- **Drawers:** Each drawer measures approximately 26.5" L x 13.4" D x 6.7" H and can support up to 22 pounds. Ideal for clothes, blankets, and personal items.
- **Top Shelf:** The open top shelf and large tabletop provide space for decorative items, lamps, books, or a television.



Image: The dresser offers large capacity storage with six spacious drawers for organizing various items.



Image: The dresser's design allows for placement of a television and display of decorative items on its top surface and open shelves.

6. Maintenance

Proper care will extend the life and appearance of your dresser:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood warping or cracking.
- **Hardware:** Periodically check and tighten all hardware to ensure stability.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common solutions:

- **Wobbly Dresser:** Ensure all screws are tightened. Check that the dresser is on a level surface. Adjust leg levelers if applicable.
- **Drawers Not Sliding Smoothly:** Check that drawer slides are correctly installed and free of obstructions. Apply a silicone-based lubricant if necessary.
- **LED Lights Not Working:** Verify that the power cord is securely plugged into a working outlet. Check connections for the LED light bar. Refer to the LED light bar's specific instructions for troubleshooting.
- **Power Outlets Not Functioning:** Ensure the dresser's main power cord is plugged into a live wall outlet. Test the wall outlet with another device. Check for any tripped circuit breakers.
- **Missing or Damaged Parts:** Do not attempt to force assembly with incorrect or damaged parts. Contact customer service for replacements.

8. Specifications

Feature	Detail
Brand	GAOMON
Model Name	White 6-Drawer Dresser (B0DTP5XXN9)
Material	Wood (MDF)
Finish Type	Painted
Product Dimensions (D x W x H)	15.6"D x 55.1"W x 32.2"H
Number of Drawers	6
Drawer Dimensions (L x D x H)	26.5" x 13.4" x 6.7" (approximate)
Drawer Weight Capacity	Up to 22 pounds per drawer
Item Weight	125.66 Pounds
Mounting Type	Floor Mount (with anti-tip device)
LED Light Features	16 colors, 21 dynamic modes, App/Key control, Music Sync, Timing Function
Power Outlet	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Power Cord Length	6.56 feet
Required Assembly	Yes
UPC	199108624215

9. Customer Service and Support

GAOMON is committed to providing high-quality products and excellent customer service. If you have any questions, concerns, or require assistance with assembly, missing parts, or product issues, please do not hesitate to contact our customer service team.

- Our responsive customer service team is available 24/7 to provide prompt assistance and satisfactory solutions.

- Please have your model number (B0DTP5XXN9) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTP5XXN9

More documents and user manuals: **https://manuals.plus/**