EUROSTAR TO902W

EUROSTAR TO902W 4-Slice Toaster Oven Broiler

User Manual

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the toaster oven.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause hazards.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. Product Overview

The EUROSTAR TO902W is a versatile 4-slice toaster oven broiler designed for efficient and convenient cooking. It offers multiple functions and user-friendly features to enhance your kitchen experience.

Key Features:

- **3 Functions:** Bake, Broil, and Toast for diverse cooking needs.
- **Adjustable Temperature Control:** Set temperatures up to 465 degrees Fahrenheit.
- **60-Minute Cooking Timer:** Features a convenient timer with a 'stay-on' function for longer cooking tasks.
- **Slide-Open Crumb Tray:** Designed for easy removal and cleaning of crumbs.
- **Includes Baking Tray & Grill Rack:** Comes with essential accessories to get you started.
- **Power Indicator Light:** Illuminates when the oven is in operation.
- **Cool-Touch Handle:** Ensures safe opening and closing of the door during use.
- **Clear-View Glass Door:** Allows you to monitor your food without opening the door.

Components:



Figure 1: Front view of the EUROSTAR TO902W Toaster Oven with labeled features including the cool-touch handle, clear-view glass door, adjustable temperature control, 60-minute timer, power indicator light, slide-open crumb tray, baking tray, and grill rack.

- **Temperature Control Dial:** Adjusts the cooking temperature.
- **Function Selector Dial:** Choose between Bake, Broil, or Toast.
- **Timer Dial:** Sets the cooking duration up to 60 minutes or to 'Stay On'.
- **Power Indicator Light:** Red light indicating the unit is on.
- **Oven Door:** Clear glass door with a cool-touch handle.
- **Grill Rack:** For toasting and broiling.
- **Baking Tray:** For baking and collecting drips.
- **Crumb Tray:** Located at the bottom for easy cleaning.

3. Setup

1. **Unpacking:** Carefully remove the toaster oven and all accessories from the packaging. Remove any protective films or packing materials.
2. **Initial Cleaning:** Before first use, wipe the interior and exterior of the toaster oven with a damp cloth. Wash the baking tray, grill rack, and crumb tray in warm, soapy water. Rinse and dry thoroughly.
3. **Placement:** Place the toaster oven on a stable, level, heat-resistant surface. Ensure there is adequate clearance (at

least 4 inches) on all sides and above the appliance for proper ventilation. Do not place it near flammable materials.

4. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

4. Operating Instructions

Familiarize yourself with the controls before operating the appliance.

Control Dials:

- **Temperature Dial:** Located at the top, this dial allows you to select the desired cooking temperature from 'Warm' up to 465°F.
- **Function Dial:** The middle dial selects the cooking mode: 'Bake', 'Broil', or 'Toast'.
- **Timer Dial:** The bottom dial sets the cooking time up to 60 minutes. For continuous operation, turn the dial counter-clockwise past the 'Off' position to the 'Stay On' setting.

General Operation:

1. Place food on the baking tray or grill rack. Insert the tray/rack into the desired slot inside the oven.
2. Close the oven door using the cool-touch handle.
3. Set the **Temperature Dial** to the desired temperature.
4. Select the desired function ('Bake', 'Broil', or 'Toast') using the **Function Dial**.
5. Set the **Timer Dial** to the desired cooking time. The power indicator light will illuminate, indicating the oven is on.
6. Monitor food through the clear-view glass door.
7. When the timer reaches 'Off', a bell will sound, and the oven will turn off. If using 'Stay On', manually turn the timer dial to 'Off' when cooking is complete.
8. Carefully remove food using oven mitts.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster oven.

Before Cleaning:

- Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.

Cleaning the Interior:

- Wipe the interior walls with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
- For stubborn stains, a non-abrasive liquid cleaner can be used.

Cleaning Accessories:

- **Baking Tray & Grill Rack:** Wash in warm, soapy water. Rinse thoroughly and dry. These are not dishwasher safe.
- **Slide-Open Crumb Tray:** Pull out the crumb tray from the bottom of the oven. Discard crumbs. Wash in warm, soapy water, rinse, and dry thoroughly before reinserting.

Cleaning the Exterior:

- Wipe the exterior surfaces with a damp cloth and mild detergent. Dry thoroughly.
- Do not use abrasive cleaners or metal scouring pads, as they may scratch the surface.

6. Troubleshooting

If you encounter issues with your toaster oven, please refer to the following common problems and solutions:

- **Appliance does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the timer dial is set to a cooking time or 'Stay On'. The oven will not operate if the timer is set to 'Off'.
- **Food not cooking evenly:**
  - Ensure the correct temperature and function settings are selected for your food.
  - Preheat the oven for a few minutes before placing food inside.
  - Rotate the food halfway through the cooking cycle if necessary.
- **Excessive smoke:**
  - This may occur during initial use due to protective coatings burning off. This is normal and should subside quickly.
  - Ensure the crumb tray and interior are clean and free of food debris or grease buildup.

If the problem persists, please contact customer support.

7. Specifications

Specification	Detail
Product Dimensions	11.65 x 13.19 x 8.31 inches
Item Weight	9 pounds
Manufacturer	EUROSTAR
ASIN	B0DTQMDV8C
Item Model Number	TO
Date First Available	January 22, 2025

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product or contact EUROSTAR customer service directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question