Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Morphy Richards 510067

Morphy Richards Crisp Pro 5L Digital Air Fryer

Model: 510067

User Manual

1. Introduction

Thank you for choosing the Morphy Richards Crisp Pro 5L Digital Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, using rapid air circulation technology to fry, roast, bake, and grill with little to no oil. Please read this manual carefully before first use and keep it for future reference.



Image 1.1: The Morphy Richards Crisp Pro 5L Digital Air Fryer, showcasing its sleek design and a plate of crispy fries, highlighting its healthy cooking capabilities.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric

shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

3. Product Overview & Components

Familiarize yourself with the parts of your Morphy Richards Crisp Pro Digital Air Fryer.



Image 3.1: The main unit of the air fryer with its removable non-stick basket, illustrating the primary components for cooking.

Included Components:

- Main Air Fryer Unit
- Non-Stick Fry Tray / Basket
- Instruction Manual (this document)
- Warranty Card

4. Before First Use (Setup)

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean:** Wash the non-stick basket and fry tray with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4

inches) of free space on the back and sides, and 10 cm (4 inches) above the appliance.

4. **Initial Run (Optional but Recommended):** To eliminate any manufacturing odors, plug in the air fryer and run it empty for about 10-15 minutes at 180°C (350°F). A slight odor may be present, which is normal. Allow to cool completely afterward.

5. Operating Instructions

5.1 Control Panel Overview



Image 5.1: The digital touch control panel, featuring icons for various preset menus, temperature, and timer adjustments.

The Morphy Richards Crisp Pro features an easy-to-use digital touch interface. The display shows temperature and time, with intuitive icons for preset menus and manual adjustments.

5.2 Basic Operation

1. **Plug In:** Connect the power cord to a grounded wall outlet. The appliance will beep, and the display will light up briefly.
2. **Prepare Food:** Place your ingredients into the non-stick basket. Do not overfill the basket.
3. **Insert Basket:** Slide the basket back into the air fryer until it clicks into place.
4. **Power On:** Press the Power button to turn on the display.
5. **Select Cooking Method:**
    - **Using Preset Menus:** Press the Menu button repeatedly to cycle through the 8 preset options (e.g., fries, chicken, fish). The corresponding icon will light up, and the default time and temperature will be displayed.
    - **Manual Setting:** Alternatively, use the temperature (°C) and time (min) icons, along with the '+' and '-' buttons, to set your desired cooking temperature and time manually.
6. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle. The fan and heating element will activate.
7. **Shake/Flip (Optional):** For even cooking, some recipes require shaking or flipping ingredients halfway through. The air fryer may beep to remind you. Carefully remove the basket using the cool-touch handle, shake/flip, and reinsert.
8. **Cooking Continuity Function:** If you remove the basket during cooking, the air fryer will pause automatically and resume once the basket is reinserted.
9. **Finish:** Once the timer reaches zero, the air fryer will beep, and the heating element will turn off. Carefully pull out the basket and transfer food to a serving plate.



Image 5.2: An illustrative diagram highlighting the air fryer's core functionalities: 8 preset menus, adjustable time and temperature, dual fan technology for even cooking, and the cooking continuity feature.

5.3 Healthy Cooking Benefits

The Morphy Richards Crisp Pro utilizes Dual Fan Technology for efficient air circulation, allowing you to achieve crispy results with significantly less oil.



Image 5.3: A visual representation of air-fried dishes, illustrating the health benefits of using the air fryer, such as reduced fat and improved protein retention.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Basket and Tray:** The non-stick basket and fry tray are **not** dishwasher safe. Wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak them in hot water for about 10 minutes.
3. **Clean Interior:** Wipe the inside of the appliance with a damp cloth and mild detergent. Do not use abrasive cleaners or steel wool.
4. **Clean Exterior:** Wipe the exterior with a damp cloth.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Power outlet not working.	Ensure the power cord is securely plugged into a working outlet.
Food is not cooked evenly.	Basket is overfilled; Food not shaken/flipped.	Do not overfill the basket. Shake or flip ingredients halfway through cooking.
White smoke comes from the appliance.	Grease from previous use; Fatty ingredients.	Clean the basket and fry tray thoroughly after each use. For fatty foods, drain excess oil.

Problem	Possible Cause	Solution
Food is not crispy.	Too much moisture in food; Not enough oil (for some foods).	Pat food dry before air frying. Lightly brush or spray some oil on foods that typically require it for crispiness.

8. Specifications

Feature	Specification
Model Name	Crisp Pro Digital
Model Number	510067
Capacity	5 Liters
Output Wattage	1500 Watts
Control Method	Touch
Air Frying Technology	Dual Fan Technology
Product Dimensions (D x W x H)	36D x 37.6W x 36H Centimeters
Item Weight	4300 Grams
Material	Acrylonitrile Butadiene Styrene (ABS)
Inner Material	Plastic (with non-stick coating)
Dishwasher Safe	No
Special Features	8 Preset Menu Options, Adjustable Temperature Control, Dual Fan Technology, Non-Stick Removable Basket, Smart Digital Touch Interface

9. Warranty and Customer Support

Your Morphy Richards Crisp Pro 5L Digital Air Fryer (Model 510067) comes with a**2-Year Warranty** from the date of purchase. Please retain your purchase receipt for warranty claims.
For any product-related queries, service requests, or warranty claims, please contact:

- **Manufacturer/Importer:** M/S. BAJAJ ELECTRICALS LIMITED
- **Address:** # 45/47 VEER NARIMAN ROAD, MUMBAI-400 001, MAHARASHTRA
- Please refer to the warranty card included with your product for specific contact details and terms and conditions.

© 2025 Morphy Richards. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DTTZ7KSZ

More documents and user manuals: **https://manuals.plus/**