Calvin Klein CK Meridian 25100091

Calvin Klein Women's CK Meridian 22mm Quartz Slim Watch Instruction Manual

Model: 25100091

Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your Calvin Klein Women's CK Meridian 22mm Quartz Slim Watch. Please read this guide thoroughly to ensure optimal performance and longevity of your timepiece.

Setup

Setting the Time

To set the time, gently pull the crown (the small knob on the side of the watch case) outwards to the time-setting position. Rotate the crown clockwise or counter-clockwise until the hands indicate the correct time. Once set, push the crown back into its original position to engage the movement and start the watch.

Adjusting the Bracelet

The stainless steel bracelet is designed for a comfortable fit. If adjustment is needed, it is recommended to visit an authorized Calvin Klein service center or a professional jeweler. They can safely add or remove links to achieve the perfect fit without damaging the watch.

The Calvin Klein CK Meridian watch as it appears in its packaging, alongside the instruction booklet. This image shows the initial presentation of the product.





Front view of the Calvin Klein CK Meridian 22mm Quartz Slim Watch with a black dial and black stainless steel bracelet. The crown for time adjustment is visible on the right side of the case.

Operating

Reading the Time

Your CK Meridian watch features a minimalist analog display with two hands (hour and minute). The longer hand indicates minutes, and the shorter hand indicates hours.

Quartz Movement

This watch is equipped with a precise quartz movement, which provides accurate timekeeping with minimal maintenance. The movement is powered by a battery.

Maintenance

General Care and Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

Water Resistance

The watch is water resistant up to 30 meters (3 ATM / 100 feet). This means it is suitable for splashes or brief immersion in water, such as washing hands or light rain. It is **not** suitable for swimming, showering, diving, or any water sports. Ensure the crown is fully pushed in before any contact with water.

Battery Replacement

A maintenance interval of 3 to 5 years is recommended, in addition to any required battery replacement. Battery replacement should only be performed by an authorized Calvin Klein service center or a qualified watch technician to prevent damage to the movement and maintain water resistance. **Never** attempt to open the watch yourself.





The Calvin Klein CK Meridian watch worn on a wrist, demonstrating its fit and aesthetic. This view highlights the bracelet design and how the watch sits on the wearer.

Troubleshooting

Watch Not Running

- Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
- If the watch stops running and the crown is in the correct position, the battery may need replacement. Refer to the "Battery Replacement" section.

Time Inaccuracy

- Quartz watches are highly accurate. If you notice significant time inaccuracy, it may indicate a low battery or a need for service.

Specifications

Technical Specifications

Feature	Detail
Display	Analog
Watch Movement Type	Quartz

Feature	Detail
Strap Type	Bracelet
Water Resistance Depth	30 Meters
Clasp Type	JEWELRY BUCKLE
Water Resistance Level	Water Resistant
Shape	Square
Band Color	Black
Dial Color	Black
Face Style	Minimalist
Brand Name	Calvin Klein
Model Name	CK Meridian
Model Number	25100091
Item Weight	78 Grams
Band Material Type	Stainless Steel
Case Material Type	IONIC PLATED BLACK STEEL
Crystal	Mineral
Case Diameter	22 Millimeters
Band Width	7.25 Millimeters
Case Thickness	6.1 Millimeters



Rear view of the Calvin Klein CK Meridian watch, showing the stainless steel case back with engraved details such as the Calvin Klein logo, model information, and water resistance rating.

Warranty

Limited Warranty

Your Calvin Klein watch is covered by a limited warranty. For specific terms and conditions, please refer to the warranty card included with your purchase or visit the official Calvin Klein website. The warranty typically covers manufacturing defects but does not cover damage resulting from improper use, accidents, or unauthorized repairs.



The Calvin Klein CK Meridian watch box open, revealing the watch and the Calvin Klein Watches warranty and instruction booklet. This image highlights the included documentation.

Support

Customer Support

For any questions, service requests, or further assistance with your Calvin Klein watch, please contact an authorized Calvin Klein service center. You can find contact information and service locations on the official Calvin Klein website: www.calvinklein.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question