Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ymiko Ymikoah21utk3pv-13

Ymiko Portable High Temperature Steam Cleaner User Manual

Model: Ymikoah21utk3pv-13

Important Safety Instructions

Please read all safety warnings and instructions carefully before using this appliance to avoid injury or damage.

- **High Temperature Steam:** The steam produced by this cleaner is extremely hot (100°C). Avoid direct contact with skin or eyes to prevent severe burns.
- **Electrical Safety:** This is an electrical appliance. Do not immerse the unit in water or other liquids. Ensure your power outlet matches the specified voltage (110V US Plug). Unplug the unit from the power source before filling, cleaning, or performing maintenance.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Do not allow them to operate or play near the steam cleaner.
- **Water Tank:** Never open the water tank cap while the unit is pressurized or hot. Allow the unit to cool down completely and release any residual pressure before opening.
- **Water Quality:** Use only clean tap water in the water tank. Do not add detergents, chemicals, or aromatic oils, as this can damage the appliance and create hazardous fumes.
- **Ventilation:** Use the steam cleaner in a well-ventilated area.
- **Intended Use:** Use this appliance only for its intended purpose as described in this manual.

Product Overview

The Ymiko Portable High Temperature Steam Cleaner is designed for effective and chemical-free cleaning across various surfaces in your home. Its compact design and smart touch screen control make it a versatile tool for tackling grease and

dirt.

Package Contents

- 1 x High Temperature Steam Cleaner Unit
- 2 x Gasket
- 1 x Rinse Head
- 1 x Large Nylon Brush
- 1 x Brass Brush
- 1 x Small Nylon Brush
- 1 x Supply Cord
- 1 x Extension Pole
- 1 x Towel Cover
- 1 x Glass Scraper
- 1 x User Manual
- 1 x Silicone Tape



Image: All accessories included with the Ymiko Portable High Temperature Steam Cleaner.

Product Features

- **Chemical-Free Cleaning:** Effectively removes grease and dirt without harmful fumes.
- **Compact Design:** Easy to store with an ergonomic handle for comfortable use.
- **Multi-purpose Use:** Suitable for various surfaces including stovetops, walls, microwaves, bathrooms, floors, tiles, and more.
- **Smart Touch Screen Control:** Easily adjust steam output with 6 settings.
- **Versatile Cleaning:** Comes with 3 different brush heads for various cleaning tasks.



Image: The Ymiko Portable High Temperature Steam Cleaner, showing the main unit connected to the steam nozzle via a flexible hose.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Ensure all listed package contents are present and undamaged.
3. **Position:** Place the steam cleaner on a stable, flat, and heat-resistant surface.
4. **Fill Water Tank:** Open the water tank cap and fill the 1200ml tank with clean tap water. Do not overfill. Securely close the cap.
5. **Attach Accessories:** Select the appropriate cleaning head or nozzle for your task. Before connecting the spray copper head to the steam head or the extended nozzle, add a water ring to ensure a secure, leak-free connection. Twist firmly to attach.
6. **Connect Power:** Plug the supply cord into the power input on the unit, then plug the other end into a standard 110V US electrical outlet.



Image: Rear view of the steam cleaner, highlighting the power input port and the carrying handle.

Operating Instructions

General Operation

1. **Power On:** After setup, press the power button on the unit or nozzle to turn on the steam cleaner.
2. **Heat Up:** Allow the unit a few minutes to heat the water and generate steam. The steam temperature will reach 100°C.
3. **Steam Output Adjustment:** Use the touch screen controls to select one of the 6 available steam output levels. Start with a lower setting and increase as needed for your cleaning task.
4. **Apply Steam:** Direct the steam nozzle towards the surface to be cleaned. Hold the nozzle a few inches away from the surface and move it steadily. For best results, use short bursts of steam.
5. **Wipe Clean:** After steaming, wipe the treated surface with a clean cloth to remove loosened dirt and moisture.

Using Different Brush Heads

- **Large Nylon Brush:** Ideal for general scrubbing on larger, durable surfaces like floors, tiles, and stovetops.
- **Small Nylon Brush:** Suitable for delicate surfaces or smaller areas, such as grout lines, fixtures, and intricate details.
- **Brass Brush:** Designed for heavy-duty scrubbing on very stubborn dirt, grease, and grime on robust surfaces like BBQ grills or oven racks. Use with caution on softer surfaces to avoid scratching.
- **Glass Scraper:** Use for streak-free cleaning of windows, mirrors, and other glass surfaces.
- **Extension Pole:** Attach for extended reach, useful for cleaning high walls, ceilings, or floors without bending.

Touch Screen Control

The integrated touch screen allows for easy adjustment of steam output. The '+' and '-' buttons increase or decrease the steam intensity, providing precise control for various cleaning needs. The power button controls the unit's on/off state.





Image: Close-up of the steam nozzle handle with the power and steam level adjustment buttons clearly visible.



Image: Top view of the main unit, showcasing the touch screen control panel for steam settings.

Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your steam cleaner.

1. **Power Off and Unplug:** Always turn off the appliance and unplug it from the power outlet immediately after use.
2. **Cool Down:** Allow the steam cleaner to cool down completely before handling or performing any maintenance.
3. **Drain Water Tank:** Once cooled, carefully open the water tank cap and drain any remaining water.
4. **Clean Exterior:** Wipe the exterior surfaces of the main unit and accessories with a soft, damp cloth. Do not use abrasive cleaners or solvents.

5. **Clean Nozzles/Brushes:** Remove any debris or residue from the cleaning nozzles and brush heads. Rinse them with water if necessary and allow them to air dry.
6. **Descaling (Periodically):** Depending on water hardness, mineral deposits may build up. Consult the manufacturer's website or contact support for recommended descaling procedures if steam output decreases significantly.
7. **Storage:** Store the steam cleaner and its accessories in a dry, cool place, away from direct sunlight and out of reach of children.

Troubleshooting

If you encounter issues with your steam cleaner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
No steam or very little steam	• Water tank is empty or low. • Unit has not heated up sufficiently. • Nozzle/hose is blocked.	• Refill water tank. • Allow 3-5 minutes for heating. • Check for blockages and clean if necessary.
Unit not turning on	• Power cord not properly connected. • Power outlet is faulty.	• Ensure power cord is securely plugged into both the unit and the wall outlet. • Test the outlet with another appliance.
Water leaking from connections	• Accessories not securely attached. • Gasket missing or damaged.	• Ensure all attachments are firmly twisted into place. • Check if the water ring/gasket is properly installed and undamaged. Replace if necessary.
Steam pressure is weak	• Mineral buildup (limescale). • Water tank low.	• Perform descaling procedure (refer to manufacturer guidelines). • Refill water tank.

Specifications

Feature	Specification
Model Number	Ymikoah21utk3pv-13
Water Tank Capacity	1200 ml
Power	1500 W
Adjustable Settings	6 levels (steam output)
Pressure	3.5 BAR
Steam Temperature	100°C (212°F)
Power Cord Length	1.5 m
Steam Hose Length	2 m
Voltage	110V (US Plug)
Dimensions (L*W*H)	28cm * 18cm * 17cm
ASIN	B0DV537RPH

Warranty Information

This Ymiko Portable High Temperature Steam Cleaner is covered by a standard manufacturer's warranty. For specific details regarding warranty duration, coverage, and claims process, please refer to the warranty card included with your product packaging or visit the official Ymiko website.

Customer Support

For further assistance, product inquiries, or technical support, please contact Ymiko customer service. You can often find support information and FAQs on the brand's official Amazon store page:

Visit the Ymiko Store on Amazon

© 2023 Ymiko. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DV537RPH

More documents and user manuals: **https://manuals.plus/**