Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GreenLife CC009979-001

GreenLife 8QT Ceramic Nonstick Slow Cooker User Manual

Model: CC009979-001

1. Introduction

Thank you for choosing the GreenLife 8QT Ceramic Nonstick Slow Cooker. This appliance is designed to simplify your cooking process, allowing you to prepare delicious meals with minimal effort. Its versatile design includes a removable pot that is safe for use on cooktops and in ovens, offering flexibility for searing, sautéing, and browning ingredients before slow cooking. The healthy ceramic nonstick coating ensures easy food release and cleanup. Please read this manual thoroughly before first use to ensure safe and optimal operation of your slow cooker.



Image 1.1: Front view of the GreenLife 8QT Ceramic Nonstick Slow Cooker.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the slow cooker.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the base unit, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “OFF”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Avoid sudden temperature changes, such as adding cold food to a hot pot.
- The removable pot is oven safe up to 400°F (204°C) and stovetop safe. Do not place the base unit in an oven or on a stovetop.

3. Product Components

Your GreenLife Slow Cooker consists of the following main components:

- **Base Unit:** Houses the heating element and control panel.
- **Removable Inner Pot:** The ceramic nonstick cooking vessel. This pot is PFAS-free, stovetop, and oven safe.
- **Tempered Glass Lid:** Allows you to monitor cooking progress without releasing heat.



Image 3.1: The PFAS-free ceramic nonstick removable inner pot.



Image 3.2: The clear tempered glass lid.

4. Setup and First Use

4.1 Unpacking

1. Carefully remove all packaging materials and any labels from the slow cooker.
2. Retain packaging for future storage or disposal.

4.2 Cleaning Before First Use

1. Wash the removable inner pot and glass lid in warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the exterior of the base unit with a damp cloth. Do not immerse the base unit in water or any other liquid.

4.3 Assembly

1. Place the base unit on a flat, stable, heat-resistant surface, away from walls or cabinets to allow for proper ventilation.
2. Insert the clean, dry removable inner pot into the base unit.

3. Place the glass lid on top of the inner pot.

5. Operating Instructions

The GreenLife Slow Cooker features an easy-to-use control panel for various cooking functions.



Image 5.1: Close-up of the control panel with Delay Timer, Keep Warm, Mode, and On/Off dial.

5.1 Control Panel Functions

- **On/Off Dial:** Turn to power the unit on and off.
- **Mode Button:** Cycles through cooking temperature settings: LOW, MEDIUM, HIGH.
- **Delay Timer Button:** Sets a delay before cooking begins.
- **Keep Warm Button:** Activates the keep warm function after cooking is complete.
- **Digital Display:** Shows cooking time, delay time, and current mode.

5.2 Basic Operation

1. Prepare your ingredients and place them into the removable inner pot. Cover with the glass lid.

2. Plug the slow cooker into a standard electrical outlet. The display will illuminate.
3. Turn the On/Off dial to the 'On' position.
4. Press the **Mode** button repeatedly to select your desired cooking temperature (LOW, MEDIUM, or HIGH).
5. Use the dial to set the cooking time. The cooking time can be set from 30 minutes to 20 hours.
6. The slow cooker will begin cooking after a few seconds. The display will count down the remaining cooking time.

5.3 Delay Timer Function

The Delay Timer allows you to set a time for the slow cooker to start cooking later.

1. After setting the cooking mode and time (as per steps 1-5 in Basic Operation), press the **Delay Timer** button.
2. Use the dial to set the desired delay time (up to 10 hours).
3. The display will count down the delay time. Once the delay time reaches zero, the slow cooker will automatically begin cooking according to your set mode and cooking time.

5.4 Keep Warm Function

Once the cooking cycle is complete, the slow cooker will automatically switch to the Keep Warm function for up to 4 hours.



Image 5.2: The slow cooker maintaining food temperature with the Keep Warm function.

- You can also manually activate the **Keep Warm** function by pressing the button after cooking or if you wish to keep food warm without cooking.
- The display will show

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question