Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Majority Naga 60

Majority Naga 60 Soundbar User Manual

Model: Naga 60

Important Safety Information

Please read this manual carefully before using your Majority Naga 60 Soundbar. Keep these instructions for future reference. Follow all warnings and instructions provided with the product.

- Do not expose this appliance to dripping or splashing liquids.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this appliance during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

What's in the Box

Carefully unpack your Majority Naga 60 Soundbar and ensure all items are present. If any items are missing or damaged, please contact customer support.

- 1 x Majority Naga 60 Soundbar
- 1 x Remote Control (with batteries)
- 1 x Power Adapter
- 1 x HDMI Cable
- 1 x AUX to RCA Cable
- 1 x Wall Mount Kit (brackets and fixings)
- 1 x User Manual (this document)



Image: All components included in the Majority Naga 60 Soundbar package, laid out clearly. This includes the soundbar unit, a black remote control, a power adapter, an HDMI cable, an AUX to RCA cable, and a set of wall mounting brackets and screws.

Product Overview

Soundbar Controls

The soundbar features intuitive controls located on the top panel for easy access to essential functions.

- **Power Button:** Turns the soundbar on or off.
- **Volume Up/Down:** Adjusts the sound level.
- **Input/Source Button:** Cycles through available input sources (HDMI ARC, Optical, AUX, Bluetooth, USB).
- **Play/Pause:** Controls media playback in Bluetooth or USB mode.



Image: A close-up view of the top surface of the Majority Naga 60 Soundbar, highlighting the control buttons. The remote control is also visible next to the soundbar.

Rear Panel Connections

The rear panel provides various ports for connecting your soundbar to different audio sources.

- **AUX IN:** For connecting devices via a 3.5mm audio cable.
- **USB:** For playing audio files from a USB drive.
- **SW. OUTPUT (MAX 1.2V):** Output for an external subwoofer (not included).
- **ARC (HDMI ARC):** For connecting to a TV's HDMI ARC port, allowing TV remote control of the soundbar.
- **OPTICAL IN:** For connecting to devices with an optical audio output.
- **DC 24V:** Power input for the included power adapter.



Image: A detailed view of the rear connection panel of the Majority Naga 60 Soundbar. Clearly visible ports include AUX IN, USB, SW. OUTPUT, HDMI ARC, OPTICAL IN, and DC 24V power input.

Setup

Placement Options

The Naga 60 Soundbar offers flexible placement options to suit your home entertainment setup.

- **Tabletop Placement:** Place the soundbar on a flat, stable surface directly in front of your TV. Ensure there are no obstructions in front of the speakers.
- **Wall Mounting:** Use the included wall mount kit to attach the soundbar to the wall below your TV. Refer to the wall mounting instructions provided with the kit for detailed steps.



Image: A black metal wall mounting bracket, designed for securing the soundbar to a wall. The bracket shows screw holes for attachment.

Connecting to Your TV or Audio Source

Choose the appropriate connection method based on your TV or audio device's available ports.

HDMI ARC Connection (Recommended)

1. Connect one end of the supplied HDMI cable to the **ARC** port on the soundbar.
2. Connect the other end to the **HDMI ARC** port on your TV.
3. Ensure your TV's HDMI ARC function is enabled in its settings. This allows your TV remote to control the soundbar's volume.

Optical Connection

1. Connect an optical cable (not included) from the **OPTICAL IN** port on the soundbar to the optical output port on your TV or audio device.
2. Ensure your TV's audio output is set to "PCM" or "Stereo" for optical connection.

AUX Connection

1. Connect the supplied AUX to RCA cable from the **AUX IN** port on the soundbar to the 3.5mm headphone jack or RCA audio output on your device.

Power Connection

1. Connect the power adapter to the **DC 24V** port on the soundbar.
2. Plug the power adapter into a wall socket.

Operating Instructions

Power On/Off

Press the **Power** button on the soundbar or remote control to turn the unit on or off.

Selecting Input Source

Press the **Input/Source** button on the soundbar or the corresponding source button (HDMI, OPT, AUX, BT, USB) on the remote control to switch between input modes.

Volume Control

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the soundbar or remote control to adjust the volume level.

Bluetooth Pairing

1. Turn on the soundbar and select **Bluetooth (BT)** mode using the Input/Source button. The display will show "BT" and flash, indicating it's in pairing mode.
2. On your Bluetooth device (e.g., smartphone, tablet), enable Bluetooth and search for available devices.
3. Select "Majority Naga 60" from the list.
4. Once paired, the soundbar will emit a confirmation tone, and the "BT" indicator will stop flashing.
5. To disconnect, switch to another input source or disable Bluetooth on your device.



Image: The Majority Naga 60 Soundbar with its display showing "BT", indicating Bluetooth mode. A smartphone is placed next to it, showing a music playback screen, illustrating Bluetooth connectivity.

USB Playback

1. Insert a USB drive (FAT32 format, up to 64GB) containing audio files into the **USB** port on the soundbar.
2. Select **USB** mode using the Input/Source button.
3. The soundbar will automatically begin playing audio files from the USB drive.
4. Use the Play/Pause, Next/Previous track buttons on the remote control to manage playback.

Sound Modes

The remote control may feature buttons for different sound modes (e.g., Music, Movie, Dialog, 3D). Press these buttons to optimize the audio for your content.



Image: A close-up of the black remote control for the Majority Naga 60 Soundbar, showing various buttons for power, input selection, volume, playback, and sound modes like Music, Movie, Dialog, and 3D.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the ventilation openings are clear and not blocked to prevent overheating.
- **Storage:** If storing the soundbar for an extended period, unplug it from the power outlet and store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected or power outlet not active.	Check that the power adapter is securely connected to the soundbar and a working power outlet.
No sound	Incorrect input source selected, volume too low, or incorrect TV audio settings.	Ensure the correct input source (HDMI, Optical, AUX, BT, USB) is selected. Increase the volume on both the soundbar and your TV/device. For Optical/HDMI ARC, check your TV's audio output settings (e.g., set to PCM for Optical). Ensure cables are securely connected.
Bluetooth pairing fails	Soundbar not in pairing mode, device too far, or interference.	Ensure the soundbar is in Bluetooth pairing mode (BT indicator flashing). Move your Bluetooth device closer to the soundbar. Try unpairing and re-pairing the device. Clear previous Bluetooth connections on your device.
Remote control not working	Batteries are dead or remote is out of range/blocked.	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the soundbar. Point the remote directly at the soundbar's sensor.

Specifications

Brand	Majority
Model Name	Naga 60
Maximum Speaker Output Power	120 Watts
Frequency Response	20000 Hz
Connectivity Technology	Auxiliary, Bluetooth, HDMI ARC, Optical
Audio Output Mode	Stereo
Input Voltage	240 Volts
Mounting Type	Wall mount or table top

Material	ABS plastic body with metal front grille
Speaker Type	Soundbar
Product Features	120W, 2.1 Channels, Bluetooth, HDMI ARC, Wall Mountable
Recommended Uses	Music player, Computer, Television
Color	Black
Water Resistance Level	Not waterproof
Maximum Range (Bluetooth)	10 Meters
Control Method	Push button, Remote control
Speaker Size	52 Millimeters
Audio Encoding	DTS 2.1
Includes MP3 Player	Yes
Number of Audio Channels	2.1
Impedance	4 Ohms
Signal-to-Noise Ratio	86.99 dB
Compatible Devices	Laptop, Smartphone, Tablet, Television
Power Source	Electric cable
Product Dimensions (L x D x H)	61 x 11.8 x 7.8 cm (approx. 24 x 4.65 x 3.07 inches)
Product Weight	2.96 kg (approx. 6.5 lbs)

Warranty and Support

The Majority Naga 60 Soundbar comes with a**3-Year Extended Warranty**. Registration may be required to activate the extended warranty. Please refer to the warranty card included in your package or visit the official Majority website for registration details and terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact Majority customer support through their official website or the contact information provided in your product packaging.
Online Resources: For additional support, FAQs, and product information, visit theMajority Brand Store.

© 2024 Majority. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DV9W6JHJ

More documents and user manuals: **https://manuals.plus/**