Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T'nB CBBOUNCE2SL

T'nB Bounce Max Wireless Headphones User Manual

Model: CBBOUNCE2SL

Brand: T'nB

Introduction

Thank you for choosing the T'nB Bounce Max Wireless Headphones. These over-ear headphones are designed to provide an immersive audio experience with superior comfort and convenience. Featuring Bluetooth connectivity, integrated microphone, and long-lasting battery life, the Bounce Max is perfect for enjoying your music and managing calls on the go.

This manual provides detailed instructions on how to set up, operate, and maintain your headphones to ensure optimal performance and longevity.



Image: T'nB Bounce Max Wireless Headphones in silver. These over-ear headphones feature a sleek metallic silver finish on the earcups and a light grey headband and ear cushions, designed for comfort and style.

Safety Information

Please read all safety warnings and instructions carefully before using this product to prevent injury or damage.

- **Hearing Protection:** Avoid listening at high volume levels for extended periods to prevent hearing damage.

- **Driving Safety:** Do not use headphones while driving or cycling, or in any situation where your inability to hear ambient sounds could pose a danger to yourself or others.
- **Water and Moisture:** Keep the headphones away from water and excessive moisture. Do not immerse them in liquid.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use harsh chemicals or abrasive materials.
- **Temperature:** Do not expose the headphones to extreme temperatures (hot or cold).
- **Disassembly:** Do not attempt to disassemble, repair, or modify the headphones. This will void the warranty.
- **Battery:** The headphones contain a rechargeable battery. Do not expose the battery to excessive heat or dispose of it in fire. Recycle responsibly.

Package Contents

Please check the package contents upon opening to ensure all items are present:

- T'nB Bounce Max Wireless Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable (Jack Cable)
- User Manual (this document)



Image: Front of the T'nB Bounce Max headphone packaging. The box prominently displays the headphones, brand logo, and "BOUNCE MAX" text, indicating key features like Bluetooth and 50H max playing time.



Image: Back of the T'nB Bounce Max headphone packaging. This view highlights features such as ultra comfort, removable and washable pads, explosive sound, rotating pads, 50H max playing time, built-in hands-free mic, built-in commands, USB-C cable included, and a 3.5mm jack cable for battery saving.

Product Overview

Familiarize yourself with the different parts of your T'nB Bounce Max headphones:

- **Earcups:** Over-ear design for passive noise reduction and comfort.
- **Ear Pads:** Removable and washable fabric ear pads.

- **Headband:** Adjustable and soft headband for ultra comfort.
- **Control Buttons:** Located on the earcup for managing music and calls. (Specific button functions detailed in Operating Instructions)
- **Microphone:** Integrated for hands-free calls.
- **USB-C Port:** For charging the headphones.
- **3.5mm Audio Jack:** For wired connection.



Image: Front view of the T'nB Bounce Max headphones. This image clearly shows the large, comfortable earcups and the padded headband, emphasizing the over-ear design.


tnb



Image: Top view of the T'nB Bounce Max headphones. This perspective highlights the design of the headband and how the earcups are attached, providing a sense of their overall structure.

Setup

1. Charging the Headphones

Before first use, fully charge your headphones. A full charge provides up to 50 hours of playback time.

1. Connect the small end of the USB-C charging cable to the USB-C port on the headphone earcup.
2. Connect the large end of the USB-C cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator on the headphones will show charging status (e.g., red for charging, blue for fully charged).

2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually the multi-function button) for approximately 3 seconds until the LED indicator lights up and you hear an audible prompt.
- **To Power Off:** Press and hold the Power button for approximately 5 seconds until the LED indicator turns off and you hear an audible prompt.

3. Bluetooth Pairing

Pair your headphones with your Bluetooth-enabled device (smartphone, tablet, computer).

1. Ensure the headphones are powered off.
2. Press and hold the Power button for about 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device, go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. Select "T'nB Bounce Max" from the list.
5. Once paired, the LED indicator will turn solid blue, and you will hear a confirmation sound.
6. If prompted for a password, enter "0000".

Note: The headphones will automatically attempt to reconnect to the last paired device when powered on.

4. Wired Connection (3.5mm Audio Cable)

You can use the headphones in wired mode, which conserves battery life or allows use when the battery is depleted.

1. Connect one end of the included 3.5mm audio cable to the 3.5mm audio jack on the headphone earcup.
2. Connect the other end of the cable to the audio output jack of your device (e.g., smartphone, MP3 player, computer).
3. In wired mode, the headphone's battery is not used, and some control functions on the headphones may be disabled (e.g., volume control, track skipping via headphone buttons).

Operating Instructions

The T'nB Bounce Max headphones feature intuitive controls for managing your audio and calls.

Music Playback Controls

Function	Action
Play/Pause	Press the Multi-function button once.
Next Track	Long press the "+" button.
Previous Track	Long press the "-" button.
Volume Up	Short press the "+" button.
Volume Down	Short press the "-" button.

Call Management

Function	Action
Answer/End Call	Press the Multi-function button once.
Reject Call	Press and hold the Multi-function button for 2 seconds.
Redial Last Number	Double-press the Multi-function button.

Maintenance

Proper maintenance will extend the life of your T'nB Bounce Max headphones.

- **Cleaning Ear Pads:** The fabric ear pads are removable and washable. Gently detach them from the earcups. Hand wash with mild soap and water, then air dry completely before reattaching.
- **Cleaning Headphones Body:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or spray directly onto the headphones.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the headphones at least once every three months if not used regularly.

Troubleshooting

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Solution
Headphones do not power on.	Ensure the headphones are charged. Connect them to a power source using the USB-C cable.

Problem	Solution
Cannot pair with Bluetooth device.	◦ Ensure headphones are in pairing mode (flashing red/blue LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device (within 10 meters). ◦ Turn off and on Bluetooth on your device, then try pairing again. ◦ If previously paired, try "forgetting" the device on your phone and re-pairing.
No sound or low volume.	◦ Increase volume on both the headphones and your connected device. ◦ Ensure the headphones are properly paired or the 3.5mm cable is fully inserted. ◦ Try playing different audio sources.
Sound is distorted or cuts out.	◦ Move closer to your Bluetooth device to avoid interference. ◦ Avoid obstacles between the headphones and your device. ◦ Ensure no other strong wireless signals are interfering.
Microphone not working.	◦ Ensure the headphones are connected via Bluetooth (microphone does not work in wired mode). ◦ Check microphone settings on your connected device.

Specifications

Feature	Detail
Model Name	CBBOUNCE2SL
Connectivity Technology	Wireless (Bluetooth) / Wired (3.5mm Jack)
Form Factor	Over-Ear (Circum-aural)
Color	Silver
Frequency Response	20 - 20000 Hz
Sensitivity	102 dB
Battery Life	Up to 50 hours (Wireless)
Microphone	Integrated
Ear Pads	Removable and Washable Fabric
Included Components	Headphones, USB-C Charging Cable, 3.5mm Audio Cable

Warranty and Support

T'nB products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included in your product packaging or visit the official T'nB website.

Official T'nB Website: www.tnb.com

Please have your model number (CBBOUNCE2SL) and proof of purchase ready when contacting support.

© 2025 T'nB. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DVLN3HDN

More documents and user manuals: **https://manuals.plus/**