Havells BT6112

Havells BT6112 Beard Trimmer User Manual

MODEL: BT6112

1. Introduction

The Havells BT6112 Beard Trimmer is designed for precise and efficient facial hair grooming. This device features skin-friendly stainless steel blades, offering a smooth and comfortable trimming experience. It supports both corded and cordless operation, providing flexibility and convenience for daily use.

This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your Havells BT6112 Beard Trimmer. Please read it thoroughly before first use and retain it for future reference.



Figure 1: Havells BT6112 Beard Trimmer

2. Safety Instructions

To reduce the risk of electric shock, injury, or damage, always observe the following safety precautions:

- Do not immerse the trimmer in water or use it near water (e.g., bathtubs, showers, sinks).
- Keep the appliance dry.
- Do not use the trimmer if it is damaged, or if the blades are broken or bent.
- Ensure the charging cable is not damaged before connecting to a power source.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use attachments supplied by the manufacturer.
- Unplug the trimmer from the power outlet before cleaning.

3. Product Components

The Havells BT6112 Beard Trimmer package typically includes the following items:

- Havells BT6112 Trimmer Unit
- Adjustable Comb Attachment
- USB Type-C Charging Cable
- Cleaning Brush

- Lubricating Oil (may vary by region)

HAVELLS

BEARD TRIMMER

BT6112



20 + TRIMMING SESSIONS
1.5 HOURS OF CHARGING GIVES 1.5 HOURS OF RUN TIME



0.5 mm ZERO TRIM LOOK
WITHOUT COMB ATTACHMENT



CUSTOMIZE SHAPE
BEARD LENGTH CAN BE CUSTOMIZED AS (3-4-5-6-10-11-12-13) mm USING THE COMB ATTACHMENT



SKIN FRIENDLY BLADES
U-SHAPED STAINLESS STEEL BLADE FOR SKIN- FRIENDLY SMOOTHER GLIDE



DUAL LED INDICATOR & TYPE C CHARGING PORT
RED & WHITE LED INDICATOR

Actual product may differ from the given picture.

www.havells.com

300524/V3

Figure 2: Packaging highlighting key features

4. Setup

4.1 Initial Charging

Before first use, fully charge the trimmer. The Havells BT6112 features a Li-ion quick charging battery.

1. Connect the USB Type-C charging cable to the charging port at the bottom of the trimmer.
2. Plug the other end of the cable into a suitable USB power adapter (not included) or a USB port.
3. The dual LED indicator will show charging status (Red/White LED).
4. A full charge takes approximately 90 minutes, providing up to 1.5 hours of cordless run time.



Figure 3: Type-C Charging Port

4.2 Attaching the Comb Attachment

To achieve desired beard lengths, attach the adjustable comb attachment:

1. Ensure the trimmer is turned off.
2. Align the comb attachment with the trimmer head and slide it on until it clicks into place.
3. To adjust the trimming length, use the integrated length adjustment mechanism on the comb. Available lengths typically range from 3mm to 13mm (e.g., 3-4-5-6-10-11-12-13 mm).
4. To remove, gently push the comb attachment away from the trimmer head.

5. Operating Instructions

5.1 Turning On/Off

- To turn on the trimmer, press the power button.

- To turn off the trimmer, press the power button again.

5.2 Using the Travel Lock

The travel lock feature prevents accidental switching while traveling.

- To activate the travel lock: Press and hold the power button for a few seconds until the indicator light flashes (refer to product specific indicator behavior).
- To deactivate the travel lock: Press and hold the power button again for a few seconds until the indicator light confirms unlocking.





Figure 4: Packaging highlighting travel lock feature

5.3 Trimming Your Beard

1. Ensure your beard is clean and dry.
2. Select the desired trimming length by adjusting the comb attachment. For a 0.5 mm 'zero trim' look, remove the comb attachment.
3. Turn on the trimmer.
4. Hold the trimmer with the blades flat against your skin.
5. Move the trimmer against the direction of hair growth for an even trim.
6. For detailing or shaping, use the trimmer without the comb attachment.
7. After trimming, turn off the trimmer and clean it as described in the Maintenance section.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your trimmer.

6.1 Cleaning the Blades

1. Ensure the trimmer is turned off and unplugged from any power source.
2. Remove the comb attachment.
3. Use the supplied cleaning brush to brush away any loose hairs from the blades and the trimmer head.
4. If the blades are detachable and washable (refer to product specifics), you may rinse them under running water. Ensure they are completely dry before reattaching or storing. Do not rinse the main body of the trimmer.



Figure 5: Trimmer blades for cleaning

6.2 Lubricating the Blades

Periodically, apply a small drop of lubricating oil (if supplied) to the blades to maintain their sharpness and smooth operation. Turn on the trimmer for a few seconds to distribute the oil evenly.

6.3 Storage

Store the trimmer in a cool, dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is discharged. Travel lock is activated.	Charge the trimmer. Deactivate the travel lock by pressing and holding the power button.
Poor trimming performance.	Blades are clogged with hair. Blades are not lubricated. Battery is low.	Clean the blades thoroughly. Apply lubricating oil to the blades. Charge the trimmer.
Trimmer stops during use.	Battery is depleted.	Recharge the trimmer. Use in corded mode if battery is low.

8. Specifications

Model: BT6112

Item Part Number: GHPTTABSBK00

Blade Material: Stainless Steel

Power Source: Rechargeable Li-ion Battery (Corded/Cordless operation)

Charging Time: Approximately 90 minutes

Run Time: Up to 90 minutes (1.5 hours)

Trim Length Settings: 0.5 mm (without comb), 3-13 mm (with comb attachment)

Product Dimensions (LxWxH): 40 x 70 x 170 mm

Item Weight: 140 g

Color: Black

Recommended Uses: Beard Styling, Trimming

9. Warranty and Support

Your Havells BT6112 Beard Trimmer comes with a**2-year manufacturer warranty** from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.

For warranty service, technical support, or inquiries, please contact Havells customer service. Details can typically be found on the official Havells website or product packaging.

Manufacturer: Imported By Havells India Limited

© 2025 Havells. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question