X-ALL XAHCWASHMACH6X20G

X-ALL Washing Machine Cleaner Instruction Manual

1. Product Overview

The X-ALL Washing Machine Cleaner is designed to provide a deep cleaning solution for your washing machine. These tablets effectively remove detergent residue, hard water buildup, limescale, and grime that cause unpleasant odors. Regular use helps maintain the efficiency and cleanliness of your appliance.
This product is compatible with all types of washing machines, including High-Efficiency (HE), front-load, top-load, and those with stainless steel drums.



Image 1.1: X-ALL Washing Machine Cleaner packaging.

2. Safety Information and Ingredients

2.1 Ingredients

The primary active ingredient in X-ALL Washing Machine Cleaner is Citric Acid.

2.2 Legal Disclaimer

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is for cleaning purposes only and should not be ingested.

2.3 General Safety Precautions

- Keep out of reach of children and pets.
- Avoid contact with eyes. In case of contact, rinse thoroughly with water.
- Do not ingest. If swallowed, seek medical attention immediately.

- Store in a cool, dry place away from direct sunlight.

3. Setup and Preparation

Before using the X-ALL Washing Machine Cleaner, ensure your washing machine is completely empty of laundry. No clothing or other items should be inside the drum during the cleaning cycle.

4. Operating Instructions

Follow these simple steps for effective cleaning of your washing machine:

1. **Empty Washer:** Ensure the washing machine drum is completely empty.
2. **Add Tablet:** Place one X-ALL Washing Machine Cleaner tablet directly into the washing machine drum. Do not place it in the detergent dispenser.
3. **Start Washer:** Close the washing machine door and select a hot water cycle. Start the washing machine. Allow the cycle to complete fully.



Image 4.1: Step-by-step guide for using the cleaner.



Image 4.2: Placing a tablet into the washing machine drum.

5. Maintenance and Frequency of Use

For optimal washing machine performance and to prevent the buildup of odors and residue, it is recommended to use X-ALL Washing Machine Cleaner once a month. Regular use helps to keep internal components clean, including pipes, which can accumulate grime over time.



Image 5.1: Example of buildup in washing machine pipes that the cleaner addresses.

5.1 AquaClean Enzyme Technology

The X-ALL Washing Machine Cleaner utilizes AquaClean Enzyme Technology. This advanced formula is designed to break down tough stains, grease, grime, and odor-causing residue effectively, ensuring a thorough clean without excessive scrubbing.

6. Troubleshooting

If you experience persistent odors or unsatisfactory cleaning results after using the X-ALL Washing Machine Cleaner, consider the following:

- **Ensure Hot Water Cycle:** Verify that a hot water cycle was selected and completed. Hot water enhances the effectiveness of the cleaning tablets.
- **Repeat Treatment:** For heavily soiled machines or severe odor issues, a second cleaning cycle with another tablet may be beneficial.
- **Check for Other Sources:** Inspect the detergent dispenser, door gasket (for front-load washers), and lint trap for any visible residue or mold that may require manual cleaning.

7. Specifications

Feature	Detail
Brand	X-ALL
Item Model Number	XAHCWASHMACH6X20G
Product Dimensions	4.33 x 0.79 x 3.94 inches
Item Weight	4.23 ounces
Item Form	Tablet
Scent	Fresh
Specific Uses For Product	Washing Machine Cleaning
Material Feature	Cruelty Free
Manufacturer	X-ALL
Date First Available	February 3, 2025

8. Warranty and Support

Warranty information for the X-ALL Washing Machine Cleaner is not provided within this instruction manual. For specific warranty details or product support, please contact the manufacturer directly through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question