Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Falk 2158L

FALK Kiddy Farm - Pedal Tractor with Trailer User Manual

Model: 2158L

Safety Information Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

Introduction

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your FALK Kiddy Farm Pedal Tractor with Trailer, Model 2158L. Please read this manual thoroughly before use to ensure safe and correct operation.



Image: The FALK Kiddy Farm Pedal Tractor with Trailer, Model 2158L, in red and cream colors, designed for young children.

Safety Information

Important: Adult supervision is required at all times when the product is in use. This product is designed for children aged 2 years and above, with a maximum weight capacity of 30 kg.

- Ensure all assembly steps are completed correctly before allowing a child to use the tractor.
- Do not use on public roads, near motor vehicles, or on steep inclines.
- Always wear appropriate safety gear, such as a helmet, when operating the tractor.
- Inspect the tractor regularly for loose parts, damage, or wear. Replace worn parts immediately.
- Keep hands and feet away from moving parts, especially pedals and wheels.



Image: The FALK Kiddy Farm tractor with labels indicating "Made in France", "2+ years", and "Max 30kg", highlighting key safety and usage parameters.

Setup and Assembly

The FALK Kiddy Farm Pedal Tractor requires assembly. Please follow these general steps. Refer to the included assembly diagram for detailed instructions specific to your product.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present.
2. **Attach Wheels:** Securely attach the front and rear wheels to the tractor chassis using the provided axles, washers, and locking pins. Ensure wheels spin freely but are firmly attached.
3. **Install Steering Column:** Insert the steering column into the designated opening in the tractor body. Connect the steering linkage to the front axle assembly.
4. **Mount Seat:** Attach the seat to the tractor body using the provided fasteners. Ensure it is stable and secure.
5. **Connect Pedals:** Assemble the pedal mechanism and connect it to the rear axle drive system. Test the pedal

function to ensure smooth rotation.

6. **Attach Trailer:** Connect the trailer hitch to the rear of the tractor. Ensure the connection is secure and allows for proper articulation.
7. **Final Inspection:** Before first use, double-check all connections, fasteners, and moving parts to ensure they are correctly assembled and tightened.

Operation

Operating the FALK Kiddy Farm Pedal Tractor is straightforward, designed for young children to enjoy.

- **Pedaling:** The tractor is pedal-powered. Instruct the child to place their feet on the pedals and push alternately to move the tractor forward.
- **Steering:** The steering wheel is directional. Turn the steering wheel left or right to change the direction of the tractor.
- **Horn:** The tractor is equipped with a horn. Press the center of the steering wheel to activate the horn.
- **Using the Trailer:** The detachable trailer can be used to transport small items. Ensure the trailer is securely attached to the tractor before loading. Do not overload the trailer.



Image: A child demonstrating the use of the FALK Kiddy Farm tractor, highlighting the directional steering wheel and the attached trailer for carrying items.

Maintenance

Regular maintenance will extend the life of your FALK Kiddy Farm Pedal Tractor.

- **Cleaning:** Clean the tractor with a damp cloth and mild soap. Avoid harsh chemicals that may damage the plastic.
- **Storage:** Store the tractor in a dry, sheltered area when not in use to protect it from weather elements.
- **Inspection:** Periodically check all nuts, bolts, and fasteners to ensure they are tight. Inspect wheels, pedals, and steering components for wear or damage.
- **Lubrication:** Lightly lubricate moving parts, such as pedal axles and steering joints, with a silicone-based lubricant if they become stiff.

Troubleshooting

Problem	Possible Cause	Solution
Tractor does not move when pedaling.	Pedal chain or mechanism is disconnected or damaged.	Inspect the pedal drive system. Reconnect or repair any disconnected parts. If damaged, contact support for replacement parts.
Steering is stiff or unresponsive.	Steering linkage is obstructed or needs lubrication.	Check for obstructions around the steering column and front wheels. Apply a silicone lubricant to steering joints.
Wheels wobble or are loose.	Axle nuts or locking pins are loose or missing.	Tighten axle nuts or replace missing locking pins. Ensure wheels are securely fastened.

Specifications

- **Brand:** Falk
- **Model:** 2158L
- **Sub-brand:** Kiddy Farm
- **Material:** Plastic, Metal
- **Product Dimensions (L x W x H):** 123 cm x 42 cm x 53 cm
- **Product Weight:** 6.5 Kilograms
- **Minimum Age (Manufacturer):** 24 months (2 years)
- **Maximum Weight Capacity:** 30 kg
- **Assembly Required:** Yes
- **Theme:** Farm
- **Spare Parts Availability (EU):** 2 Years



Image: Diagram illustrating the dimensions of the FALK Kiddy Farm Pedal Tractor: 123 cm length, 42 cm width, and 53 cm height.

Warranty and Support

Falk provides a commitment to quality for its products. Spare parts for this product are available for a period of 2 years within the EU, as per manufacturer's guidelines.
For technical assistance, replacement parts, or any inquiries regarding your FALK Kiddy Farm Pedal Tractor, please contact your retailer or the official Falk customer support. Please have your model number (2158L) and purchase information ready when contacting support.

© 2024 Falk. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DVZCNRD4

More documents and user manuals: **https://manuals.plus/**