Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nikon COOLPIX P1100

Nikon COOLPIX P1100 Digital Camera Instruction Manual

Model: COOLPIX P1100

1. Introduction

This manual provides essential information for the safe and effective use of your Nikon COOLPIX P1100 digital camera. Please read this manual thoroughly before using the camera and keep it accessible for future reference.
The Nikon COOLPIX P1100 is a high-performance compact digital camera featuring an exceptional optical 125x zoom lens, equivalent to 24-3000mm in 35mm format. It is designed for capturing distant subjects with clarity, from wildlife to celestial bodies, and also offers versatile close-up photography.

2. What's in the Box

Verify that all the following items are included in your camera package:

- Nikon COOLPIX P1100 Digital Camera Body
- EN-EL20a Rechargeable Li-ion Battery
- Lens Cap (LC-77)
- Lens Hood (HB-CP1)
- Camera Strap (AN-DC3)
- USB Cable (UC-E24)



Image: Included accessories for the Nikon COOLPIX P1100, showing the battery, lens cap, lens hood, strap, and USB cable.

3. Setup

3.1. Charging the Battery

1. Insert the EN-EL20a battery into the camera.
2. Connect the camera to a USB power source (e.g., a computer or a USB AC adapter) using the supplied UC-E24 USB cable.
3. The charging indicator will light up during charging and turn off when charging is complete. A full charge typically takes approximately 3 hours, depending on the power source.

3.2. Inserting a Memory Card

The COOLPIX P1100 uses SD, SDHC, or SDXC memory cards. Ensure the camera is off before inserting or removing a memory card.

1. Open the memory card/battery cover.
2. Insert the memory card into the slot with the label facing the correct direction until it clicks into place.
3. Close the cover securely.

3.3. Attaching the Strap and Lens Hood

- Attach the AN-DC3 camera strap to prevent accidental drops.
- Attach the HB-CP1 lens hood to reduce flare and protect the lens. Align the hood with the lens and twist until it locks into place.

4. Operating the Camera

4.1. Power On/Off

Press the power button to turn the camera on or off.

4.2. Basic Shooting

In auto mode, the camera automatically adjusts settings for optimal exposure. Frame your shot using the electronic viewfinder or the vari-angle LCD monitor, then press the shutter-release button halfway to focus and fully to take the picture.

4.3. Zoom Operation

The COOLPIX P1100 features an optical 125x zoom lens, providing a focal length range equivalent to 24-3000mm. Use the zoom control lever around the shutter button to adjust the focal length. For even greater reach, Dynamic Fine Zoom extends the range to approximately 6000mm equivalent while maintaining high image quality.



Image: A visual demonstration of the Nikon COOLPIX P1100's powerful zoom, illustrating the magnification from 24mm to 3000mm equivalent focal lengths, focusing on a zebra.

4.4. Special Shooting Modes

The camera features dedicated modes for specific subjects, accessible via the mode dial:

- **Bird Mode:** Optimized settings for capturing birds, allowing for precise autofocus area selection (Spot, Normal, Wide).
- **Moon Mode:** Ideal for photographing the moon, automatically adjusting exposure for clear, detailed lunar shots.



Image: The Nikon COOLPIX P1100's specialized modes, featuring a detailed moon shot and a vibrant duck, illustrating the effectiveness of the dedicated Moon and Bird modes on the camera's dial.

4.5. Macro Photography

For close-up shots, the COOLPIX P1100 offers a Macro AF function that allows you to focus on subjects as close as approximately 1 cm from the front of the lens. This is ideal for capturing intricate details of flowers or insects.



Image: An example of macro photography with the Nikon COOLPIX P1100, showcasing a pink flower captured with sharp detail at a minimum focusing distance of 1cm.

4.6. Image Stabilization (VR)

The camera is equipped with Dual Detect Optical VR (Vibration Reduction), providing a compensation effect equivalent to 4.0 stops. This helps to minimize blur caused by camera shake, especially when shooting at high zoom ratios or in low light conditions. You can select between NORMAL (composition priority) and ACTIVE (composition priority) VR modes.

5. Connectivity (SnapBridge)

The COOLPIX P1100 supports SnapBridge, allowing you to connect the camera to a smart device (smartphone or tablet) via Bluetooth. With SnapBridge, you can:

- Automatically transfer photos to your smart device as you shoot.
- Upload images to social media instantly.

- Use your smart device for remote camera control.



Image: The SnapBridge feature in action, demonstrating seamless and automatic image transfer from the Nikon camera to a smartphone via Bluetooth connection.

6. Maintenance and Care

- **Cleaning:** Use a blower to remove dust from the lens and camera body. For stubborn smudges, use a soft, clean cloth specifically designed for optical lenses.
- **Storage:** Store the camera in a cool, dry, well-ventilated area away from direct sunlight, high temperatures, and humidity. Remove the battery if the camera will not be used for an extended period.
- **Battery Care:** Charge the battery fully before use. Avoid exposing the battery to extreme temperatures.

7. Troubleshooting

7.1. Camera Does Not Turn On

- Ensure the battery is fully charged and correctly inserted.
- Check if the battery terminals are clean.

7.2. Images Are Blurry

- Check if the lens is clean.
- Ensure the camera is stable; use a tripod for high zoom shots.
- Verify that VR (Vibration Reduction) is enabled.
- Check focus settings.

7.3. Cannot Connect to Smart Device

- Ensure Bluetooth is enabled on both the camera and the smart device.
- Make sure the SnapBridge app is installed and running on your smart device.
- Try restarting both devices.

8. Specifications

Model Name	COOLPIX P1100
Effective Pixels	16.9 MP
Image Sensor	1/2.3-inch CMOS
Lens	Optical 125x zoom NIKKOR lens
Focal Length	4.3 to 539 mm (35mm equivalent: 24 to 3000 mm)
Digital Zoom	Up to 4x (approx. 12000 mm equivalent with optical zoom)
Dynamic Fine Zoom	Up to 2x (approx. 6000 mm equivalent with optical zoom)
Vibration Reduction (VR)	Dual Detect Optical VR (approx. 4.0 stops)
Monitor	3.2-inch vari-angle TFT LCD
Viewfinder	Electronic viewfinder
Storage Media	SD, SDHC, SDXC memory cards
File Formats	Still images: JPEG, Nikon RAW; Movies: MP4 (Video: H.264/MPEG-4 AVC, Audio: AAC stereo)
Movie Recording	4K UHD (3840 x 2160), Full HD (1920 x 1080)
Connectivity	Bluetooth (SnapBridge), USB
Power Source	EN-EL20a Rechargeable Li-ion Battery

Dimensions (W x H x D)	Approx. 140.2 x 110.2 x 149.8 mm (excluding projections)
Weight	Approx. 1005 g (including battery and memory card)

9. Warranty and Support

Your Nikon COOLPIX P1100 camera comes with a**1-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical support, service, or further inquiries, please visit the official Nikon website or contact your local Nikon customer service center.

© Nikon Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DW3Z2BPS

More documents and user manuals: **https://manuals.plus/**