Wfhdtx 612

Wfhdtx 61-Key Electronic Digital Piano Model 612 User Manual

1. Introduction

Thank you for purchasing the Wfhdtx 61-Key Electronic Digital Piano, Model 612. This manual provides essential information for the safe and effective use of your new instrument. Please read these instructions thoroughly before operation and retain them for future reference.

2. Package Contents

Verify that all items listed below are included in your package:

- Wfhdtx 61-Key Electronic Digital Piano
- Power Adapter
- Microphone
- Music Sheet Stand
- User Manual (this document)



Image: The Wfhdtx 61-Key Electronic Digital Piano shown with its accompanying microphone, power adapter, and detachable music sheet stand.

3. Product Overview

The Wfhdtx 61-Key Electronic Digital Piano features a standard 61-key layout, an integrated control panel, dual speakers, and various connectivity options for an enhanced musical experience.

3.1 Keyboard Layout



Image: A detailed view of the 61 full-size keys, highlighting the black and white key arrangement.

The keyboard consists of 61 keys, providing a range suitable for beginners to practice various musical pieces.

3.2 Control Panel and Functions

The central control panel includes buttons for power, volume adjustment, tone selection, rhythm selection, demo songs, recording, and chord functions. An LCD display provides visual feedback on selected settings.



Image: An overview of the piano's capabilities, including 140 Tones, 128 Rhythms, 61 keyboard percussion sounds, 60 Demo Songs, Multi-finger chord, Duet function, Metronome, Sustain/Tremolo, and Recording functions.

3.3 Connectivity Ports



Image: A visual guide to the piano's connection points, including ports for headphones, microphone, auxiliary audio input, and the DC 5V power supply.

- **DC 5V Input:** For connecting the included power adapter.
- **MIC Input:** For connecting the included microphone.
- **PHONE Output:** For connecting headphones (3.5mm jack) for private practice.
- **AUDIO IN:** For connecting external audio sources.

4. Setup Instructions

4.1 Power Connection

Your piano can be powered by the included AC power adapter or by 1.5V AA batteries (not included).

1. **Using AC Adapter:** Connect the power adapter to the DC 5V input port on the piano and then plug the adapter into a standard electrical outlet.
2. **Using Batteries:** Open the battery compartment on the underside of the piano. Insert six (6) 1.5V AA batteries,

ensuring correct polarity. Close the compartment securely.

4.2 Attaching the Music Sheet Stand

Insert the two prongs of the music sheet stand into the designated slots on the top panel of the piano, located behind the control panel. Ensure it is firmly seated.

4.3 Connecting the Microphone

Plug the microphone cable into the MIC input port on the piano.

5. Operating Instructions

5.1 Power On/Off and Volume

- **Power:** Press the 'POWER' button to turn the piano on or off.
- **Volume:** Use the 'VOLUME +' and 'VOLUME -' buttons to adjust the overall sound level.

5.2 Selecting Tones (Voices)

The piano offers a variety of instrument sounds. To select a tone:

1. Press the 'TONE' button.
2. Use the number buttons or '+' / '-' buttons to cycle through the available tones. The selected tone number will appear on the LCD display.

5.3 Selecting Rhythms

To add a rhythmic accompaniment:

1. Press the 'RHYTHM' button.
2. Use the number buttons or '+' / '-' buttons to select a rhythm.
3. Press 'START/STOP' to begin or end the rhythm.
4. Adjust the tempo using the 'TEMPO +' and 'TEMPO -' buttons.

5.4 Playing Demo Songs

The piano includes pre-recorded demo songs for enjoyment and learning:

1. Press the 'DEMO A' or 'DEMO B' button to play a demo song.
2. Press the button again to stop playback.

5.5 Recording and Playback

Record your own performances:

1. Press the 'RECORD' button. The recording indicator will light up.
2. Play your desired melody on the keyboard.
3. Press 'PLAY' to listen to your recorded performance.

5.6 Chord Functions

The piano supports various chord modes:

- **Single Chord:** Press the 'SINGLE' button, then play a single key in the left-hand section to trigger a chord.

- **Fingered Chord:** Press the 'FINGER' button, then play a full chord in the left-hand section.
- **Chord Off:** Press the 'CHORD OFF' button to disable chord functions.

5.7 Sustain and Vibrato

Enhance your sound with effects:

- **Sustain:** Press the 'SUSTAIN' button to add a lingering effect to notes.
- **Vibrato:** Press the 'VIBRATO' button to add a slight pitch modulation to notes.

5.8 Microphone Use

After connecting the microphone to the MIC input, you can sing along while playing the piano. Adjust the microphone volume using the main volume controls.

6. Maintenance

- **Cleaning:** Wipe the piano surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the piano in a cool, dry place away from direct sunlight and extreme temperatures.
- **Power:** Disconnect the power adapter when not in use for extended periods. Remove batteries if the piano will not be used for a long time to prevent leakage.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Power adapter not connected; batteries drained or incorrectly inserted.	Ensure adapter is securely plugged in. Replace batteries or check polarity.
No sound	Volume too low; headphones connected.	Increase volume. Disconnect headphones if sound is desired from speakers.
Microphone not working	Microphone not properly connected.	Ensure microphone is fully plugged into the MIC input.
Keys not responding	Piano may be in a specific mode (e.g., demo mode).	Turn the piano off and on again to reset.

8. Specifications

Feature	Detail
Model Number	612
Number of Keys	61
Power Source	Corded Electric (DC 5V), 6 x 1.5V AA Batteries
Connectivity	Microphone Input, Headphone Output (3.5mm Jack), Audio In
Material Type	Plastic

Feature	Detail
Item Weight	4.14 pounds (approx. 1.88 kg)
Package Dimensions	32.8 x 9.8 x 3.8 inches (approx. 83.3 x 24.9 x 9.7 cm)
UPC	763300400665



Image: Visual representation of the piano's dimensions (width, depth, height) and approximate weight.

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Wfhdtx website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question