Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Czlife F9

Czlife F9 Portable Fan User Manual

Model: F9 (TM-520E)

1. Introduction

Thank you for choosing the Czlife F9 Portable Fan. This manual provides essential information for the safe and efficient operation of your fan. Please read it thoroughly before use and retain it for future reference.



Figure 1: Czlife F9 Portable Fan showcasing its versatile design as a compact unit, a desk fan, and an extended standing fan.

Key Features:

- **10000mAh Rechargeable Battery:** Provides extended cordless operation and functions as a power bank.
- **Foldable & Telescopic Design:** Adjustable height from 4 inches (10cm) to 39 inches (98cm) for various uses.
- **Multi-functional Controls:** Features 4 speed settings, 1-8 hour timer, and oscillation via integrated buttons or remote control.
- **Multi-Angle Airflow:** Offers 90° horizontal oscillation and 180° vertical tilt for comprehensive air circulation.
- **Portable & Compact:** Equipped with a handle for easy transport and storage.
- **Easy Maintenance:** Detachable front grille for convenient cleaning.

2. Setup

2.1 Unfolding the Fan

1. Locate the "OPEN" indicator on the base of the fan. Gently open the fan along the indicated direction.

2. Adjust the tilting direction of the fan head and the up-and-down angle to your desired position.
3. Extend the telescopic rod to adjust the fan's height as required, from a compact desk fan to a full-size standing fan.



Figure 2: Step-by-step guide for unfolding and adjusting the fan's height and angle.

2.2 Initial Charging

Before first use or long-term storage, fully charge the fan. Connect the provided USB-C cable to the fan's charging port and a suitable power source. The fan is equipped with a 10000mAh battery, offering up to 30 hours of continuous operation depending on settings. It can also function as a power bank to charge other devices via its USB 2.0 output port.



Figure 3: The fan's base showing the Type-C input for charging the fan and the USB 2.0 output for charging external devices.

3. Operating Instructions

3.1 Controls

The fan can be controlled using the buttons on its base or the included remote control. The remote control can be stored in a dedicated slot on the fan's base.



Figure 4: Overview of the fan's control panel and remote control functions.

- **Power On/Off:** Press the power button to turn the fan on or off.
- **Speed Settings:** Cycle through 4 fan speeds (1, 2, 3, 4) to adjust airflow intensity.
- **Timer Function:** Set the fan to operate for a specific duration (1, 2, 4, or 8 hours) before automatically turning off.
- **Oscillation:** Activate 90° horizontal oscillation for wider air distribution. The fan also supports 180° manual vertical tilt.

Note: The oscillation feature is disabled during charging to avoid stress on the charging port and extend the fan's life.



Figure 5: The fan's oscillation function provides wide area cooling.

4. Maintenance

4.1 Cleaning the Fan

To ensure optimal performance and hygiene, regular cleaning is recommended. The front grille of the fan is detachable for easy access to the blades.

1. Ensure the fan is turned off and unplugged before cleaning.
2. Gently twist the front grille counter-clockwise to detach it from the fan body.
3. Wipe the fan blades and the inside of the grille with a soft, damp cloth. Do not rinse the main fan body directly with water.
4. Once clean and dry, reattach the front grille by aligning it and twisting clockwise until secure.



Figure 6: Instructions for detaching the front cover for cleaning.

For safety, keep children away from fan blades during operation.

5. Troubleshooting

Common Issues and Solutions:

- **Fan does not turn on:** Ensure the battery is charged. Connect the fan to a power source using the USB-C cable.
- **Oscillation not working:** The oscillation feature is automatically disabled when the fan is charging. Disconnect the charging cable to enable oscillation.
- **Reduced airflow or unusual noise:** Check if the front grille or fan blades are obstructed or dirty. Refer to the Maintenance section for cleaning instructions.
- **Remote control not responding:** Ensure there are no obstructions between the remote and the fan. Check the remote's battery.
- **Short battery life:** Ensure the fan is fully charged before use. Battery performance can vary based on speed settings and usage patterns.

6. Specifications

Feature	Detail
Brand	Czlife
Model Name	F9
Item Model Number	TM-520E
Color	Black
Power Source	Battery Powered
Battery Capacity	10000mAh
Product Dimensions	7.7"D x 7.7"W x 3.93"H
Adjustable Height	4" to 39"
Noise Level	30 Decibels

Control Method	Touch, Remote
Special Features	Adjustable Height, Foldable, Oscillating, Portable, Timer, Power Bank Function
Included Components	Remote, USB-C Cable, Instruction Manual

7. Warranty and Support

For any questions or concerns regarding your Czlife F9 Portable Fan, please contact our customer support team. We are committed to assisting you with product use and any issues you may encounter.

- **Customer Support:** Please refer to the contact information provided with your product packaging or visit the official Czlife website.
- **Optional Accessories:** A storage bag and a charging head are available for separate purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWRWWHLG

More documents and user manuals: **https://manuals.plus/**