Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE YR-H71

XINFUTE YR-H71 Air Conditioner Remote Control Instruction Manual

Model: YR-H71 / 0010451255V

1. Introduction

This manual provides comprehensive instructions for the XINFUTE YR-H71 Air Conditioner Remote Control. Designed for compatibility with various Haier air conditioner models, including YR-H49, this remote offers intuitive control over your unit's functions. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

2. Setup

2.1 Battery Installation

The XINFUTE YR-H71 remote control requires two (2) AAA batteries for operation. No pairing or programming is required; simply insert the batteries correctly, and the remote will be ready for use.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align with the polarity indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important Battery Information:

- Do not mix old and new batteries.
- Do not use batteries of different types together.
- If the remote control malfunctions, remove the batteries and reload new ones after six minutes.



Figure 1: Battery compartment open, showing correct battery insertion.



Figure 2: Battery compartment closed after installation.

3. Operating Instructions

The XINFUTE YR-H71 remote control provides access to various functions of your air conditioner. Familiarize yourself with the button layout for efficient use.



Figure 3: Front view of the XINFUTE YR-H71 remote control.

3.1 Basic Functions

- **ON/OFF Button:** Press to turn the air conditioner on or off.
- **TEMP ▲/▼ Buttons:** Adjust the desired temperature setting. Press ▲ to increase temperature, ▼ to decrease.
- **MODE Button:** Cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **FAN Button:** Adjust the fan speed (e.g., Low, Medium, High, Auto).

3.2 Advanced Functions

- **SWING Button:** Activates or deactivates the automatic swing function of the air conditioner's louvers.

- **SLEEP Button:** Engages the sleep mode, which typically adjusts temperature and fan speed for comfortable sleep and energy saving.
- **HEALTH Button:** Activates specific health-related functions, if available on your air conditioner model.
- **FRESH Button:** Activates the fresh air or air purification function, if available.
- **TIMER Button:** Sets a timer for the air conditioner to turn on or off automatically. Use with the SET button to configure.
- **FILTER Button:** Indicates when the air filter needs cleaning or replacement. Press to reset after maintenance.
- **CODE Button:** Used for specific model coding or pairing, though this remote typically requires no pairing. Consult your air conditioner manual if issues arise.
- **LIGHT Button:** Controls the display light on the air conditioner unit.
- **LOCK Button:** Locks the remote control buttons to prevent accidental changes. Press again to unlock.
- **RESET Button:** Resets the remote control to its default settings. Use a pointed object to press.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or the display fades. Always replace both batteries simultaneously with new AAA batteries. Ensure correct polarity during installation.

4.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners, abrasive materials, or solvents, as these can damage the remote's finish or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - If the remote control exhibits disorder, remove the batteries and reload new ones after approximately six minutes.
- **Air conditioner not responding to specific functions:**
  - Verify that your air conditioner model supports the specific function (e.g., Health, Fresh).
  - Ensure the remote is pointed directly at the air conditioner's receiver.

6. Specifications

- **Model Name:** YR-H71 / 0010451255V
- **Brand:** XINFUTE
- **Product Dimensions:** 4 x 3 x 1 inches
- **Item Weight:** 2.4 ounces
- **Batteries:** 2 AAA batteries required (not included)

- **Material:** ABS
- **Max Number of Supported Devices:** 1

7. Warranty and Support

This product comes with a one-year warranty from the date of purchase. All goods are inspected before shipment to ensure quality. If you are not satisfied with your purchase, please contact us within 24 hours of receipt for assistance.
For further support or inquiries, please refer to the seller's contact information provided at the time of purchase.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DWWQY8RR

More documents and user manuals: **https://manuals.plus/**