Cosori CAF-DC601-KEU

Cosori Turbo Blaze 6-Liter Air Fryer Instruction Manual

Model: CAF-DC601-KEU

Introduction

Thank you for purchasing the Cosori Turbo Blaze 6-Liter Air Fryer. This manual provides essential information for safe operation, maintenance, and troubleshooting. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance and its cord out of reach of children.
- Do not operate any appliance with a damaged cord or plug.
- Do not use accessories not recommended by the manufacturer.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.
- Unplug from outlet when not in use and before cleaning.
- The appliance operates at 220 Volts.

Package Contents

- 1 x Cosori Turbo Blaze 6-Liter Air Fryer
- 1 x User Manual
- 1 x Recipe Book (recipes also available via VeSync app, though the device is not Wi-Fi enabled)

Specifications

Model Name	TurboBlaze
Model Number	CAF-DC601-KEU

Capacity	6 Liters
Power Output	1725 Watts
Voltage	220 Volts
Temperature Range	30°C - 230°C
Control Method	Touch Control
Dimensions (D x W x H)	40 cm x 30.1 cm x 30 cm
Weight	6 Kilograms
Internal Material	Stainless Steel with Ceramic Coating
Dishwasher Safe Parts	Basket and Crisper Plate
Special Features	DC Motor with 5 Fan Speeds, 9 Cooking Functions

Setup and First Use

Before First Use

1. Remove all packaging materials from the air fryer.
2. Clean the basket and crisper plate thoroughly with warm, soapy water. Rinse and dry completely.
3. Wipe the inside and outside of the air fryer with a damp cloth.
4. Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.



Image: Cosori Air Fryer showing its dimensions (40D x 30.1W x 30H cm) and basket size (23.65D x 23.65W x 11.4H cm).



Image: The 6-liter air fryer basket, demonstrating its depth of 17.8 cm, suitable for larger items like bell peppers.

Initial Run

It is recommended to run the air fryer empty for a short period to eliminate any manufacturing odors.

1. Plug the air fryer into a grounded outlet.
2. Pull out the basket. Place the crisper plate inside the basket.
3. Insert the basket back into the air fryer.
4. Select a preset like "Air Fry" and set the temperature to 200°C and time to 10 minutes.
5. Press the Start/Pause button.
6. A slight odor may be present during this initial run; this is normal.
7. Once complete, allow the air fryer to cool down before proceeding.

Operating Instructions

Control Panel Overview

The Cosori Turbo Blaze features a touch control panel for easy operation. It includes 9 preset functions and 5 fan speeds for precise cooking.



Image: The touch control panel showing various cooking modes and settings, including temperature and time adjustments.

Cooking Functions and Fan Speeds

The Turbo Blaze utilizes a DC motor with 5 fan speeds and precise temperature control from 30°C to 230°C, offering versatility for various dishes.

- **Air Fry, Roast, Grill:** Use Fan Speed 5 for crispy results.
- **Reheat, Frozen:** Ideal for quick snacks, use Fan Speeds 4 and 5.
- **Proof, Bake:** For baking bread, cakes, and pastries.
- **Dehydrate:** For drying fruits and vegetables.
- The fan operates quietly, with Fan Speed 5 producing less than 53dB.



Image: Example of crispy food, such as fried chicken, prepared using the air fryer's Turbo Fan Speed.



Image: Demonstrates the versatility of the air fryer with functions like baking muffins, proofing dough, and dehydrating oranges.

General Cooking Tips

- Use up to 95% less oil compared to traditional deep frying.
- The air fryer can cook up to 67% more energy-efficiently than a conventional oven.
- Refer to the included recipe book and cooking charts for recommended times and temperatures.
- For best results, shake the basket or flip food halfway through cooking for even browning.



Image: Illustrates quick meal preparation, showing dishes cooked in 6 and 8 minutes, highlighting speed and energy efficiency.



Image: A diagram illustrating the 360° air circulation and enhanced airflow within the air fryer for uniform cooking.



Image: Depicts the quiet operation of the air fryer, noting a sound level as low as 27 dB, like a whisper.

Care and Maintenance

Cleaning

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The basket and crisper plate are dishwasher safe for easy cleaning.
- For stubborn food residue, soak the basket and crisper plate in warm, soapy water for 15-20 minutes.
- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners.
- Clean the heating element with a non-abrasive sponge or brush if necessary, ensuring the appliance is unplugged.



Image: The air fryer basket being placed into a dishwasher, illustrating its dishwasher-safe feature for effortless cleaning.

Storage

Ensure the air fryer is clean and dry before storing. Store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet not working; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the basket in completely.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped.	Cook in smaller batches. Shake or flip food halfway through cooking.

White smoke coming from the air fryer.	Grease from previous cooking; fatty foods.	Clean the basket and crisper plate thoroughly after each use. Remove excess oil from food.
Appliance smells during first use.	Residual manufacturing odors.	This is normal. Run the air fryer empty for 10 minutes at 200°C before first use.

Warranty and Customer Support

Cosori provides a 2-year warranty for this product. For any questions, concerns, or issues regarding your air fryer, please contact Cosori Customer Support.

- **Email:** support.it@cosori.com
- Please have your model number (CAF-DC601-KEU) and purchase information ready when contacting support.

© 2026 Cosori. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question