joliker M301-EU-V3

joliker M301-EU-V3 80GB MP3/MP4 Player User Manual

Model: M301-EU-V3

1. Introduction

Thank you for choosing the joliker M301-EU-V3 MP3/MP4 Player. This device combines advanced audio and video playback capabilities with smart features like Wi-Fi and Bluetooth connectivity, an integrated camera, and access to the Google Play Store. This manual provides essential information for setting up, operating, and maintaining your device to ensure optimal performance and longevity.



Image 1.1: The joliker M301-EU-V3 MP3/MP4 Player, showcasing its sleek design and touchscreen interface.

2. Package Contents

Please check the box for the following items:

- 1x joliker M301-EU-V3 MP3/MP4 Player
- 1x USB Type-C Charging Cable
- 1x Wired Headphones
- 1x 64GB TF Card (pre-installed or separate)
- 1x Protective Film
- 1x Protective Sleeve

3. Product Overview

Familiarize yourself with the device's components:

- **4.02-inch IPS Touchscreen:** For navigation and content display.
- **Power Button:** Located on the side, used to turn the device on/off or wake/sleep the screen.
- **Volume Buttons:** Adjust audio output.
- **USB Type-C Port:** For charging and data transfer.
- **3.5mm Audio Jack:** For connecting wired headphones.
- **MicroSD Card Slot:** For expanding storage (supports up to 512GB).
- **Rear Camera:** 13-megapixel camera for photos and videos.
- **Integrated Speaker:** For audio playback without headphones.



Image 3.1: The device screen displaying various applications and indicating Wi-Fi and Bluetooth connectivity.

4. Setup

4.1. Charging the Device

Before first use, fully charge the device. Connect the provided USB Type-C cable to the player's USB-C port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status.



Image 4.1: The USB Type-C port offers faster and more convenient charging compared to older Micro USB ports.

4.2. Inserting the TF Card

The device comes with a 64GB TF card. To insert or replace the card, locate the TF card slot on the side of the player. Gently push the card into the slot until it clicks into place. Ensure the card is oriented correctly. To remove, push the card in again until it springs out.



Image 4.2: The device showing the TF card slot and the included 64GB TF card, highlighting expandable storage.

4.3. Initial Power On

Press and hold the Power button until the screen lights up. Follow the on-screen prompts to complete the initial setup, including language selection and basic settings.

4.4. Wi-Fi Connection

To connect to Wi-Fi: Go to**Settings > Network & Internet > Wi-Fi**. Turn on Wi-Fi, select your desired network, and enter the password if required. This enables access to online streaming services and the Play Store.



Image 4.3: The device demonstrating Wi-Fi connectivity, allowing access to online applications and content.

4.5. Bluetooth Connection

To connect to Bluetooth devices (e.g., headphones, speakers): Go to**Settings > Connected devices > Bluetooth**. Turn on Bluetooth, scan for available devices, and select your device to pair. Ensure your Bluetooth accessory is in pairing mode.



Image 4.4: The device connected wirelessly to headphones via Bluetooth 4.1, offering audio freedom.

5. Operating Instructions

5.1. Music Playback

The device supports MP3, WAV, APE, FLAC, and AAC formats. Use the pre-installed music player or download your preferred music app from the Play Store. Navigate to your music library, select a track, and use the on-screen controls for playback (play, pause, skip, volume).



Image 5.1: The integrated music application, featuring powerful equalizer settings and support for various audio formats.

5.2. Video Playback

The player supports 1080p video playback in AVI, MKV, RMVB, MP4, MPG, and MOV formats. Access your video files through the Gallery or a dedicated video player app. Tap on a video to play it, and use the touchscreen for playback controls.



Image 5.2: The device displaying a video on its 4.02-inch IPS touchscreen, offering clear visuals.

5.3. Camera Usage

The device features a 13-megapixel rear camera. Open the Camera app from the home screen. Tap to focus and press the shutter button to capture photos or start/stop video recording. Photos and videos are saved to the device's internal storage or TF card.



Image 5.3: The device's 13MP camera capturing a clear image, suitable for everyday photography.

5.4. App Installation (Play Store)

With Wi-Fi connected, you can access the Google Play Store to download and install additional applications like Spotify, Deezer, Audible, and more. Tap on the Play Store icon, search for your desired app, and follow the installation prompts.

6. Specifications

Feature	Specification
Brand	joliker
Model Name	M301-EU-V3
Connectivity Technology	Auxiliary, Bluetooth 4.1, USB Type-C, Wi-Fi

Memory Storage Capacity	80 GB (16GB internal + 64GB TF card)
Expandable Storage	Up to 512 GB via Micro SD
Screen Size	4.02 Inches IPS Touchscreen
Screen Resolution	640 x 1136 pixels
Processor	8-core MTK
RAM	2 GB
Operating System	Android 9.0
Camera	13 Megapixels (Rear)
Battery Capacity	2000 mAh Lithium
Battery Life (Music)	45-50 hours
Battery Life (Video)	6-8 hours
Supported Audio Formats	MP3, WAV, APE, FLAC, AAC
Supported Video Formats	AVI, MKV, RMVB, MP4, MPG, MOV
Special Features	Built-in Camera, Voice Recorder, Built-in Speaker, FM Radio, Equalizer



Image 6.1: An illustration detailing the device's 8-core MTK processor, Android 9.0 operating system, 2GB RAM, and 16GB ROM.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screen and body. Avoid abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and do not let the battery fully discharge frequently. Charge regularly.
- **Software Updates:** Periodically check for system updates in **Settings > System > System update** to ensure optimal performance and security.
- **Storage Management:** Regularly clear unnecessary files and apps to free up storage space and maintain device speed.
- **Protection:** Use the provided protective film and sleeve to guard against scratches and minor impacts.

8. Troubleshooting

Problem	Solution
Device won't turn on	Ensure the battery is charged. Connect to a charger for at least 30 minutes, then try powering on again. If unresponsive, perform a hard reset (refer to specific instructions if available, usually holding power button for 10-15 seconds).
Cannot connect to Wi-Fi	Check if Wi-Fi is enabled in settings. Ensure the Wi-Fi password is correct. Restart the device and the Wi-Fi router.
Bluetooth device not pairing	Ensure Bluetooth is enabled on both devices and they are in pairing mode. Keep devices close to each other. Try restarting both devices.
Slow performance or freezing	Close unused applications. Clear cache and data for problematic apps. Free up storage space. Restart the device.
Music/Video files not playing	Verify the file format is supported. Ensure files are not corrupted. Try a different media player app.

9. Warranty and Support

Your joliker M301-EU-V3 MP3/MP4 Player is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact joliker customer service through the retailer where you purchased the product or visit the official joliker website.

Online Support: www.joliker.com/support (Example link, please replace with actual support URL)

Email Support: support@joliker.com (Example email, please replace with actual support email)

© 2024 joliker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question