Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE AR-JE6

XINFUTE AR-JE6 AC Remote Control User Manual

Model: AR-JE6

Introduction

This manual provides comprehensive instructions for the XINFUTE AR-JE6 AC Remote Control. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your remote control.

Product Overview

The XINFUTE AR-JE6 is a replacement remote control designed for various FUJITSU General air conditioner models. It offers essential functions for controlling your AC unit, including temperature adjustment, fan speed, mode selection, and timer settings.



Image: Front view of the XINFUTE AR-JE6 AC Remote Control, displaying its buttons and LCD screen.

Compatibility

This remote control is compatible with the following FUJITSU General AC models:

- AR-JE4
- AR-JE10
- AR-JE5
- AR-JE9

It functions as a direct replacement for the original remote controls of these models.

Setup: Battery Installation

The AR-JE6 remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Important:

- Do not mix old and new batteries.
- Do not mix batteries of different types.
- Ensure correct polarity (+/-) when inserting batteries.



Image: Back view of the remote control with the battery compartment open, showing where to insert two AAA batteries.

Operating Instructions

Familiarize yourself with the buttons on your AR-JE6 remote control to operate your air conditioner effectively.



Image: Front and back views of the remote control, highlighting the button layout and battery compartment label.

Button Functions:

START/STOP (Orange Button): Powers the air conditioner ON or OFF.

MASTER CONTROL: Cycles through operating modes (AUTO, COOL, DRY, FAN).

SET TEMP. (Up/Down Arrows): Adjusts the desired temperature setting.

FAN CONTROL: Cycles through fan speeds (AUTO, HIGH, MED, LOW, QUIET).

SLEEP: Activates or deactivates the sleep mode for comfortable night operation.

TEST RUN: Initiates a test operation of the AC unit (typically for service or installation).

SET: Confirms selected settings, often used with timer functions.

SWING: Controls the louver swing function for air distribution.

ACL (Reset Button): A small recessed button, typically used for resetting the remote or AC unit settings. Use a thin, pointed object to press.

TIMER (ON/OFF/SET/CANCEL):

- **ON:** Sets a timer for the AC to turn on.
- **OFF:** Sets a timer for the AC to turn off.
- **SET:** Confirms the timer setting.
- **CANCEL:** Cancels any active timer setting.

Specifications

Model Number	AR-JE6
Dimensions	4 x 3 x 1 inches (approximately)
Item Weight	2.4 ounces (without batteries)
Battery Type	2 x AAA batteries (not included)
Material	ABS Material

Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new ones.
- **Battery Type:** Confirm you are using two AAA batteries.
- **Obstruction:** Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- **Distance:** Operate the remote within the effective range of the air conditioner.
- **AC Unit Power:** Verify that the air conditioner unit itself is powered on and functioning.

Incorrect Functionality:

- **Reset Remote:** Press the ACL (reset) button using a thin, pointed object. This may restore default settings.
- **Compatibility:** Double-check that your AC model is listed as compatible with the AR-JE6 remote.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance degrades or the display becomes dim. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

Warranty and Support

This product comes with a one-year warranty from the date of purchase. If you encounter any issues or are not satisfied with your purchase, please contact the seller within 24 hours of receipt. All goods are inspected before shipment to ensure quality.
For further assistance, please refer to the seller's contact information provided at the point of purchase or visit the XINFUTE Store on Amazon.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DX226XKS

More documents and user manuals: **https://manuals.plus/**